

JT5

Operator's Manual



CMW®

Issue 1.0
Original Instruction

053-2380

Overview



Chapter Contents

Serial Number Location 2

Intended Use 3

Equipment Modification 3

Unit Components 4


Operator Orientation. 5

About This Manual 5

- Bulleted Lists. 5
- Numbered Lists. 5
- “Continued” Indicators. 5

Serial Number Location

Record serial numbers and date of purchase in spaces provided. Drilling unit serial number is located as shown.



j31om001h.eps

Item	
date of manufacture	
date of purchase	
drilling unit serial number	
trailer serial number	
engine serial number	

Intended Use




The JT5 is a self-contained horizontal directional drilling unit designed to install buried cable and pipe at distances to 150' (45.7 m) depending on soil conditions and is intended for operation in ambient temperatures from 0° to 115°F (-18° to 46°C). Use in any other way is considered contrary to the intended use.

The JT5 can be used with Ditch Witch drilling fluid units and Ditch Witch locating equipment. It should be operated, serviced, and repaired only by persons familiar with its particular characteristics and acquainted with the relevant safety procedures.

Equipment Modification

This equipment was designed and built in accordance with applicable standards and regulations. Modification of equipment could mean that it will no longer meet regulations and may not function properly or in accordance with the operating instructions. Modification of equipment should only be made by competent personnel possessing knowledge of applicable standards, regulations, equipment design functionality/requirements and any required specialized testing.

Unit Components




j31om002h.eps

- | | |
|-----------------------|----------------|
| 1. Anchoring system | 5. Tracks |
| 2. Operator's station | 6. Spindle |
| 3. Carriage | 7. Drill frame |
| 4. Stabilizer | 8. Wrench |

Operator Orientation

IMPORTANT: Top view of unit is shown.

1. Front of unit
2. Right side of unit
3. Rear of unit
4. Left side of unit



j31om003h.eps

About This Manual

This manual contains information for the proper use of this machine. See the beige **Operation Overview** pages for basic operating procedures. Cross references such as "See page 50" will direct you to detailed procedures.

Bulleted Lists

Bulleted lists provide helpful or important information or contain procedures that do not have to be performed in a specific order.

Numbered Lists

Numbered lists contain illustration callouts or list steps that must be performed in order.

"Continued" Indicators



indicates that a procedure is continued on the next page.



Foreword



This manual is an important part of your equipment. It provides safety information and operation instructions to help you use and maintain your Ditch Witch equipment.

Read this manual before using your equipment. Keep it with the equipment at all times for future reference. If you sell your equipment, be sure to give this manual to the new owner.

If you need a replacement copy, contact your Ditch Witch dealer. If you need assistance in locating a dealer, visit our website at **www.ditchwitch.com** or write to the following address:

The Charles Machine Works, Inc.
Attn: Marketing Department
PO Box 66
Perry, OK 73077-0066
USA

The descriptions and specifications in this manual are subject to change without notice. The Charles Machine Works, Inc. reserves the right to improve equipment. Some product improvements may have taken place after this manual was published. For the latest information on Ditch Witch equipment, see your Ditch Witch dealer.

Thank you for buying and using Ditch Witch equipment.

JT5 Operator's Manual

Issue number 1.0/OM- 4/11

Part number 053-2380

Copyright 2011

by The Charles Machine Works, Inc.



, Ditch Witch, CMW, AutoCrowd, Jet Trac, Roto Witch, Subsite, Fluid Miser, Power Pipe, Super Witch, Pierce Airrow, The Underground, The Underground Authority Worldwide, and Zahn are registered trademarks of The Charles Machine Works, Inc.

This product is covered by one or more of the following patents:

U.S. B1 4,858,704; 4,953,638; 5,148,880; 5,242,026; 5,341,887; 5,490,569; 5,684,466; 5,713,423; 5,794,719; 5,880,680; 5,941,322; 6,085,852; 6,109,371; 6,179,065; 6,216,803; 6,250,403; 6,250,404; 6,290,606; 6,311,790; 6,411,094; 6,543,551; 6,550,547; 6,672,409; 6,739,413; 6,761,231; 6,776,246; 6,808,210; 6,827,158; 6,848,506; 6,871,712; RE37,450; RE37,923; RE37,975; RE38,418; **AU** 689,533; 706,544; 718,034; 755,862; **CA** 2,156,398; 2,217,899; **DE** 694 17 019; 695 29 634; 297 01 406; **EP** 0683845; 0674093; 0817901; 0846841; 0927892; **FR** 674,093; **GB** 2,309,239; 2,312,006; EP674,093; EP846,841; **JP** 3,458,247; other U.S. and foreign patents pending.

Contents

	Overview machine serial number, information about the type of work this machine is designed to perform, basic machine components, and how to use this manual	1
	Foreword part number, revision level, and publication date of this manual, and factory contact information	7
	Safety machine safety alerts and emergency procedures	11
	Controls machine controls, gauges, and indicators and how to use them	21
	Operation Overview an overview for completing a job with this machine: planning, setting up, installing product, and restoring the jobsite; with cross references to detailed procedures	43
	Prepare procedures for inspecting and classifying the jobsite, planning the installation path, and preparing the jobsite for work	47
	Drive procedures for startup, cold start, driving, and shutdown	63
	Transport procedures for lifting, hauling, and towing	67
	Conduct a Bore procedures for drilling and backreaming	73
	Systems and Equipment downhole tools and drill pipe, anchor, electric strike, tracker control, and fluid systems	91
	Complete the Job procedures for restoring the jobsite and rinsing and storing equipment	121
	Service service intervals and instructions for this machine including lubrication, replacement of wear items, and basic maintenance	127

	Specifications machine specifications including weights, measurements, power ratings, and fluid capacities	151
	Support the warranty policy for this machine, and procedures for obtaining warranty consideration and training	155
	Service Record a record of major service performed on the machine	159

Safety

Chapter Contents



Guidelines 12

Safety Alert Classifications 13

Safety Alerts 14

Emergency Procedures 17

- Electric Strike Description 17
- If an Electric Line is Damaged 18
- If a Gas Line is Damaged 19
- If a Fiber Optic Cable is Damaged 20
- If Machine Catches on Fire 20

Guidelines

Follow these guidelines before operating any jobsite equipment:

- Complete proper training and read operator's manual before using equipment.
- Contact your local One-Call (811 in USA) or the One-Call referral number (888-258-0808 in USA and Canada) to have underground utilities located before digging. Also contact any utilities that do not participate in the One-Call service.
- Classify jobsite based on its hazards and use correct tools and machinery, safety equipment, and work methods for jobsite.
- Mark jobsite clearly and keep spectators away.
- Wear personal protective equipment.
- Review jobsite hazards, safety and emergency procedures, and individual responsibilities with all personnel before work begins. Safety videos are available from your Ditch Witch dealer.
- Replace missing or damaged safety shields and safety signs.
- Use equipment carefully. Stop operation and investigate anything that does not look or feel right.
- Do not operate unit where flammable gas may be present.
- Contact your Ditch Witch dealer if you have any question about operation, maintenance, or equipment use.

Safety Alert Classifications

These classifications and the icons defined on the following pages work together to alert you to situations which could be harmful to you, jobsite bystanders or your equipment. When you see these words and icons in the book or on the machine, carefully read and follow all instructions. **YOUR SAFETY IS AT STAKE.**



Watch for the three safety alert levels: **DANGER**, **WARNING** and **CAUTION**. Learn what each level means.

 **DANGER** indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.

 **WARNING** indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

 **CAUTION** indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.

Watch for two other words: **NOTICE** and **IMPORTANT**.


NOTICE can keep you from doing something that might damage the machine or someone's property. It can also alert you against unsafe practices.

IMPORTANT can help you do a better job or make your job easier in some way.


Safety Alerts



Turning shaft will kill you or crush arm or leg. Stay away.



Electric shock. Contacting electric lines will cause death or serious injury. Know location of lines and stay away.



Deadly gases. Lack of oxygen or presence of gas will cause sickness or death. Provide ventilation.



Moving tools will kill or injure. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.




Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.




Crushing weight could cause death or serious injury. Use proper procedures and equipment or stay away.




Moving parts could cut off hand or foot. Stay away.




⚠ WARNING Explosion possible. Serious injury or equipment damage could occur. Follow directions carefully.



⚠ WARNING Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.



⚠ WARNING Improper control function could cause death or serious injury. If control does not work as described in instructions, stop machine and have it serviced.



⚠ WARNING Looking into fiber optic cable could result in permanent vision damage. Do not look into ends of fiber optic or unidentified cable.



⚠ WARNING Pressurized fluid or air could pierce skin and cause injury or death. Stay away.



⚠ WARNING Fire or explosion possible. Fumes could ignite and cause burns. No smoking, no flame, no spark.



⚠ WARNING Moving traffic - hazardous situation. Death or serious injury could result. Avoid moving vehicles, wear high visibility clothing, post appropriate warning signs.







⚠ WARNING Hot pressurized cooling system fluid could cause serious burns. Allow to cool before servicing.



⚠ CAUTION Flying objects may cause injury. Wear hard hat and safety glasses.




⚠ CAUTION Hot parts may cause burns. Do not touch until cool.



⚠ CAUTION Exposure to high noise levels may cause hearing loss. Wear hearing protection.



⚠ CAUTION Fall possible. Slips or trips may result in injury. Keep area clean.



⚠ CAUTION Battery acid may cause burns. Avoid contact.



⚠ CAUTION Improper handling or use of chemicals may result in illness, injury, or equipment damage. Follow instructions on labels and in material safety data sheets (MSDS).

Emergency Procedures



⚠ WARNING

Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.



Before operating any equipment, review emergency procedures and check that all safety precautions have been taken.

EMERGENCY SHUTDOWN - Turn ignition switch to stop position or push remote engine stop button (if equipped).

Electric Strike Description



⚠ DANGER

Electric shock. Contacting electric lines will cause death or serious injury. Know location of lines and stay away.

When working near electric cables, remember the following:

- Electricity follows all paths to ground, not just path of least resistance.
- Pipes, hoses, and cables will conduct electricity back to all equipment.
- Low voltage current can injure or kill. Many work-related electrocutions result from contact with less than 440 volts.

Most electric strikes are not noticeable, but indications of a strike include:

- power outage
- smoke
- explosion
- popping noises
- arcing electricity

If any of these occur, or if strike alarm sounds or flashes, assume an electric strike has occurred.

If an Electric Line is Damaged

If you suspect an electric line has been damaged and you are **on drilling unit or bonded equipment**, DO NOT MOVE. Remain on drilling machine or mats and take the following actions. The order and degree of action will depend on the situation.

- Warn people nearby that an electric strike has occurred.
- Have someone contact electric company.
- Reverse drilling direction and try to break contact. Do not touch drill pipe with hands or hand-held tools.
- Press electric strike system status button.
 - If alarm sounds again, stay where you are and wait for electric company to shut off power.
 - If alarm does not sound and there is no other indication of a strike, wait at least one full minute before moving away from equipment. Utility might use automatic reclosers which will restart current flow. If alarm sounds again while waiting, stay where you are until electric company shuts off power.
 - If alarm does not sound but all lights in strike indicator are on, assume strike is continuing and stay where you are until electric company shuts off power.
- Do not resume drilling or allow anyone into area until given permission by electric company.

If you suspect an electric line has been damaged and you are **off drilling unit or bonded equipment**, DO NOT TOUCH ANY EQUIPMENT connected to drilling unit. Take the following actions. The order and degree of action will depend on the situation.

- Stay where you are unless you are wearing electric insulating boots. If you leave, do not return to area or allow anyone into area until given permission by electric company.

If a Gas Line is Damaged



⚠ WARNING Fire or explosion possible. Fumes could ignite and cause burns. No smoking, no flame, no spark.



⚠ WARNING Explosion possible. Serious injury or equipment damage could occur. Follow directions carefully.



If you suspect a gas line has been damaged, take the following actions. The order and degree of action will depend on the situation.

- Immediately shut off engine(s), if this can be done safely and quickly.
- Remove any ignition source(s), if this can be done safely and quickly.
- Warn others that a gas line has been cut and that they should leave the area.
- Leave jobsite as quickly as possible.
- Immediately call your local emergency phone number and utility company.
- If jobsite is along street, stop traffic from driving near jobsite.
- Do not return to jobsite until given permission by emergency personnel and utility company.

If a Fiber Optic Cable is Damaged

Do not look into cut ends of fiber optic or unidentified cable. Vision damage can occur.

If Machine Catches on Fire

Perform emergency shutdown procedure and then take the following actions. The order and degree of action will depend on the situation.

- Immediately move battery disconnect switch (if equipped) to disconnect position.
- If fire is small and fire extinguisher is available, attempt to extinguish fire.
- If fire cannot be extinguished, leave area as quickly as possible and contact emergency personnel.

Controls

Chapter Contents

Set-Up Console 22

Anchor Console 24

Operator's Station 26

- Gauges and Indicators 26
- Controls 29

Engine Compartment 32


ESID 34

750/752 Display 37

- Indicators 37
- Controls 40



Set-up Console







j31om004h.eps

1. Engine stop button

2. Stabilizer and frame tilt control
3. Left track control


4. Right track control

Item	Description	Notes
1. Engine stop button  c00ic062h.eps	To stop engine, press.	IMPORTANT: If this switch is used to stop drilling unit, turn ignition switch off if machine will be left unattended for long periods of time. Battery discharge can occur. If wrenches are engaged when engine stop button is pressed, wrenches will remain engaged but could gradually open.

Item	Description	Notes
2. Stabilizer and frame tilt control  c00ic287h.eps	To raise stabilizer and decrease frame tilt, pull. To lower stabilizer and increase frame tilt, push.	Note: Stabilizer control lowers the front of the drill frame along with the stabilizer.
3. Left track control  c00ic147h.eps	To move forward, push. To move backward, pull. To stop, move to center.	
4. Right track control  c00ic148h.eps	To move forward, push. To move backward, pull. To stop, move to center.	







Anchor Console



j31om005h.eps

- | | |
|--------------------------|---------------------------|
| 1. Left rotation control | 3. Right rotation control |
| 2. Left thrust control | 4. Right thrust control |


Item	Description	Notes
1. Left rotation control 	To drive anchor, push down. To remove anchor, pull up.	IMPORTANT: Stand on platform when operating anchor controls.

Item	Description	Notes
2. Left thrust control  c00ic170h.eps	To move anchor down, push down. To move anchor up, pull up.	IMPORTANT: Stand on platform when operating anchor controls.
3. Right rotation control  c00ic169h.eps	To drive anchor, push down. To remove anchor, pull up.	IMPORTANT: Stand on platform when operating anchor controls.
4. Right thrust control  c00ic170h.eps	To move anchor down, push down. To move anchor up, pull up.	IMPORTANT: Stand on platform when operating anchor controls.



Operator's Station

Gauges and Indicators



j31om006h.eps

1. Hydraulic fluid sight glass





2. Hourmeter

3. Cold start wait (glow plug) indicator
4. Engine oil pressure indicator


5. Engine temperature indicator

6. Drilling fluid pressure gauge


Item	Description	Notes
1. Hydraulic fluid sight glass	Displays level of hydraulic fluid.	Maintain level in center of glass.

Item	Description	Notes
2. Hourmeter  c00ic019h.eps	Displays engine operating time.	Use engine operating times to schedule service.
3. Cold start wait indicator  c00ic099a.eps	Lights when intake air pre-heater (glow plug) is operating. Wait until light goes off before starting engine.	See "Start Unit" on page 64.
4. Engine oil pressure indicator  c00ic096a.eps	Lights when oil pressure is too low. Light will come on briefly when engine is started.	If light remains on: • Stop engine. • Check oil level. • Check for leaks before starting engine. • If pressure is still low, consult engine manual.
5. Engine temperature indicator  c00ic596h.eps	Lights when engine temperature is too high.	If light remains on: • Stop engine and let it cool. • Check fan belt tension. • Check for low engine oil level. • Check cooling fins for dirt and debris.




Item	Description	Notes
6. Drilling fluid pressure gauge  A circular pressure gauge with a black outer ring and a white face. The face is divided into three colored sectors: a green sector on the left (approximately 120 degrees), a yellow sector in the middle (approximately 120 degrees), and a red sector on the right (approximately 120 degrees). A black needle is positioned in the yellow sector. A curved black arrow is drawn along the top of the green sector. At the bottom center of the gauge face, there is a small circular symbol with a horizontal line through it and the text '2702670-1' below it. c00ic597h.eps <tr><td> Displays drilling fluid pressure supplied by drilling fluid pump. • Yellow: low pressure • Green: optimum pressure • Red: high pressure </td><td> If pressure is too high, check if nozzle is plugged. </td></tr>	Displays drilling fluid pressure supplied by drilling fluid pump. • Yellow: low pressure • Green: optimum pressure • Red: high pressure	If pressure is too high, check if nozzle is plugged.
Displays drilling fluid pressure supplied by drilling fluid pump. • Yellow: low pressure • Green: optimum pressure • Red: high pressure	If pressure is too high, check if nozzle is plugged.	





Controls




j31om007h.eps

- | | |
|----------------------------|----------------------------|
| 1. Ignition switch | 5. Wrench control |
| 2. Engine throttle control | 6. Pipe lubricator control |
| 3. Fluid flow control | 7. Auxiliary outlet |
| 4. Carriage control | |


Item	Description	Notes
1. Ignition switch  c00ic065h.eps	To start engine, insert key and turn clockwise. To stop engine, turn key counterclockwise.	

Item	Description	Notes
2. Engine throttle control  c00ic042h.eps	To increase engine speed, push up. To decrease engine speed, pull down.	
3. Fluid flow control  c00ic449h.eps	To increase flow, turn counterclockwise. To decrease flow, turn clockwise. To stop flow, turn all the way clockwise.	
4. Carriage control  c00ic452h.eps	To move carriage forward, push. To move carriage backward, pull. To rotate spindle counterclockwise (breakout), move right. To rotate spindle clockwise (makeup), move left.	
5. Wrench control  c00ic454h.eps	To clamp front wrench and shut off drilling fluid, move toward pipebox. To unclamp front wrench, move away from pipebox. To clamp and rotate rear (rotating) wrench, move toward engine compartment. To unclamp rear (rotating) wrench, move toward seat.	
6. Pipe lubricator control (optional)	To apply joint compound at front wrench, press button.	IMPORTANT: Manually apply joint compound at carriage.

Item	Description	Notes
7. Auxiliary outlet  c00ic448h.eps	Provides power for other equipment.	Power output is 12V, 5A.



Engine Compartment



j31om008h.eps



1.

Air filter service indicator
2.

Tracker control switch
3.


Battery disconnect switch

Item	Description	Notes
1. Air filter service indicator	Indicates when to change air filter. Press button to reset indicator after changing filter.	

Item	Description	Notes
2. Tracker control key  c00ic063h.eps	To allow tracker operator to stop thrust and rotation, move key to enable position (up). To override tracker control mode, move key to disable position (right).	IMPORTANT: Remove key and keep in tracker operator's possession.
1. Battery disconnect switch  ic0251h.eps	To connect, turn clockwise. To disconnect, turn counterclockwise.	





ESID




j07om042h.eps

- | | |
|------------------------------|--------------------------------------|
| 1. Alphanumeric display | 5. Current problem indicator |
| 2. Strike indicator | 6. OK indicator |
| 3. Alarm interrupt button | 7. Electrical power supply indicator |
| 4. Voltage problem indicator | 8. Self test button |

Item	Description	Notes
1. Alphanumeric display	Display amount of current and voltage being detected as a percentage of strike condition. The line with the "V" shows voltage reading and the line with the "A" shows current reading.	


Item	Description	Notes
2. Strike indicator  c00ic077h.eps	Red lights come on as values in display increase. Light in triangle represents strike warning condition and will trigger alarm(s) and strobe(s). Remember that system can go from one or two lights to an electric strike immediately.	NOTICE: The ESID does not indicate proximity to electric lines. System will activate only when voltage and/or amperage detected at the drilling unit are above threshold minimum limits.
3. Alarm interrupt button  c00ic078h.eps	To turn off strike alarm at drilling unit, press.	
4. Voltage problem indicator  c00ic078h.eps	Blinking red light indicates a voltage indicator problem.	See "ESID Diagnostic Codes" on page 97.
5. Current problem indicator  c00ic080h.eps	Blinking red light indicates a current indicator problem.	See "ESID Diagnostic Codes" on page 97.



Item	Description	Notes
6. OK indicator  c00ic056h.eps	Green light means system self test detected no problems. Strike system is ready to operate.	
7. Electrical power supply indicator  c00ic081h.eps	Green light means control box has sufficient electrical power for operation. Strike system is ready to operate if OK indicator is also on.	
8. Self test button  c00ic075h.eps	To start manual self test, press. To reset system after a strike has been detected, press.	Checks all systems and circuits. NOTICE: See "If an Electric Line is Damaged" on page 18.

750/752 Display

Indicators








j07om043h.eps

- | | |
|---|-------------------------------------|
| 1. Beacon temperature display | 5. Depth estimate |
| 2. Pitch/slope indicator and percentage indicator | 6. Display battery status indicator |
| 3. Roll indicator | 7. Beacon battery status indicator |
| 4. Target identifier indicator | 8. Beacon temperature indicator |

IMPORTANT: Some items operate differently depending where data is being saved. **Internal** refers to pipe data being saved to 750/752 Display memory. **External** refers to pipe data being sent to a properly connected laptop computer running a version of Trac Management System software.


Item	Description	Notes
1. Beacon temperature display  c00ic286h.eps	Shows beacon temperature readings in degrees Fahrenheit and degrees Centigrade.	

Item	Description	Notes
2. Pitch/slope indicator and percentage indicator  c00ic083h.eps	Indicates pitch beacon percent of grade.	Internal: shows pipe label and stored pitch. External: shows desired pitch.
3. Roll indicator  c00ic084h.eps	Indicates beacon roll angle.	
4. Target identifier indicator  c00ic085h.eps	Indicates approximate beacon location.	Only one set of arrows is active at a time.
5. Depth estimate  c00ic086h.eps	Indicates beacon depth estimate.	Internal: shows job number and stored depth. External: shows desired depth.

Item	Description	Notes
6. Display battery status indicator  c00ic087h.eps	Indicates display power from drilling unit.	If all five bars are not showing, check display power connections.
7. Beacon battery status indicator  c00ic088h.eps	Indicates beacon battery status.	See beacon instruction sheet.
8. Beacon temperature indicator  c00ic089h.eps	Indicates beacon temperature.	See beacon instruction sheet.




Controls




- | | |
|--------------------------|---------------------|
| 1. Delete button | 4. Roll stop button |
| 2. On/Off button | 5. Recall button |
| 3. Channel select button | 6. Store button |

IMPORTANT: Some items operate differently depending where data is being saved. **Internal** refers to pipe data being saved to 750/752 Display memory. **External** refers to pipe data being sent to a properly connected laptop computer running a version of Trac Management System software.

Item	Description	Notes
1. Delete button  c00ic071h.eps	To delete current pipe, press. Second function: To delete all jobs in internal logging memory, press with Recall button.	Previous pipe number will appear in numeric display when data is deleted.
2. On/Off button  c00ic112h.eps	To turn on, press. To turn off, press again.	

Item	Description	Notes
3. Channel select button  c00ic073h.eps	To display current channel, press and release. To switch channels, press and hold. Second function: To start a new job, press with Recall button. "Init" and job number will be displayed.	Unit defaults to last channel used each time unit is turned on. IMPORTANT: Make sure display and tracker are set to the same channel.
4. Roll stop button  c00ic074h.eps	This feature is not yet available.	
5. Recall button  c00ic075h.eps	To see data about pipe, press and release. Second function: To access second functions, press with other buttons.	Internal: shows data about previous pipe. External: shows data about next pipe.



Item	Description	Notes
6. Store button  c00ic076h.eps	To display serial number, press and hold while pressing on/off button. To store current pipe data, press. Second function: To download all jobs stored in internal logging memory: • Press with Recall button • Connect display to PC running Trac Management System software.	Pipe number will appear in numeric display when data is stored. IMPORTANT: Pipe data cannot be stored without a valid depth estimate.

Operation Overview

Chapter Contents

Planning 44

Setting Up at Jobsite 44

Drilling 45

Backreaming 45

Leaving Jobsite 46

Storing Equipment 46



Planning

1. Gather information about jobsite. See page 49.
2. Inspect jobsite. See page 50.
3. Classify jobsite. See page 52.
4. Plan bore path. See page 55.
5. Check supplies and prepare equipment. See page 61.
6. Load equipment. See page 68.

Setting Up at Jobsite

1. Prepare jobsite. See page 60.
2. Unload drilling unit from trailer. See page 70.
3. Assemble drill string. See page 79.
4. Position drilling unit and frame. See page 75.
5. Assemble strike system. See page 95.
6. Anchor drilling unit. See page 93.
7. Calibrate tracker with beacon that will be installed in beacon housing. See tracker operator's manual.

Drilling

1. Start system. See page 75.
2. Prime drilling fluid pump. See page 76.
3. Engage tracker control if desired. See page 107.
4. Drill first pipe. See page 81.
5. Record bore path. See page 84.
6. Add pipe. See page 82.
7. Drill remaining pipes in pipe box and correct direction (page 80) as necessary.
8. Surface drill head. See page 85.



Backreaming

1. Assemble backream string. See page 86.
2. Start drilling unit and adjust throttle.
3. Set drilling fluid flow. Check that fluid flows through all nozzles. See page 102.
4. Remove pipe from bore. See page 88.
5. Remove pullback device. See page 89.

Backreaming Tips

- Plan backreaming job before drilling. Plan bore path as straight as possible. Check bend limits of pullback material. Check that appropriate pullback devices are on hand.
- Keep all bends as gradual as possible.
- Drilling fluid quality is a key factor in backreaming success. Contact your Ditch Witch dealer for information on testing water, selecting additives, and mixing drilling fluid.
- Backreaming requires more fluid than drilling. Make sure enough fluid is used.

Leaving Jobsite

1. Remove downhole tools. See page 89.
2. Remove anchors. See page 94.
3. Rinse unit and downhole tools. See page 124.
4. Disassemble strike system and disconnect from fluid system. See page 125.
5. Stow tools. See page 125.
6. Load unit onto trailer. See page 68.

Storing Equipment

1. For cold weather storage, antifreeze drilling unit. See page 122.
2. For long-term storage, disconnect battery disconnect switch.

Prepare

Chapter Contents

Gather Information 49

- Review Job Plan 49
- Notify One-Call Services 49
- Examine Pullback Material 49
- Arrange for Traffic Control 49
- Plan for Emergency Services 49

Inspect Site 50

- Identify Hazards 50
- Select Start and End Points 51

Classify Jobsite. 52

- Inspect Jobsite 52
- Select a Classification 52
- Apply Precautions 53

Plan Bore Path 55

- Recommended Bend Limits 56
- Entry Pitch 58
- Minimum Setback 58
- Minimum Depth 59
- Bore Path Calculator 59



Prepare Jobsite 60

- Mark Bore Path 60
- Prepare Entry Point. 60

Check Supplies and Prepare Equipment 61

- Check Supplies 61
- Prepare Equipment 62
- Assemble Accessories 62

Gather Information

A successful job begins before the bore. The first step in planning is reviewing information already available about the job and jobsite.

Review Job Plan

Review blueprints or other plans and make sure you have taken bore enlargement during backreaming and pullback into account. Check for information about existing or planned structures, elevations, or proposed work that may be taking place at the same time.

Notify One-Call Services

Contact your local One-Call (811 in USA) or the One-Call referral number (888-258-0808 in USA and Canada) to have underground utilities located before digging. Also contact any utilities that do not participate in the One-Call service.

Examine Pullback Material

Ask for a sample of the material you will be pulling back. Check its weight and stiffness. Contact the manufacturer for bend radius information. Check that you have appropriate pullback devices.

Arrange for Traffic Control

If working near a road or other traffic area, contact local authorities about safety procedures and regulations.

Plan for Emergency Services

Have the telephone numbers for local emergency and medical facilities on hand. Check that you will have access to a telephone.



Inspect Site

Inspect jobsite before transporting equipment. Check for the following:

- overall grade or slope
- changes in elevation such as hills or open trenches
- obstacles such as buildings, railroad crossings, or streams
- signs of utilities (See "Inspect Jobsite" on page 52.)
- traffic
- access
- soil type and condition
- water supply
- sources of locator interference (rebar, railroad tracks, etc.)

Take soil samples from several locations along bore path to determine best bit and backreamer combinations.

Identify Hazards

Identify safety hazards and classify jobsite. See "Classify Jobsite" on page 52.

**⚠ WARNING**

Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.

NOTICE:

- Wear personal protective equipment including hard hat, safety eye wear, and hearing protection.
- Do not wear jewelry or loose clothing.
- Notify One-Call and companies which do not subscribe to One-Call.
- Comply with all utility notification regulations before digging or drilling.
- Verify location of previously marked underground hazards.
- Mark jobsite clearly and keep spectators away.

Remember, jobsite is classified by hazards in place -- not by line being installed.

Select Start and End Points

Select one end to use as a starting point. Consider the following when selecting a starting point:

Slope

Fluid system should be parked on a level site. Consider how slope will affect drilling unit setup, bending pipe, and fluid flow out of hole.

Traffic

Vehicle and pedestrian traffic must be a safe distance from drilling equipment. Allow at least 10' (3 m) buffer zone around equipment.

Space

Check that starting and ending points allow enough space for gradual pipe bending. See "Minimum Setback" on page 58.

Check that there is enough space to work and to set up electric strike system.

Comfort

Consider shade, wind, fumes, and other site features.

Drill downhill when possible so fluid will flow away from drilling unit.



Classify Jobsite

Inspect Jobsite

- Follow U.S. Department of Labor regulations on excavating and trenching (Part 1926, Subpart P) and other similar regulations.
- Contact your local One-Call (811 in USA) or the One-Call referral number (888-258-0808 in USA and Canada) to have underground utilities located before digging. Also contact any utilities that do not participate in the One-Call service.
- Inspect jobsite and perimeter for evidence of underground hazards, such as:
 - “buried utility” notices
 - utility facilities without overhead lines
 - gas or water meters
 - junction boxes
 - drop boxes
 - light poles
 - manhole covers
 - sunken ground
- Have an experienced locating equipment operator sweep area within 20' (6 m) to each side of bore path. Verify previously marked line and cable locations.
- Mark location of all buried utilities and obstructions.
- Classify jobsite.

Select a Classification

Jobsites are classified according to underground hazards present.

If working . . .	then classify jobsite as . . .
within 10' (3 m) of a buried electric line	electric
within 10' (3 m) of a natural gas line	natural gas
in concrete, sand or granite which is capable of producing crystalline silica (quartz) dust	crystalline silica (quartz) dust
within 10' (3 m) of any other hazard	other

NOTICE: If you have any doubt about jobsite classification, or if jobsite might contain unmarked hazards, take steps outlined previously to identify hazards and classify jobsite before working.

Apply Precautions

Once classified, precautions appropriate for jobsite must be taken.

Electric Jobsite Precautions



⚠ DANGER Electric shock. Contacting electric lines will cause death or serious injury. Know location of lines and stay away.

In addition to using a directional drilling system with an electric strike system, use one or both of these methods.

- Expose line by careful hand digging or soft excavation. Use beacon to track bore path.
- Have service shut down while work is in progress. Have electric company test lines before returning them to service.



Natural Gas Jobsite Precautions



⚠ WARNING Fire or explosion possible. Fumes could ignite and cause burns. No smoking, no flame, no spark.



⚠ WARNING Explosion possible. Serious injury or equipment damage could occur. Follow directions carefully.

In addition to using a directional drilling system and positioning equipment upwind from gas lines, use one or both of these methods.

- Expose lines by careful hand digging or soft excavation. Use beacon to track bore path. Have someone observe clearance between drill head and backreamer when crossing a line.
- Have gas shut off while work is in progress. Have gas company test lines before returning them to service.

Crystalline Silica (Quartz) Dust Precautions



⚠ WARNING Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.

NOTICE: Cutting, drilling, or working materials such as concrete, sand, or rock containing quartz may result in exposure to silica dust. Use water spray or other means to control dust. If workers are exposed to dust they must wear appropriate breathing protection. Silica dust may cause lung disease and is known to the State of California to cause cancer.

Follow OSHA or other guidelines for exposure to crystalline silica when trenching, sawing or drilling through material that might produce dust containing crystalline silica (quartz).

Other Jobsite Precautions

You may need to use different methods to safely avoid other underground hazards. Talk with those knowledgeable about hazards present at each site to determine which precautions should be taken or if job should be attempted.

Plan Bore Path

Plan the bore path, from entry to end, before drilling begins. The Ditch Witch **Trac Management System Plus** is available for planning your bore path. This special software can be run in the field using a laptop computer equipped with Windows® 95 or higher operating system. See your Ditch Witch dealer for details.

If not using Trac Management System Plus, mark the bore path on the ground with spray paint or flags, or record it on paper for operator reference.

For complicated bores, consult an engineer. Have the jobsite surveyed and bore path calculated. Be sure the engineer knows minimum entry pitch, bend limits of drill pipe, bend and tension limits of pullback material, pipe lengths, and location of all underground utilities.

For less complicated bores, plan the bore based on four measurements:

- recommended bend limit
- entry pitch
- minimum setback
- minimum depth



IMPORTANT: See the following pages for more information about these measurements. If not using Trac Management System Plus, see “Bore Path Calculator” on page 59 and use these measurements to help plan your bore.

Recommended Bend Limits

Ditch Witch drill pipes are designed to bend slightly during operation. Slight bending allows for steering and correcting direction. Bending beyond recommended limits will cause damage that might not be visible. This damage adds up and will later lead to sudden drill pipe failure.


IMPORTANT: Consider recommended bend limits during any bend, not just during bore entry.

Pipe Pitch

Ditch Witch drill pipe is tested to bend at a maximum percent pitch. For JT5 drill pipe, make sure pitch (A) changes no more than **7%** over the full length of each pipe.

NOTICE: Bending drill pipe more sharply than recommended will damage pipe and cause failure over time. Changes in pitch must be **equally distributed** over the length of a pipe. Maximum changes in pitch within 1-2' (300-600 mm) of pipe create sharp bends that will damage pipe.

Monitor the pitch of each pipe with the 750/752 Display on the operator's console. See page 49.



j07om003c.eps


Bend Radius

JT5 drill pipes have a tested minimum bend radius of 70' (21.3 m). This means that a 90-degree bend in the bore path:

- has a radius (A) of 70' (21.3 m)
- requires approximately 110' (33.5 m) of drill pipe (B).

NOTICE: Bending drill pipe more sharply than recommended will damage the pipe and cause failure over time.

- If bend radius is reduced, drill pipe life is reduced.
- If bend radius is increased, drill pipe life is increased.




j07om078h.eps

IMPORTANT: Use the charts on the next page to keep bends within safe limits.

Pipe-By-Pipe Bend Limits

Pipe (C)	Forward (B)	Deflection (A)	Pipe (C)	Forward (B)	Deflection (A)
1	4' 11" (1.5 m)	0' 2" (.05 m)	13	55' 5" (16.9 m)	27' 3" (8.3 m)
2	9' 10" (3.0 m)	0' 8" (.2 m)	14	58' 4" (17.8 m)	31' 3" (9.5 m)
3	14' 8" (4.5 m)	1' 7" (.5 m)	15	60' 11" (18.6 m)	35' 5" (10.8 m)
4	19' 5" (5.9 m)	2' 9" (.8 m)	16	63' 2" (19.3 m)	39' 8" (12.1 m)
5	24' 1" (7.4 m)	4' 3" (1.3 m)	17	65' 1" (19.9 m)	44' 4" (13.5 m)
6	28' 8" (8.7 m)	6' 2" (1.9 m)	18	66' 9" (20.4 m)	48' 11" (14.9 m)
7	33' 1" (10.1 m)	8' 4" (2.5 m)	19	68' 1" (20.8 m)	53' 8" (16.4 m)
8	37' 4" (11.4 m)	10' 9" (3.3 m)	20	69' 1" (21.1 m)	58' 6" (17.8 m)
9	41' 5" (12.6 m)	13' 7" (4.1 m)	21	69' 8" (21.2 m)	63' 4" (19.3 m)
10	45' 3" (13.8 m)	16' 7" (5.1 m)	22	69' 11" (21.3 m)	68' 4" (20.8 m)
11	48' 11" (14.9 m)	19' 11" (6.1 m)	23	70' 0" (21.4 m)	70' 0" (21.3 m)
12	52' 4" (15.9 m)	23' 6" (7.2 m)			



j25om038h.eps

Pipe 13 is illustrated.

Entry Pitch


Entry pitch is the slope of the drill frame compared with the slope of the ground. Determine entry pitch one of two ways:

1. With Pitch Beacon

- Lay pitch beacon on the ground and read pitch.
- Lay pitch beacon on drill frame and read pitch.
- Subtract ground pitch from drilling unit pitch.


2. With Measurements

- Measure from the ground to front end of drill frame (H1).
- Measure from the ground to back end of frame (H2).
- Subtract (H1) from (H2). Record this number.
- Measure the distance between front and back points (C).
- Divide (H2-H1) by (C), then multiply by 100. This is your pitch.



j07om006c.eps

IMPORTANT: A shallow entry pitch (A1) allows you to reach horizontal sooner and with less bending. Increasing entry pitch (A2) makes bore path longer and deeper.




j07om007c.eps

Minimum Setback

Setback is the distance from the entry point to where pipe becomes horizontal (B1).


NOTICE: If setback is too small (B2), you will exceed bend limits and damage the pipe.



j07om008c.eps

Minimum Depth

Because you must bend pipe gradually, entry pitch and bend limits determine how deep the pipe will be when it becomes horizontal. This is called the **minimum depth**.




j07om009c.eps

- To reduce minimum depth (D1), reduce entry pitch. This also decreases setback.
- To increase minimum depth (D2), increase entry pitch. This also increases setback.

Bore Path Calculator

Entry pitch, setback, and minimum depth work together with bend limits to determine the bore path. To find the setback (B) and entry pitch (A) that will take you to the desired minimum depth (D), use the chart below.



j07om010c.eps

Minimum depth (D)	Entry pitch (A)	Setback (B)	Depth to begin steering (S)
2' 0" (0.6 m)	-18%	17' 4" (5.3 m)	0' 11" (0.28 m)
2' 4" (0.7 m)	-20%	18' 8" (5.7 m)	1' 0" (0.30 m)
2' 9" (0.8 m)	-22%	19' 11" (6.1 m)	1' 1" (0.33 m)
3' 1" (0.9 m)	-24%	21' 2" (6.5 m)	1' 2" (0.36 m)
3' 6" (1.1 m)	-26	22' 5" (6.8 m)	1' 3" (0.38 m)
3' 11" (1.2 m)	-28	23' 8" (7.2 m)	1' 4" (0.41 m)
4' 5" (1.4 m)	-30	24' 11" (7.6 m)	1' 5" (0.43 m)

IMPORTANT: Numbers in table based on **70' (21.3 m) minimum bend radius**, beacon housing, EZ-Connect, connector, transition sub, and 1/3 of first drill pipe (L, totaling 5' [1.5 m]) in the ground before steering.

Prepare Jobsite

**⚠ WARNING**

Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.

NOTICE:

- If jobsite classification is in question or if the possibility of unmarked electric utilities exists, classify jobsite as electric.
- Cutting high voltage cable can cause electrocution. Expose lines by hand before digging.
- All vegetation near operator's station must be removed. Contact with trees, shrubs, or weeds during electrical strike could result in electrocution.

Mark Bore Path


Mark your planned bore path and all located utility lines with flags or paint.

Prepare Entry Point

For bore to be successful, first pipe must be straight as it enters the ground.

To help ensure that the first pipe does not bend, dig a small starting hole so that the first pipe is drilled into a vertical surface.

To prevent bending or straining pipe, position drilling unit for straight entry.



j07om011c.eps

Check Supplies and Prepare Equipment

Check Supplies

- receiver/transmitter or tracker with spare batteries
- beacons with new and spare batteries
- two-way radios with new and spare batteries
- quick wrench (see page 115)
- transition sub
- anchoring equipment and accessories
- bits, screens, nozzles (see page 110)
- adapters, pipe, beacon housings
- marking flags or paint
- water and additional hoses
- fuel (Use low sulfur or ultra low sulfur fuel only.)
- drilling fluid additives (see page 102)
- spare fuses
- keys
- backreamers, swivels, pulling devices (see page 110)
- wash down hose and spray gun
- duct tape
- spray lubricant
- tool joint compound (see page 130)
- electrically insulating boots and gloves
- personal protective equipment, such as hard hat and safety glasses
- notepad and pencil



Prepare Equipment

Fluid Levels

- fuel (Use low sulfur or ultra low sulfur fuel only.)
- hydraulic fluid
- engine coolant
- battery charge
- engine oil

Condition and Function

- filters (air, oil, hydraulic)
- fluid pump
- couplers
- tires and tracks
- pumps and motors
- drilling fluid mixer
- hoses and valves
- water tanks

Assemble Accessories

Fire Extinguisher

If required, mount a fire extinguisher near the power unit but away from possible points of ignition. The fire extinguisher should always be classified for both oil and electric fires. It should meet legal and regulatory requirements.

Drive

Chapter Contents

Start Unit 64
Steer Unit 64
Shut Down Unit 65



Start Unit

1. Insert key.
2. Turn key clockwise. When the ambient temperature is below 32°F (0°C), use the cold start procedure to activate glow plugs.
 - Turn key to ON position. Glow plugs will activate.
 - Wait for cold start wait indicator to turn off. (See page 26.)
 - Turn key to START position.
3. Run engine at low throttle for 5 minutes.

Steer Unit

To steer drilling unit, follow instructions for type of steering desired. See page 22 for more information.

To steer while moving forward, move one control slightly more than the other to turn in the desired direction. Drilling unit will gradually turn to left or right.

To steer while moving backward, move one control slightly more than the other to turn in the desired direction. Drilling unit will gradually turn to left or right.

For tight steering at low speed, one control to reverse and one control to forward to turn in the desired direction. Tracks will counter-rotate and turn drilling unit in a tight circle.

Tips to Reduce Track Wear

Rubber tracks are best suited for soil-based job sites with minimal rock and debris. Sharp objects such as gravel, steel shards, and broken concrete will damage rubber tracks and undercarriage components. Excessive operation on concrete or asphalt will shorten track life. When storing your machine, keep tracks away from rain and direct sunlight.

Wash tracks daily to remove foreign objects and abrasive soil from sprockets and idler rollers. Drive slowly and make wide turns when possible. Regularly check undercarriage components (sprocket, rollers, idler) for wear and damage. Maintain proper track tension. (See "Check Track Tension and Condition" on page 148.)

To prevent premature wear, avoid the following:

- Spinning tracks under heavy load.
- Turning on sharp objects such as stones, stumps and debris.
- Quick turns or "spin" turns on asphalt or concrete.
- Driving over curbs, ledges, and sharp objects.
- Driving with sidewall edges pressed against hard walls, curbs or other objects.
- Driving on slopes.
- Operating on corrosive materials such as salt or fertilizer. Wash immediately.

Shut Down Unit

1. Stop track movement.
2. Lower drill frame and stabilizer to the ground.

IMPORTANT: If frame and stabilizer cannot be lowered, use cylinder locks or other suitable material to block the tracks. Remove cylinder locks or chocks before driving unit.

3. Run engine at low throttle for 3 minutes to cool.
4. Turn key to STOP.
5. Remove key.



Transport

Chapter Contents

Lift 68

Haul 68

• Load 68

• Tie Down 69

• Unload 70

Tow 71



Lift

This machine is not configured for lifting. If the machine must be lifted, load machine into a container or onto a platform appropriate for lifting. See "Specifications" on page 151 for weight of machine.

Haul

Load



WARNING Crushing weight. If load falls or moves it could kill or crush you. Use proper procedures and equipment or stay away.

NOTICE:


- Load and unload trailer on level ground.
- Verify that trailer wheels are blocked.
- Incorrect loading can cause trailer swaying.
- Attach trailer to vehicle before loading or unloading.
- Ten to fifteen percent of total vehicle weight (equipment plus trailer) must be on tongue to help prevent trailer sway.

1. Start drilling unit engine.
2. Move drilling unit to rear of trailer and align with ramps.
3. Slow engine to low throttle and slowly drive unit onto trailer.
4. Lower drill frame and stabilizer to trailer floor. Keep tracks fully on trailer floor.
5. Stop engine when unit is safely positioned on trailer bed.
6. Attach tiedowns to drilling unit where indicated on page 69.

Tie Down


Points

Tiedown points are identified by tiedown decals. Securing to trailer at other points is unsafe and can damage machinery.



lc1320a.eps

Procedure




WARNING

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

Do not use tiedown points for towing or lifting.

Loop tiedowns around rear tiedown points. Use D-rings or pin to trailer using hole in anchor plate. Make sure tiedowns are tight before transporting.



j31om039h.eps



Unload



WARNING Crushing weight. If load falls or moves it could kill or crush you. Use proper procedures and equipment or stay away.

NOTICE:

- Load and unload trailer on level ground.
- Ensure trailer wheels are blocked.
- Attach trailer to vehicle before loading or unloading.

1. Lower ramps.
2. Remove tiedowns.
3. Start drilling unit engine.
4. Raise stabilizer and drill frame.
5. Slow engine to low throttle and slowly back unit down trailer or ramps.

Tow

Under normal conditions, drilling unit should not be towed. If unit breaks down and towing is necessary:

- Attach chains to indicated tow points facing towing vehicle.
- Disengage track hydraulics.
- Tow for short distances at less than 1 mph (1.6 km/h).
- Use maximum towing force of 1.5 times unit weight.

To disengage track hydraulics:


1. Loosen locknut (2).
2. Turn screw (1) on each counterbalance valve clockwise until it stops.

IMPORTANT: Be sure to count number of turns.

3. Repeat on other track.

To engage track hydraulics:

1. Turn screw (1) on counterbalance valve exactly the same number of turns counterclockwise.
2. Tighten locknut (2).
3. Repeat on other track.






WARNING

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

Do not use tiedown points (D-rings) for towing or lifting.



j31om049h.eps

Loop chain through tow points on left and right side of unit (shown) and pull straight forward.

Conduct a Bore



Chapter Contents

Position Equipment 75

Connect Fluid System 75

Start System 75

Prime Drilling Fluid Pump 76

Operate Carriage Control 77

Assemble Drill String 79

- Prepare Beacon Housing 79
- Attach EZ-Connect to Drill Head 79
- Attach Transition Sub 80
- Connect Drill Pipe 80
- Engage EZ-Connect

Drill First Pipe 81

Add Pipe 82

Correct Direction 83

- Basic Rules 83
- Procedure 83
- Drill Head Position 84

Record Bore Path	84
Surface Drill Head	85
Assemble Backream String	86
Remove Pipe	88
Remove Pullback Device	89

Position Equipment

1. Review bore plan and select drilling unit position and fluid unit position. See "Select Start and End Points" on page 47.
2. Move equipment into selected positions.



Connect Fluid System




⚠ DANGER

Electric shock. Contacting electric lines will cause death or serious injury. Know location of lines and stay away.

NOTICE: If an electrical strike occurs while drilling unit is connected to a fluid system, the fluid system will also become electrified. Do not connect drilling unit to a public or private (business or home) water supply.

1. Connect fluid hose from mixing system to drilling fluid pump. A 1.5" (38 mm) or larger, non-collapsible hose is required.
2. Install y-strainer between mixing unit and drilling fluid pump. Position strainer so that drilling fluid flows in the direction of the arrow. In most cases, positioning strainer at outlet of mixing unit gives best results.

IMPORTANT: Clean y-strainer regularly.



Y_Strainer.eps

Start System

1. Start drilling unit and remote fluid unit. Allow both engines to warm up.

IMPORTANT: Ensure that mixture of drilling fluid matches drilling conditions.


2. Enable tracker control mode. See "Tracker Control" on page 107.
3. Move drilling unit throttle control until engine is at full throttle.
4. Move fluid control to desired setting to fill pipe with fluid.

Prime Drilling Fluid Pump

**⚠ WARNING**

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

NOTICE: Failure to prime the drilling fluid pump will cause flow fluctuations, which will make it difficult to control the washwand.

**⚠ WARNING**


Pressurized fluid or air could pierce skin and cause injury or death. Stay away.

Prime drilling fluid pump each time tank is changed. To prime the pump:

1. Fill drilling fluid hose and connect hose to unit.
2. Operate mixing/transfer pump at full speed for 1 - 3 minutes to discharge air from system.
3. Return mixing/transfer pump to normal operating speed and continue the bore.
4. If drilling fluid pressure surges are observed, repeat step 2.

Operate Carriage Control

The thrust/rotation control has eight positions which allow the four basic functions to be combined. The chart below summarizes functions that occur when control is put at a combined position. Operator must be in seat for control to function.



c00ic452h.eps




Carriage Movement	Rotation Direction	
forward	clockwise (makeup)	 ic1102a.eps
reverse	counterclockwise (breakout)	 ic1104a.eps

Clamp Pipe

**⚠ DANGER**

Turning shaft can kill you or crush arm or leg. Stay away.


NOTICE: Clamping anywhere else on the pipe will weaken the pipe. Pipe can later break, even when operating under normal loads.

**⚠ WARNING**

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

NOTICE: Wrenches can open after engine shutdown. Ensure that any downhole tool or pipe in tool joint vises is attached to spindle or removed before transport.

Clamp on pipe when joint is centered between wrenches (1 and 2). Always clamp on the larger diameter areas on either side of the tool joint face.



j07om043c.eps

Assemble Drill String




⚠ DANGER Moving tools will kill or injure. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.

Prepare Beacon Housing

1. Select nozzles and bit.

IMPORTANT: A variety of nozzles and bits are available to suit your particular job conditions. See “Downhole Tools” on page 110 for more information, or contact your Ditch Witch dealer.

2. Insert nozzle (2) into beacon housing.
3. Attach bit (3) to beacon housing (1).
4. Install beacon, following beacon instructions for:
 - battery replacement
 - beacon positioning
5. Install beacon housing lid. See “Beacon Housings” on page 111.
6. Follow beacon instructions to check beacon operation.
7. Follow tracker instructions to calibrate beacon.



j310m047h.eps


Attach EZ-Connect to Drill Head

1. Apply tool joint compound to shoulders and threads and hand tighten EZ-Connect adapter (4) to beacon housing (1).
2. Use quick wrench to fully tighten joint.

Attach Transition Sub

Use either machine torque or quick wrench to attach transition sub.

- Attach transition sub (6) directly to beacon housing (1), **or**
- Attach transition sub (5) to EZ-Connect adaptor (4).



j31om046h.eps

Machine Torque

1. Apply tool joint compound to shoulders and threads and thread transition sub onto saver sub.
2. Align drill pipe flats of EZ-Connect box or beacon housing with front wrench of drill frame.
3. Start drilling unit engine.
4. Use machine power to slowly rotate spindle and transition sub onto EZ-Connect box or beacon housing.
5. Tighten to full machine torque.

Quick Wrench

1. Lube joints with TJC.
2. Attach quick wrench to the joint in the join position and tighten joint. See "Quick Wrench" on page 115.

Connect Drill Pipe

1. Start drilling unit engine.
2. Align transition sub in front wrench.
3. Load pipe into wrench cradle.
4. Lubricate shoulders and threads.
5. Remove hands from pipe area.
6. Move carriage forward until saver sub nears male pipe thread.
7. Slowly rotate spindle clockwise. Carriage will move forward as threads screw together.
8. Slowly move carriage forward until pipe end touches end of transition sub.
9. To thread pipes together and fully torque joint, slowly rotate drill pipe until spindle stops turning.
10. Open front wrench and move carriage back.

Drill First Pipe



⚠ DANGER

Turning shaft can kill you or crush arm or leg. Stay away.

NOTICE:

- Keep everyone at least 10' (3 m) away from turning drill string.
- Push rod or pipe slowly. Forcing can bend string. Do not use bent rod or pipe.



⚠ WARNING

Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.

1. Turn on drilling fluid.
2. Visually check for drilling fluid flow.
3. Turn drill bit to starting position. See "Prepare Entry Point" on page 60.
4. Slowly move carriage forward. See "Prepare Entry Point" on page 60. Take care to steer to drill straight in line with drilling unit. Drill in downhole tools and 1/3 of first pipe before steering.
5. Monitor gauges.

Add Pipe

1. Set engine throttle to full speed.
2. Clamp pipe joint. See "Clamp Pipe" on page 78.
3. Locate drill head.
4. Engage front wrench until pipe is clamped and pressure develops.
5. Slowly rotate spindle counterclockwise. Move carriage back as threads unscrew.
6. After threads are fully unscrewed, stop rotation and move carriage to back of frame, slowing down as carriage approaches rear end.
7. Connect Pipe. See "Connect Drill Pipe" on page 80.
8. Ensure that pipe fills and fluid pressure begins to rise.
9. Rotate spindle.
10. Slowly move carriage forward. Adjust rotation speed control according to bit size and soil conditions.
11. Monitor gauges.
12. Locate drill head with tracker at least every half-length of pipe.

Correct Direction



Correcting direction is a skill operators gain with experience and knowledge of equipment and soil conditions. These instructions cover only basic procedures. For information about specific equipment or jobsites, contact your Ditch Witch dealer.

To track progress and make corrections, one crew member locates the drill head and sends instructions to the operator. Corrections are made by tracking the drill head, comparing current position to bore plan, and steering drill head as needed.

Basic Rules

- Steering ability depends on soil condition; bit, drill head, and nozzle used; roll of drill head; and distance pushed without outer rotation.
- All corrections should be made as gradually as possible. See "Recommended Bend Limits" on page 56.
- Over correcting will cause "snaking." This can damage pipe and will make drilling and pullback more difficult. Begin to straighten out of each correction as early as possible.
- Do not push an entire piece of drill pipe into ground without rotation. This can exceed bend radius and cause pipe failure.


Procedure

1. When drilling has stopped/paused, locate drill head. Take readings available with your beacon and locating equipment such as:
 - depth
 - pitch
 - left/right information
 - temperature
 - beacon roll
2. Compare position to bore plan. Determine direction drilling should go.
3. Position drill head.
4. Push in drill pipe as needed to change direction.
5. Rotate in remaining length of drill pipe.

Drill Head Position

The drill head position is determined by reading beacon roll. Roll is displayed as a clock face position.

1. Read beacon roll.
2. Slowly rotate pipe until locator displays desired beacon roll.



j07om048c.eps

To change direction:

1. Rotate pipe to clock position you intend to travel.
2. Push pipe into ground.

To move forward without changing direction:

Rotate pipe into ground.

Record Bore Path

Locate drill head every length of pipe. As the job is completed, record the actual data for each drill pipe. List pitch and depth of each joint and a brief description of the procedure. In addition, draw a simple sketch of the site and record depth and rough location of pullback.

The Trac Management System Plus is also available for plotting and tracking your bore path. It utilizes the 750/752 Tracker, 750/752 Display, a tracking beacon, and special software. The display can store jobs in its memory or the system can be run in the field using a laptop computer equipped with the Windows® 95 or higher operating system. See your Ditch Witch dealer for details.

Surface Drill Head



⚠ DANGER

Moving tools will injure or kill. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.



⚠ DANGER

Turning shaft will kill you or crush arm or leg. Stay away.

NOTICE:

- Tracker operator and drill operator should maintain two-way communication.
- Keep everyone clear of the exposed drill string.
- No one should enter pit until clear communication is given by the drill operator that the drill unit is shut down. Do not enter pit until tracker control is turned off and green light on drill unit is lit.
- Drill operator should be instructed to discontinue drill string rotation as soon as drill bit exits the bore. Use thrust only to extend drill string beyond exit hole.

1. Guide drill head to target pit or up through surface. Make all bends gradual. See "Recommended Bend Limits" on page 56.
2. Clean area around exit point.
3. Turn fluid flow control to off position as soon as drill head emerges.
4. Allow tracker operator to turn off tracker to disable drilling unit thrust/pullback and rotation hydraulics. Tracker operator waits for green light to enter pit and change tools.
5. Clean drill head especially around threads.
6. Disconnect EZ-Connect joint or use quick wrench to remove drill head. Keep threads clean. See "Quick Wrench" on page 115.

Assemble Backream String

Sometimes it is necessary to enlarge the pilot hole to accommodate larger product. As a general rule, the final hole should be 1.5 times larger than the diameter of the product being installed. The number of passes needed depends on soil conditions. Do not try to increase hole size too much in one pass. Several passes using successively larger reamers will save wear on machine.

**⚠ DANGER**

Moving tools will kill or injure. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.

**⚠ WARNING**

Jobsite hazards could cause death or serious injury. Use correct equipment and work methods. Use and maintain proper safety equipment.

NOTICE: Continue to use strike system during backreaming.

**⚠ DANGER**

Turning shaft will kill you or crush arm or leg. Stay away.

NOTICE:

- Maintain two-way communication with tracker operator.
- Begin backream only when tracker operator has communicated that everyone is clear of the exposed backream string or has disabled thrust and rotation hydraulics using tracker control.
- Do not allow anyone to stand to the side of the exposed drill string. Drill string and backreamer can move sideways suddenly if rotated while away from the exit hole.



1. Select backreaming devices. See "Backreamers" on page 112.
2. Determine fluid rate requirements and install appropriate nozzles to provide sufficient flow. See "Backream Fluid Requirements" on page 113 and "Nozzles" on page 110.
3. Attach backreamer to backream beacon housing if tracking backream.
4. Install beacon, following beacon instructions for:
 - battery replacement
 - beacon positioning
5. Install beacon housing lid. See "Beacon Housings" on page 111.
6. Follow beacon instructions to check beacon operation.
7. Follow tracker instructions to calibrate beacon.
8. Connect EZ-Connect joint or use quick wrench to attach backreamer/beacon housing assembly to transition sub. See "Quick Wrench" on page 115.
9. Attach pullback devices or product to end of backreamer/beacon housing assembly.



Remove Pipe

NOTICE: If engine is shut off during backreaming, drill pipe clamped by wrenches but not connected to saver sub can be pulled downhole as vise wrenches loosen.

1. Stop carriage when pipes are aligned in wrenches.
2. Clamp pipe in front wrench. See page 78.
3. Clamp and rotate rear wrench to break front joint. See "Wrench control" on page 25.
4. Disengage rear wrench.
5. Unscrew front joint.
 - Slowly rotate spindle counterclockwise to unscrew pipe. Move carriage back slowly until threads unscrew.
 - Move carriage back until pipe is properly positioned in rear wrench.
6. Break rear joint.
 - Engage rear wrench.
 - Slowly rotate spindle counterclockwise until joint is loosened. **Do not** fully unscrew joint.
 - Disengage rear wrench.
 - Move carriage back and grip pipe with both hands.
 - Pull pin end of pipe clear of saver sub, lift pipe and stow it in box.
7. Lube front threads.
8. Attach saver sub to next pipe.
 - Move carriage forward until saver sub touches pipe.
 - Rotate spindle to screw onto pipe. Slowly tighten joint to full machine torque.
9. Disengage front wrench to release pipe.

Remove Pullback Device

The pullback device can be removed when the last pipe is on the frame. It can also be removed when a target pit along the bore path has been reached. Remaining pipe is then pulled back and removed.



⚠ DANGER

Moving tools will injure or kill. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.

1. Turn off drilling fluid.
2. Move drilling unit throttle control until engine is at low throttle.
3. Turn drilling unit engine off.
4. Use tracker control to verify that unit is turned off.
5. Clean pullback device.
6. Use quick wrench to remove pullback device. See "Quick Wrench" on page 115.

Systems and Equipment

Chapter Contents



Anchor System 93

- Drive Anchor 94
- Remove Anchor 94

Electric Strike System 95

- FCC Statement 95
- Assemble Voltage Detector 96
- Test Strike System 96
- Troubleshoot Strike System 97
- Use Electric Strike Simulator 100

Drilling Fluid 102

- Guidelines 102
- Polymer 102
- Bentonite 103
- Mixtures 103
- Basic Fluid Recipes 104
- Drilling Fluid Requirements 105
- Funnel Viscosity 106

Tracker Control 107

- Overview 107
- Operation 107

Downhole Tools 110

- Nozzles 110
- Bits 110
- Beacon Housings 111
- Backreamers 112
- Backream Fluid Requirements 113

Quick Wrench 115

Drill Pipe 117

- Perform Regular Drill Pipe Care 117
- Use Drill Pipe Correctly 119

Anchor System



⚠ WARNING

Crushing weight. If load falls or moves, it could kill or crush you. Use proper procedures and equipment or stay away.



NOTICE:

- Stand on operator platform.
- Drive anchor properly before drilling.
- Wear high-top protective boots with legs of pants completely tucked inside.
- Wear protective gloves.
- If you are not driving anchor to full depth, drive optional ground rod into soil away from drilling unit and connect ground rod to drilling unit.



⚠ DANGER

Turning shaft can kill you or crush arm or leg. Stay away.


Drive Anchors

IMPORTANT: Carefully time anchor rotation with anchor movement. Properly driven anchors should thread into soil and should not auger up soil.

1. Use anchor rotation and thrust controls to drive anchor into ground.
2. Anchor is set when cap top plate (1) rests firmly on centering tube (2).
3. Repeat process for other anchor.

Remove Anchors

1. Use anchor rotation and thrust controls to slowly remove anchor shaft from ground.
2. Repeat process for other anchor.



j31om048h.eps

Electric Strike System

Any time you drill in an electric jobsite, electric strike system must be properly set up, tested, and used. You must wear protective boots and gloves meeting the following standards:

- Boots must have high tops and meet the electric hazard protection requirements of ASTM F2413 when tested at 14,000 volts. Tuck legs of pants completely inside boots.
- Gloves must have 17,000 AC maximum use voltage, according to ASTM specification D120-87.



If working around higher voltage, use gloves and boots with appropriately higher ratings.

NOTICE: The strike system does not prevent electric strikes or detect strikes before they occur. **If alarms are activated, a strike has already occurred** and equipment is electrified.

Read and follow “Electric Jobsite Precautions” on page 53. Review safety procedures before each job.


FCC Statement

The Electric Strike System has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, can cause harmful interference to radio communications. Operation of this equipment in a residential area could cause harmful interference which the user will be required to correct at his own expense.

Changes or modifications not expressly approved in writing by The Charles Machine Works, Inc. may void the user's authority to operate this equipment.

Assemble Voltage Detector

1. Drive voltage stake into ground at least 6' (2 m) away from any part of system.
2. Clip voltage limiter to voltage stake.



j070m021c.eps

Test Strike System

If system fails any part of this test, see “ESID Diagnostic Codes” on page 97 on the following page. Do not drill until test is completed successfully.

1. Turn on drilling unit.
2. ESID control module will perform internal tests which check everything but alarms and strobe.
3. If green OK indicator and electrical power supply indicator lights remain on, press self test button to perform total test of strike system. During this test:
 - All lights should glow.
 - Alphanumeric readout should display numbers.
 - Alarms and strobes on all connected units should sound.
4. If this test is successful, OK indicator and electrical power supply indicator lights will remain on.
5. Use Electric Strike Simulator to test voltage and current sensors. See page 100.

ESID Diagnostic Codes

When strike system detects a problem, an error code will be displayed. Anytime this happens, press self test button to retest. If error code is still displayed and does not appear in this chart, have control module checked or replaced.



Code	Display	Condition	Result
502	2.5V REF	2.5V reference error in ESID	internal reference failure, ESID may not give valid readings
503	-5V REF	-5V reference error in ESID	internal reference failure, ESID may not give valid readings
504	CLK RESP	clock response error	clock may not be working
505	LCD RESP	LCD response error	LCD display may not work
506	LED RESP	LED response error	LED display may not work
507	LCD CONTR	LCD contrast error	LCD contrast not saved properly
508	COP RESET	cop watchdog error	processor has reset, unknown status of ESID code
510	STRB DVR	strobe driver output error	strobe may not function
511	HORN DVR	horn driver output error	horn may not function
512	BAT POWER	battery power/horn driver error	strike hold on power may not function
513	TEST WIRE	no continuity on test wire for testing ESID	Information Center may not be able to reset ESID
515	STR VOLT	strike voltage input error	
516	STR COIL	strike current input error	
517	POST AC V	self test ac voltage input error	self test of ac voltage stake failed
518	POST AC I	self test ac current input error	self test of ac current coil failed
519	POST DC V	self test dc voltage input error	self test of dc voltage input amplifier failed
520	POST DC I	self test dc current input error	self test of dc current input amplifier failed
521	V NOT GND	strike voltage input stake not grounded	self test of voltage stake failed
588	EEP WRITE	EEProm write error	ESID may not be able to record strike history
589	MISC CODE	invalid error report entry	software error report

Troubleshoot Strike System

In addition to self-test diagnostic codes, other problem situations and their possible causes and solutions are listed in the chart below.

Problem	Possible cause	Possible solution
No lights or readings showing after drilling unit key has been on at least one minute	Problems in startup	Push self test button. If problem goes away, retest strike system
	No power to strike system control module	Check drilling unit electric system
		Check that harness from drilling unit to control module is connected
		Check that cable from drilling unit carries more than 10V
	Defective control module	Have control module checked or replaced
Screen is blank	Strike system is not getting adequate power from drilling unit	Check drilling unit electric system
		Check that harness from drilling unit to control module is connected
		Check that harness from drilling unit carries more than 10V
	Defective control module	Have control module checked or replaced
Information on screen is visible during self test but not after test is complete	LCD contrast is not set properly	Contact your Ditch Witch dealer to adjust contrast
OK indicator is on, but electrical power supply indicator is off	Strike system is not getting adequate power from drilling unit	Check drilling unit electric system
		Check that harness from drilling unit to control module is connected
		Check that harness from drilling unit carries more than 10V
	Defective control module	Have control module checked or replaced
Electrical power supply indicator is on, but OK indicator is off	Problem detected during test	Check for error code and have control module checked or replaced
	Defective control module	Have control module checked or replaced

Problem	Possible cause	Possible solution
Strobe light on drilling unit does not work during total test	Improper connections with control module	Check connections and wiring harness
	Defective strobe light	1. Disconnect strobe and connect to external 12V power source. 2. If strobe does not work, replace it.
	Defective control module	Have control module checked or replaced
Alarm on drilling unit does not work during total test	Improper connections with control module	Check connections and wiring harness
	Defective alarm	1. Disconnect strobe and connect to external 12V power source. 2. If strobe does not work, replace it.
	Defective control module	Have control module checked or replaced
Strobe light and alarm on drilling unit do not work during total test	Improper connections with control module	Check connections and wiring harness
	Defective control module	Have control module checked or replaced
EC2 code displays and current problem indicator is on	Improper connections with control module	Check cable connections on control module and current transformer
	Defective current transformer	1. Disconnect current transformer. 2. Check for 20-40 ohms from pin 1 to pin 4, 20-40 ohms from pin 1 to pin 2, and less than 1 ohm from pin 2 to pin 4.
	Defective current transformer cable	1. Disconnect cable from transformer and control module. 2. Check continuity of cable. 3. If continuity is zero or cable is damaged, replace.
	Defective control module	Have control module checked or replaced
EV1 code displays and voltage problem indicator is on	Improper connection of voltage limiter to ground stake	Check voltage limiter connection to ground stake and verify that ground stake is driven into the ground
	Defective voltage limiter	Have voltage limiter checked or replaced
	Defective control module	Have control module checked or replaced



Problem	Possible cause	Possible solution
EV2 code displays and voltage problem indicator is on	Improper connections with control module	Check cable connection on control module
	Defective voltage limiter	Have voltage limiter checked or replaced
	Defective control module	Have control module checked or replaced

Use Electric Strike Simulator

Use the Electric Strike Simulator (p/n 259-506) to test voltage and current sensors on ESID. If readings are less than indicated here, replace 9V battery in simulator and retest.

Current Test

To test for current at normal levels:

1. Thread one lead wire through current transformer.
2. Clip ends of lead wires together to make one loop.
3. Move simulator switch to "current" and press test button.
4. Watch screen and lights above display on strike system.
 - Three or four lights should turn on.
 - Current "A" should show 30-50% in display.

To test for current at strike levels:

1. Put two or three loops through current transformer.
2. Follow steps above to test.
3. Display should show the following:
 - All lights should turn on.
 - Alarm and strobe should turn on.

With two loops,

- Current "A" should be 80-110%.
- Strike indication might go on and off.

With three loops,

- Current should be 130-160%.
- Strike indication should be continuous.



Voltage Test

1. Place voltage limiter on something insulated from ground and drilling unit (such as dry board or tire), but near frame of drilling unit.
2. Clip one lead to frame.
3. Clip other lead to one voltage limiter mount.
4. Move simulator switch to "voltage" and press test button.
5. Watch screen and lights above display on strike system.
 - All lights should turn on.
 - Alarm and strobe should turn on.
 - Voltage "V" should show 90-110%.

It is normal for simulator voltage levels to drift below strike level. When this happens, light in triangle should go off and alarm and strobe should stop working. If the level drifts above strike level again, light, alarm, and strobe should be turned on again.

Drilling Fluid

For productive drilling and equipment protection, use these recommended Baroid® products, available from your Ditch Witch dealer. Use appropriate PPE Material Safety Data Sheet (MSDS) information, available at www.ditchwitch.com/safe.

- Soda ash
- Quik-Gel™ dry powder bentonite (p/n 259-804)
- E-Z Mud™ liquid polymer (p/n 259-805)
- Liqui-Trol™ liquid polymer suspension (p/n 259-808)
- Quik-Trol™ dry powder polymer (p/n 259-809)
- Bore-Gel™ drilling fluid (p/n 259-807)
- Con-Det™ water-soluble cleaning solution (p/n 259-810)

Guidelines

Match drilling fluid to soil type. This chart is meant as a guideline only. See your local Ditch Witch dealer for soil conditions and drilling fluid recommendations for your area.

Soil type	Drilling fluid recommendation
smooth, flowing sand	bentonite or Bore-Gel + medium chain polymer
coarse sand or light soil	bentonite or Bore-Gel
heavy clay	long chain polymer + Con-Det
swelling clay	long chain polymer + Con-Det
rock	Bore-Gel

Polymer

This drilling fluid additive provides excellent lubrication and increases viscosity in average soils and heavy clay. In swelling clay, polymer can reduce swelling that traps pipe in the bore.

There are two types of polymer:

- long chain such as Baroid EZ-Mud
- medium chain such as Baroid Quik-Trol

Bentonite

Bentonite is a dry powder. When properly mixed with water, it forms a thin cake on bore walls, lubricating the bore, keeping it open, and holding fluid in the bore.

Some things to remember when mixing bentonite:

- Use clean water free of salt, calcium, or excessive chlorine.
- Use water with pH level between 9 and 10.
- Use water with hardness of less than 120 ppm.
- Do not use bentonite containing sand.
- Mix bentonite thoroughly or it will settle in tank.
- Do not mix bentonite to a funnel viscosity of over 50.

For information on measuring funnel viscosity, see "Funnel Viscosity" on page 106.

Mixtures

Bentonite does not mix well in water containing polymer. To use both, mix bentonite first, then add polymer. When adding other products follow the order listed below.

NOTICE:

- If chemicals are added in the wrong order, they will not mix properly and will form clumps.
- If tank contains bentonite/polymer mix and more drilling fluid is needed, completely empty tank and start with fresh water before mixing another batch.

General mixing order:

1. Soda ash
2. Bentonite
3. Polymer
4. Con-Det

Bore-Gel contains premixed bentonite, polymer, and soda ash. Use approximately 15 lb/100 gal (7 kg/380 L) in normal drilling conditions, up to 45 lb/100 gal (21 kg/380 L) in sand or gravel and up to 50 lb/100 gal (23 kg/380 L) in rock.



Basic Fluid Recipes

Soil type	Mixture/100 gal (378 L) of water	Notes
fine sand	35 lb (16 kg) Bore-Gel	
coarse sand	35 lb (16 kg) Bore-Gel .5 lb (225 g) No-Sag	Add .5 lb (225 g) of Quik-Trol for additional filtrate control
fine sand below water table	40 lb (18 kg) Bore-Gel .75 lb (340 g) Quik-Trol	Add .5 - 1 gal (2-4 L) of Dinomul in high torque situations
coarse sand below water table	40 lb (18 kg) Bore-Gel .75 lb (340 g) Quik-Trol .75 lb (340 g) No-Sag	Add .5 - 1 gal (2-4 L) of Dinomul in high torque situations
gravel	50 lb (23 kg) Bore-Gel .75 lb (340 g) Quik-Trol .75 lb (340 g) No-Sag	Add .5 lb (225 g) of Barolift to reduce loss of returns
cobble	50 lb (23 kg) Bore-Gel .75 lb (340 g) Quik-Trol .75 lb (340 g) No-Sag	Add .5 lb (225 g) of Barolift to reduce loss of returns
sand, gravel, clay or shale	35 - 40 lb (16-18 kg) Bore-Gel .5 pt (235 mL) EZ-Mud .5 gal (2 L) Con-Det	Vary mixture according to percentage of sand and clay
clay	.5 lb (225 g) Poly Bore .5 gal (2 L) Con-Det	Flow rate should be 3-5 parts fluid to 1 part soil. May use .25 - .5 gal (1-2 L) of Penetrol instead of Con-Det
swelling/sticky clay	.75 - 1 lb (340-450 g) Poly Bore .5 - 1 gal (2-4 L) Con-Det	Flow rate should be 3-5 parts fluid to 1 part soil. May use .25 - .5 gal (1-2 L) of Penetrol instead of Con-Det
solid rock (shale)	40 lb (18 kg) Bore-Gel	Use .5 pt (235 mL) of No Sag for large diameter or longer bores
solid rock (other than shale)	40 - 50 lb (18-23 kg) Bore-Gel	Use .5 pt (235 mL) of EZ-Mud in reactive shales
rock/clay mixture	40 - 50 lb (18-23 kg) Bore-Gel .5 pt (235 mL) EZ-Mud	
rock/sand mixture	40 - 50 lb (18-23 kg) Bore-Gel	Use .5 pt (235 mL) of No Sag for large diameter or longer bores
fractured rock	50 lb (23 kg) Bore-Gel .5 - 1lb (225-450 g) No-Sag	Use .5 lb (225 g) of Barolift to reduce fluid loss to formation

Drilling Fluid Requirements

1. Determine drilling conditions and choose appropriate drilling fluid mix.
2. Estimate amount of supplies needed and check availability.
 - Drilling fluid
 - Water supply. If more water than can be carried with the unit will be needed, arrange to transport additional water.
 - Bentonite and/or polymer
3. Check water quality.
 - Use meter or pH test strips to test pH of water. If pH is below 9.0, add 1 lb (454 g) soda ash per tank. Test and repeat until pH is between 9 and 10.
 - Check water hardness using hardness test strips. Treat with soda ash if hardness exceeds 125 ppm.




Funnel Viscosity

Viscosity is the measure of internal resistance of a fluid to flow; the greater the resistance, the higher the viscosity. Viscosity of drilling fluids must be controlled.

To determine viscosity, you will need a Marsh funnel (p/n 259-267) and a measuring cup, available from your Ditch Witch dealer.

IMPORTANT: Make sure Marsh funnel is clean and free of obstruction and that you have a stopwatch available for timing the viscosity.

1. Using wash hose and a clean container, take a fresh sample of drilling fluid. The sample must be at least 1.5 qt (1.4 L).
2. With finger over bottom of funnel, fill with fluid from the container through the screen until fluid reaches the bottom of the screen.
3. Move funnel over 1 qt (.95 L) container.
4. Remove finger from bottom of funnel and use the stopwatch to count the number of seconds it takes for 1 qt (.95 L) of fluid to pass through the funnel. The number of seconds is the viscosity.
5. Thoroughly rinse measuring cup and Marsh funnel.



j070m033c.eps

Tracker Control

Overview



WARNING

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.



This mode allows the 750/752 Tracker operator to disable hydraulic power to drilling unit thrust and rotation.


NOTICE: This mode does not disable thrust and rotation immediately. Functions are disabled within 16 seconds.

Use tracker control any time you change downhole tools or during other times when the drill string is exposed. Tracker control works by stopping communication between the tracker and the display. When this happens, the green tracker control light on the drilling unit comes on and thrust and rotation are disabled.

Operation

Enable Thrust and Rotation

1. Start drilling unit.
2. Turn off 750/752 Display.
3. Press and hold DOWNLOAD (1) while turning on 750/752 Display until a four-digit code (2) appears.




j07om023c.eps

4. Turn on 750/752 Tracker and check four-digit code.

If codes on tracker and display match, thrust and rotation hydraulics on the drilling unit are enabled.

If codes on tracker and display do not match, adjust tracker code:


- Press and hold fore/aft/left/right button while making the following adjustments.
- Use ON/OFF to advance first two digits (1). Use DEPTH to lower first two digits.
- Use up arrow to advance last two digits (2). Use down arrow to lower last two digits.
- Press and hold each button to advance or lower value quickly.
- To start sending code from the tracker to the display, press and hold fore/aft/left/right button and press MODE. Thrust and rotation hydraulics on the drilling unit are now enabled.



j07om024c.eps

Troubleshooting Tip: If thrust and rotation are not enabled:

- Check whether the green tracker control light located on carriage is on. If it is, communication has probably stopped between tracker and display, or tracker is set to incorrect code.
 - If communication cannot be restored, install tracker control key (shown) in drilling unit. Green tracker control light located on carriage will go off. Thrust and rotation will function.
5. Remove tracker control key (shown). Keep in tracker operator's possession.
6. Drill and track bore.




j31om041h.eps

Disable Thrust and Rotation

1. When drill head enters target pit or exits the ground, turn off tracker.

After 8-16 seconds, green tracker control light (shown), located on drilling unit carriage, will come on. Hydraulic power to thrust and rotation will be disabled.




j31om042h.eps

IMPORTANT: Tracker operator cannot disable thrust and rotation from tracker if tracker control key (shown) is installed in drilling unit and turned to the disable position. See "Tracker control key" on page 33 for more information.

NOTICE: If you are not using tracker control, turn off drilling unit before changing downhole tools.

2. Change downhole tools.
3. **If you are tracking backreamer's path,** turn on tracker and enable code transmission. After 8-16 seconds, green tracker control light on drilling unit carriage will go off and thrust and rotation will function.

If you are not tracking backreamer's path, install tracker control key (shown) on drilling unit. Green tracker control light on drilling unit carriage will go off and thrust and rotation will function.



j31om041h.eps

Downhole Tools

Nozzles

Nozzles control fluid flow from the pipe to the bore. Select nozzles that will supply **at least** the amount of fluid per minute needed for the flow and pressure you will be using. A nozzle that will supply more fluid per minute is recommended. See your Ditch Witch dealer for nozzle recommendations.

Bits

Selection

These charts are meant as a guideline only. No one bit works well in all conditions. See your Ditch Witch dealer for soil conditions and bit recommendations for your area.

- 1 = best
- 2 = good
- 3 = fair
- 4 = not recommended

Bit	Sandy Soil	Soft Soil	Medium Soil	Hard Soil	Rocky Soil	Soft Rock	Hard Rock
Sand bit	1	2	4	4	4	4	4
Durabit	2	2	1	1	4	4	4
Tuff bit	2	1	1	1	2	3	4
Steep Taper Tuff bit	4	3	2	1	1	2	4
Barracuda bit	2	1	1	2	3	4	4
Steep Taper bit	4	3	2	1	1	2	4
Hard Surface bit	2	1	2	3	4	4	4
Glacier bit	4	4	4	3	1	2	4
Rhino bit	4	4	3	3	1	1	3
Jetting assembly	4	4	3	2	1	2	3
Rockmaster	4	4	3	2	1	1	1
Talon Rock bit	4	3	2	1	1	1	4

Soil	Description
sandy soil	sugar sand, blow sand, or other soils where sand is the predominant component
soft soil	sandy loam
medium soil	loams, loamy clays
hard soil	packed clays, gumbo, all compacted soils
rocky soil	chunk rock, glacial till, cobble, rip rap, gravel
soft rock	soft limestone, sandstone, shale, coral, caliche
hard rock	granite, schist, marble, hard limestone



Installation

Remove all paint from mating surfaces before attaching any bit to housing. Install screws (p/n 107-277) and tighten bolts to 120 ft•lb (163 N•m).

Beacon Housings

Beacon Installation

To ensure beacon is installed correctly in rock housing, place battery end of beacon away from bit end of housing.

Backreamers

A backreamer enlarges the hole as pipe is pulled back through the bore. No one backreamer works well in all conditions. These charts are meant as a guideline only. See your local Ditch Witch dealer for soil conditions and backreamer recommendations for your area.

- 1 = best
- 2 = good
- 3 = fair
- 4 = not recommended

Backreamer	Sandy Soil	Soft Soil	Medium Soil	Hard Soil	Rocky Soil	Soft Rock	Hard Rock
Beavertail	3	1	1	1	3	4	4
Three Wing	4	3	3	2	1	1	4
Water Wing	4	3	2	1	2	2	4
Compact Fluted	1	1	2	2	2	3	4
Kodiak	4	3	3	2	1	2	4
Rhino Rock	4	4	4	4	3	2	1
Rockmaster	4	4	4	4	3	1	1
Compaction Cone	1	2	3	4	4	4	4
HC Hard Condition	4	3	2	1	1	4	4
ST Saw Tooth	2	2	1	2	2	3	4
MX Mixer	2	2	3	4	4	4	4
CT Cutter	3	2	1	2	3	4	4
EX Expander	1	2	3	4	4	4	4
Fluted Cone	1	1	2	2	2	3	4

IMPORTANT: For soil definitions, see the chart on the previous page.

Backream Fluid Requirements

Backreaming is only successful when enough fluid reaches the bore. The amount of fluid needed depends on size of bore and soil condition.

Follow these steps to find the **minimum** amount of fluid needed in perfect conditions.



IMPORTANT: Use more fluid than recommended or the backream might be dry and unsuccessful.

Instructions	Example
1. Find amount of fluid needed for your size of backreamer. See the table on the next page.	U.S. A 6" backreamer requires at least 1.47 gal/ft.
	Metric A 152-mm backreamer requires at least 18.24 L/m.
2. Multiply this number by distance per minute you plan to backream. The answer is an estimate of amount of fluid you will need for each minute of backreaming.	U.S. 1.5 gal x 2 ft/min = 3 gal for each minute of backreaming.
	Metric 18 L x .5 m/min = 9 L for each minute of backreaming

IMPORTANT: After you have determined how much fluid you will need, see your Ditch Witch dealer for nozzle recommendations.

Backream Fluid Requirements

Backreamer/product diameter		Gal/ft	L/m	Backreamer/product diameter		Gal/ft	L/m
.5 in	13 mm	0.01	0.13	13.5 in	343 mm	7.44	92.35
1 in	25 mm	0.04	0.51	14 in	356 mm	8.00	99.31
1.5 in	38 mm	0.09	1.14	14.5 in	368 mm	8.58	106.54
2 in	51 mm	0.16	2.03	15 in	381 mm	9.18	114.01
2.5 in	64 mm	0.25	3.17	15.5 in	394 mm	9.80	121.74
3 in	76 mm	0.37	4.56	16 in	406 mm	10.44	129.72
3.5 in	89 mm	0.5	6.21	16.5 in	419 mm	11.11	137.95
4 in	102 mm	0.65	8.11	17 in	432 mm	11.79	146.44
4.5 in	114 mm	0.83	10.26	17.5 in	445 mm	12.49	155.18
5 in	127 mm	1.02	12.67	18 in	457 mm	13.22	164.17
5.5 in	139 mm	1.23	15.33	18.5 in	470 mm	13.96	173.42
6 in	152 mm	1.47	18.24	19 in	483 mm	14.73	182.92
6.5 in	165 mm	1.72	21.41	19.5 in	495 mm	15.51	192.68
7 in	178 mm	2.00	24.83	20 in	508 mm	16.32	202.68
7.5 in	190 mm	2.29	28.50	20.5 in	521 mm	17.15	212.94
8 in	203 mm	2.61	32.43	21 in	533 mm	17.99	223.46
8.5 in	216 mm	2.95	36.61	21.5 in	546 mm	18.86	234.23
9 in	229 mm	3.30	41.04	22 in	559 mm	19.75	245.25
9.5 in	241 mm	3.68	45.73	22.5 in	572 mm	20.65	256.52
10 in	254 mm	4.08	50.67	23 in	584 mm	21.58	268.05
10.5 in	267 mm	4.50	55.86	23.5 in	597 mm	22.53	279.83
11 in	289 mm	4.94	61.31	24 in	610 mm	23.50	291.86
11.5 in	292 mm	5.40	67.01	24.5 in	622 mm	24.49	304.15
12 in	305 mm	5.88	72.97	25 in	635 mm	25.50	316.69
12.5 in	318 mm	6.37	79.17	25.5 in	648 mm	26.53	329.49
13 in	330 mm	6.90	85.63	26 in	660 mm	27.58	342.53

Quick Wrench

To attach or remove downhole tools, use quick wrench to join or break the joint.




⚠ DANGER Moving tools will injure or kill. Shut off drill string power when anyone can be struck by moving or thrown tools. Never use pipe wrenches on drill string.




IMPORTANT: Apply TJC to threads and hand-tighten joint before attaching quick wrench components to tighten joint.

Attach quick wrench in either the join or break position.



QuickWrench_JoinBreak_Flats.eps

Join




Break

- Unbolt vise (1) and place jaws around pipe.
- Bolt jaws of vise together.
- Place jaw (2) around pipe.
- Pin handles (3) to wrench jaws. Be sure handles are both up.
- Attach pivot nuts (4) to wrench handles so that screw drive handle (5) is over joint.

To Join

1. Scribe straight line across joint on both sides of separating line (A).
2. Scribe second line (B) on moveable side of joint in the opposite direction of tightening action .25" (6 mm) away from first line.
3. Turn handle until second line (B) meets first (A).
4. Turn handle opposite direction two turns to relieve pressure.
5. Remove quick wrench components.



j07om071h.eps

To Break

1. Turn handle until joint is broken.
2. Turn handle opposite direction two turns to relieve pressure.
3. Remove quick wrench components.

Drill Pipe

Perform Regular Drill Pipe Care

Precondition New Pipe



Repeat this procedure **three times** for each piece of pipe before it is used the first time:

1. **Hand-lubricate** entire surface of threads and shoulders of both ends of pipe with copper base tool joint compound. See page 120 for correct lubricant.
2. Join pipe and tighten joint.
3. Break joint.
4. Move pipe back to box.

NOTICE: Failure to follow this procedure could result in fused joints. Pipe will be damaged or destroyed.

Lubricate Joints Before Each Use

Lubricate threads and shoulders of male joints with copper base tool joint compound. This prevents rust and reduces wear on shoulders and threads. See page 130 for correct lubricant.


Clean the Threads

Clean the threads as needed with high-pressure water and detergent.

NOTICE: Do not use gasoline or other petroleum-based solvents. This prevents tool joint compound from sticking to the joints and will reduce thread life.

Use Caps and Plugs

Before transporting in dusty conditions or prolonged storage, install caps and plugs to male and female ends of pipe and to saver sub.



j070m031c.eps

Replace Worn Saver Sub

Because each pipe comes in contact with the saver sub, check saver sub regularly for wear. Replace it when it is worn, or it will damage your drill pipe. See page 149 for replacement procedure.

Precondition a new saver sub the same way you do new pipe. See "Precondition New Pipe" on page 117.

Rotate Pipe Order


Because the lead drill pipe is in the ground longer, it is subjected to higher shock loads and experiences more wear. To help spread this wear evenly over all pipe, move the lead pipe from the previous job out of the first position. See "Rotate Pipe Order" on page 118.

Use Drill Pipe Correctly

Align the Joints

Always carefully align the male and female ends of pipe before screwing them together. Poor alignment can damage the threads and destroy the usefulness of the joint.

IMPORTANT: The first pipe drilled must be in a straight line with the unit. A misaligned pipe can damage threads on each pipe that is added.




DrillPipe_Align.eps

Clamp Pipe Correctly

Clamp on pipe when joint is centered between wrenches. Clamp only on the tool joint of the drill pipe as shown. This portion of the drill pipe is designed for clamping and is considerably thicker and stronger than the rest of the pipe.

NOTICE: Clamping anywhere else on the pipe will weaken the pipe. Pipe can later break, even when operating under normal loads.



DrillPipe_Clamp.eps



Make Up and Break Out Joints Correctly

- **Make up and break out joints slowly.** Do not ram pipes together during makeup or force them apart during breakout. Carefully time rotation with carriage travel speed, and always connect and disconnect joints slowly and deliberately. This will help prevent thread crossing, galling, and shoulder swelling.
- **Torque joints fully.** Once the joint is connected and the shoulder faces are touching, torque them to full machine torque. Improperly torqued joints will damage the shoulder faces and threads, and will cause joints to leak or break while drilling or backreaming.

Do not Overwork the Pipe

Never exceed the bend radius for your pipe. See “Recommended Bend Limits” on page 56. Do not oversteer.

NOTICE: Bending pipe more sharply than recommended will damage pipe and cause failure.

Complete the Job

Chapter Contents

Antifreeze Drilling Unit	122
• Add Antifreeze	122
• Reclaim Antifreeze	123
Rinse Equipment	124
Disconnect	125
Stow Tools	125




Antifreeze Drilling Unit

Your drilling unit can be left overnight in freezing conditions by circulating a polypropylene-based antifreeze (p/n 265-644) through optional antifreeze system before shutdown.

Add Antifreeze


Without optional antifreeze kit:

1. Move carriage to front of drill frame.
2. Position 1-gal (4-L) bucket under spindle.
3. Connect hose to drilling fluid pump inlet (shown).
4. Insert hose into container of approved antifreeze.
5. Turn drilling fluid control fully clockwise to off position.
6. Start unit and set throttle to slow position.
7. Slowly turn drilling fluid control counterclockwise to start fluid flow.
8. Run drilling fluid pump until antifreeze comes out of spindle.
9. Turn drilling fluid control fully clockwise to stop flow.



Using optional antifreeze kit:

1. Fill antifreeze tank with 1 gal (4 L) of approved antifreeze.
2. Move carriage to front of drill frame.
3. Position 1-gal (4-L) bucket under spindle.
4. Open valve between antifreeze tank and head of drilling fluid pump.
5. Turn drilling fluid control fully clockwise to off position.
6. Start unit and set throttle to slow position.
7. Slowly turn drilling fluid control counterclockwise to start fluid flow.
8. Run drilling fluid pump until antifreeze comes out of spindle.
9. Turn drilling fluid control fully clockwise to stop flow.



Reclaim Antifreeze

1. Connect remote fluid system. See page 89.
2. Turn on remote fluid system engine and open valves to allow fluid flow.
3. Start drilling unit and run at low throttle.
4. Move carriage to front of drill frame.
5. Position 1-gal (4-L) bucket under spindle.
6. Turn drilling fluid pump on low speed.
7. Turn drilling fluid pump off when drilling fluid comes out of spindle.
8. Pour antifreeze into tank.



IMPORTANT: Antifreeze can be removed from antifreeze tank and disposed of properly or it can be reused until it is too diluted with drilling fluid to protect against freezing.


Rinse Equipment

Using Optional Washwand

Connect the washwand at quick connect at rear of unit. Close valve (shown) to shut off flow to spindle.

IMPORTANT:

- Never use high flow when using wash wand.
- Use extreme caution when working with highly pressurized water.




j31om045h.eps



⚠ WARNING Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

NOTICE: Failure to prime the drilling fluid pump will cause flow fluctuations, which will make it difficult to control the washwand. For instructions, see "Connect Fluid System" on page 109.



⚠ WARNING Pressurized fluid or air could pierce skin and cause injury or death. Stay away.

Spray water onto equipment to remove dirt and mud. Some pressure might be needed to remove dried mud from wrench area.

NOTICE: Do not spray water onto operator's console. Electrical components could be damaged. Wipe down instead.

Disconnect

Disconnect and store the following hoses and cables (if used):

- electric strike system voltage stake
- fluid hose

Stow Tools

Make sure all quick wrenches, bits, pullback devices, and other tools are loaded and properly secured on trailer.



Service

Chapter Contents

Service Precautions 128
Recommended Lubricants/Service Key 130
Startup/10 Hour 132
50 Hour 137
100 Hour 141
150 Hour 143
250 Hour 143
750 Hour 144
1000 Hour 145
2000 Hour 147
As Needed 147



Service Precautions

**⚠ WARNING**

Incorrect procedures could result in death, injury, or property damage. Learn to use equipment correctly.

NOTICES:

- Unless otherwise instructed, all service should be performed with engine off.
- Refer to engine manufacturer's manual for engine maintenance instructions.

Welding Precaution

NOTICE: Welding can damage electronics.

- Disconnect battery to prevent damage to battery. Do not turn off battery disconnect switch with engine running, or alternator and other electronic devices may be damaged.
- Connect welder ground clamp close to welding point and make sure no electronic components or bearings are in the ground path.

Washing Precaution

NOTICE: Water can damage electronics. When cleaning equipment, do not spray electrical components with water.


Working Under Drilling Unit



⚠ WARNING Crushing weight could cause death or serious injury. Use proper procedures and equipment or stay away.

Before working under area of drilling unit supported by a stabilizer, make sure drilling unit is parked on hard surface.

1. Remove yellow cylinder lock from storage at rear of pipe box and place over extended cylinder rod (shown) with curved ends toward stabilizer shoe.
2. Raise stabilizer to lower unit until load is supported by cylinder lock.



j310m009h.eps


Opening/Closing Front Hood

To open

1. Unlock hood at outside latches (1).
2. Press key lock buttons to release latches and tip hood toward you.
3. Lift hood to remove.

To close

1. Align pins (2) with designated holes.
2. Secure latches (1). Lock if necessary.



j310m010h.eps



Recommended Lubricants/Service Key

Item	Description
 DEO	Diesel engine oil meeting or exceeding CH-4 per the API service classification or E5 per the European Automobile Manufacturer's Association (ACEA) and SAE viscosity recommended by engine manufacturer (SAE 10W30)
 EO	Engine oil (SAE 10W30)
 MPG	Multipurpose grease. Use polyurea based NLGI GC-LB Grade 1.5 or lithium based NLGI GC-LB Grade 2.
 MPL	Multipurpose gear oil meeting API service classification GL-5 (SAE 80W90)
 DEAC	Diesel engine antifreeze/coolant meeting ASTM D5345 (prediluted) or D4985 (concentrate)
 THF	Tractor hydraulic fluid, similar to Phillips 66 HG, Mobilfluid 423, Chevron Tractor Hydraulic Fluid, Texaco TDH Oil, or equivalent
 TJC	Tool joint compound: Ditch Witch standard (p/n 259-858) or summer grade (p/n 256-031)
	Check level of fluid or lubricant
	Check condition
	Filter
	Change, replace, adjust, service or test


Proper lubrication and maintenance protects Ditch Witch equipment from damage and failure. Service intervals listed are for minimum requirements. In extreme conditions, service machine more frequently. Use only recommended lubricants. Fill to capacities listed in "Fluid Capacities" on page 153.

For more information on engine lubrication and maintenance, see your Kubota® engine manual.

NOTICE:

- Use only genuine Ditch Witch parts, filters, approved lubricants, TJC, and approved coolants to maintain warranty.
- Use the "Service Record" on page 159 to record all required service to your machine.

Engine Oil Temperature Chart



t10om043h.eps

Temperature range anticipated before next oil change

Approved Coolant

Any coolant is approved for use with this unit. However, it was filled with John Deere Cool-Gard coolant before shipment from factory. Add only Cool-Gard (p/n 255-006) or any fully-formulated, ethylene glycol based, low-silicate, heavy-duty diesel engine coolant meeting ASTM specification D5345 (prediluted) or D4985 (concentrate). Before using any other kind of coolant, completely flush radiator.

NOTICE: Do not mix heavy-duty diesel engine coolant and automotive-type coolant. This will lead coolant breakdown and engine damage.

Approved Fuel

This engine is designed to run on diesel fuel. Use only high quality fuel meeting ASTM D975 No. 2D, EN590, or equivalent. At temperatures below 32° F (0° C) winter fuel blends are acceptable. See the engine operation manual for more information.

IMPORTANT: For machines operated in the U.S.: The engine in this product is certified to operate on low sulfur diesel fuel (LSD) with a sulfur content of 500 ppm (0.05%) or less. Use LSD or ultra low sulfur diesel fuel (ULSD) only. Using fuels with higher sulfur content will affect exhaust emissions. Such action is a violation of the US Clean Air Act and US EPA regulations and will result in fines.

For machines operated outside the U.S.: Fuel sulfur content should be less than 5000 ppm (0.5%). Worldwide fuel sulfur regulations vary widely. Fuel used should always comply with local regulations. If fuel sulfur content exceeds 5000 ppm, use a lube oil meeting API CF (or equivalent) with a TBM value of 10 or greater. Do not use lube oils meeting API CJ-4 (or other low SAPS equivalent) under any conditions.

Biodiesel blends up to 5% (B5) are approved for use in this unit. The fuel used must meet the specifications for diesel fuel shown above. In certain markets, higher blends may be used if certain steps are taken. Extra attention is needed when using biodiesel, especially when operating in cold weather or storing fuel. Contact your Ditch Witch dealer or the engine manufacturer for more information.



Startup/10 Hour

Location	Task	Notes
DRILLING UNIT	Check engine air filter service indicator	
	Check engine oil level	DEO
	Check hydraulic hoses	
	Check hydraulic fluid level	THF
	Check pipe auto lubricator spray nozzle	optional equipment
	Check tool joint compound level	TJC
	Check coolant level	DEAC
	Check drilling fluid pump oil level	

Drilling Unit

Check Engine Air Filter Service Indicator

Check air filter restriction indicator before startup and every 10 hours of operation. Change air filter elements when air filter restriction indicator reaches the red zone.

NOTICE: Only open the air filter canister when air restriction is indicated. Change the elements, do not attempt to clean them.


- Compressed air or water may damage filter elements.
- Tapping filter elements to loosen dirt may damage the elements.



AirFilterIndicator.eps

To replace air filter:


1. Open filter canister.
2. Remove and discard primary filter (3) and safety elements (2).
3. Install new safety (2) and primary (3) elements.
4. Close canister.
5. Reset air filter indicator (1).



j31om044h.eps

Check Engine Oil Level

While engine oil is warm, move carriage to front of drill frame and check oil level at dipstick (1) before startup and every 10 hours of operation. Add DEO at fill tube (2) as necessary to keep oil level at highest line on dipstick.



j31om011h.eps

Check Hydraulic Hoses


**⚠ WARNING**

Pressurized fluid or air could pierce skin and cause injury or death. Stay away.

NOTICE: Escaping pressurized fluid can cause injury or pierce skin and poison.

- Before disconnecting a hydraulic line, turn engine off and operate all controls to relieve pressure. Lower, block, or support any raised component with a hoist. Cover connection with heavy cloth and loosen connector nut slightly to relieve residual pressure. Catch all fluid in a container.
- Before using system, check that all connections are tight and all lines are undamaged.
- Fluid leaks can be hard to detect. Use a piece of cardboard or wood, rather than hands, to search for leaks.
- Wear protective clothing, including gloves and eye protection.
- If you are injured, seek immediate medical attention from a doctor familiar with this type of injury.


Check hydraulic hoses for leaks before startup and every 10 hours of operation.



CheckHoses.eps

Check Hydraulic Fluid Level

Check hydraulic fluid level before startup and every 10 hours of operation. Maintain fluid level at halfway point on sight glass (2) when engine is off and fluid is cool. Add THF at hydraulic fluid fill (1) as necessary.




j31om012h.eps

Check Pipe Auto Lubricator Spray Nozzle (Optional)

Check pipe auto lubricator spray nozzle before startup and every 10 hours of operation. Ensure that nozzle is free of obstructions and operates properly. Clean as needed.

NOTICE: Ditch Witch tool joint compound is specially formulated to work with Ditch Witch pipe lubrication system. Use of other tool joint compounds will clog system. See "Recommended Lubricants/Service Key" on page 130 for more information.




j31om013h.eps

Check Pipe Auto Lubricator TJC Level (Optional)

Check pipe auto lubricator TJC level before startup and every 10 hours of operation. Change cartridge as needed. See "Change Lubricator TJC Tube" on page 147 for procedure.

NOTICE: Ditch Witch tool joint compound is specially formulated to work with Ditch Witch pipe lubrication system. Use of other tool joint compounds will clog system. See "Recommended Lubricants/Service Key" on page 130 for more information.




j31om014h.eps



Check Coolant Level


Check coolant level before startup and every 10 hours of operation. When machine is cold, add coolant as needed to maintain between LOW and FULL indicators shown on overflow bottle.



j31om015h.eps

Check Drilling Fluid Pump Oil Level

Check drilling fluid pump oil level before startup and every 10 hours of operation. Add EO as needed.



j31om016h.eps

50 Hour

Location	Task	Notes
DRILLING UNIT	Change engine oil and filter	Initial service, DEO
	Change drilling fluid pump oil (initial)	EO
	Clean drilling fluid pump strainer	
	Check radiator	
	Change hydraulic filter	Initial service
	Check rotation gearbox oil level	2 gearboxes, MPL
	Inspect thrust rollers	
	Check battery	




Drilling Unit

Change Engine Oil and Filter (Initial)

Change engine oil after 50 hours while oil is warm and with unit parked on level ground.

1. Open drain (3).
2. Replace filter (4).
3. Close drain.
4. Add DEO at fill (2) until oil level is at highest line on dipstick (1).


IMPORTANT: Use oil specified in temperature chart found in "Recommended Lubricants/Service Key" on page 130.



j31om017h.eps

Change Drilling Fluid Pump Oil (Initial Service)


Change fluid pump oil after first 50 hours and every 750 hours thereafter. Drain at plug (2) and add EO at plug (1). Maintain fluid level at fill plug.



j31om018h.eps

Clean Drilling Fluid Pump Strainer


Clean drilling fluid pump strainer after the first 50 hours, then clean as needed.



j31om036h.eps

Check Radiator


Check radiator for dirt, grass, and other foreign matter every 50 hours. Clean out with compressed air or spray wash if required. Be careful not to damage fins with high-pressure air or water. Check more often if operating in dusty or grassy conditions.



j31om019h.eps

Change Hydraulic Filter (Initial Service)


Change hydraulic filter (shown) after first 50 hours.



Check Rotation Gearbox Oil Level


Check rotation gearbox oil level every 50 hours. Oil should be visible at plug (2). Add MPL at plug (1) as needed.

IMPORTANT: Drill frame must be level for accurate reading.



Inspect Thrust Rollers

Inspect thrust rollers every 50 hours. Clean or replace if they do not turn freely.




Check Battery

Keep batteries clean and free of corrosion. Apply coat of grease to cable clamps after cleaning.

In cold weather, battery loses some starting ability. Closely watch voltmeter for signs of battery discharge.

If battery will not hold charge, see your Ditch Witch dealer for replacement battery.

IMPORTANT: Use battery disconnect switch (shown) when servicing, welding, and during long-term storage.



j310m023h.eps

100 Hour

Location	Task	Notes
DRILLING UNIT	Change fuel filters	
	Check fan belt tension	


Drilling Unit

Change Fuel Filters


Change canister fuel filter (top) and inline fuel filter (bottom) every 100 hours.

Note: The canister fuel filter is located behind the engine oil filter.

1. Remove filter.
2. Fill new filter with clean fuel.
3. Apply fuel oil over the gasket and hand-tighten.



j31om024h.eps



j31om025h.eps




Check Fan Belt Tension

Check pump drive belt tension every 100 hours.

1. Turn off engine and remove key.
2. Apply moderate thumb pressure to top of belt.

Belt is properly tensioned when deflection (A) is 1/4-3/8" (7-9 mm). To adjust, see page 148.




j31om026h.eps

150 Hour

Change Engine Oil and Filter

Change engine oil every 150 hours while oil is warm and with unit parked on level ground.


1. Open drain (3).
2. Drain crankcase while oil is warm.
3. Replace filter (4).
4. Close drain.
5. Add DEO at fill (2) until oil level is at highest line on dipstick (1).



250 Hour

Change Hydraulic Fluid Filter

Change filter (shown) every 250 hours. Change more often if indicated by filter indicator.




500 Hour

Replace Fan Belt

Replace fan belt (shown) every 500 hours.

To replace


1. Loosen bolts (1, 2) and remove belt.
2. Install new belt and adjust properly. See page 148.



750 Hour

Change Drilling Fluid Pump Oil

Change fluid pump oil every 750 hours. Drain at plug (2) and add with oil at plug (1). Maintain fluid level at fill plug. Capacity for pump is 1 qt (0.9 L).



j31om018h.eps

1000 Hour


Location	Task	Notes
DRILLING UNIT	Change rotation gearbox oil	MPL
	Change hydraulic fluid and filter	THF

Drilling Unit

Change Rotation Gearbox Oil

Drain oil at gearbox oil drain (3) every 1000 hours. Replace drain plug. Add MPL at fill plug (1) until oil is visible at plug (2). Replace fill plug.


IMPORTANT: Drill frame must be level for accurate reading.



j31om028h.eps

Change Hydraulic Fluid and Filter

Change hydraulic fluid and filter every 1000 hours. Drain hydraulic fluid (3), change filter (4), add THF at hydraulic fluid fill (1) and check level at sight glass (2).



j31om029h.eps




2000 Hour

Change Engine Coolant

Drain cooling system at drain (2). Add approved coolant at fill (1) every two years or 2000 hours.

NOTICE:

- The use of non-approved coolant may lead to engine damage or premature engine failure and will void engine warranty.
- See "Approved Coolant" on page 131. for list of approved coolants.



j31om030h.eps

As Needed

Location	Task	Notes
DRILLING UNIT	Change pipe lubricator TJC tube	TJC
	Check track tension and condition	
	Adjust fan belt	
	Replace saver sub	
	Check fluid pump check valve	
	Replace carriage slide bars	
	Replace fuses	




Drilling Unit

Change Lubricator TJC Tube

Check pipe lubricator TJC level and change tube as needed.

To change tube

1. Pull lock handle (3) back.
2. Unscrew cartridge (2).
3. Release handle and push tube (1) out.
4. Pull handle lock.
5. Remove caps and insert new tube of TJC.
6. Screw cartridge in.
7. Release handle.
8. Unscrew cartridge 2-3 turns.
9. Watch for grease to come out of weep hole.
10. Screw cartridge back in when grease comes out of hole.




j31om031h.eps

NOTICE: Use only genuine Ditch Witch tool joint compound to maintain warranty. See "Recommended Lubricants/Service Key" on page 130 for more information.

Check Track Tension and Condition

Check track tension and condition and adjust or replace as needed. See your Ditch Witch dealer for replacement parts.

To adjust, turn bolt (1) clockwise to tighten and counterclockwise to loosen. Track tension is correct when dimension A is approximately 2.25" (57 mm).



j31om032h.eps


Adjust Fan Belt

Adjust fan belt as needed.

1. Turn off engine and remove key.
2. Apply moderate thumb pressure to belt between pulleys where shown.

Belt is properly tensioned when deflection is about 1/4-3/8" (6-10 mm).

3. If needed, loosen alternator bolts (1,2) and pull alternator out until correct tension is reached.



j31om027h.eps


Replace Saver Sub

Check saver sub and replace as needed. See your Ditch Witch dealer for replacement parts.

To replace


IMPORTANT: Saver sub must mate up to every drill pipe. Check sub for thread wear. If saver sub threads are more worn than pipe threads, saver sub is damaging the drill pipe.

1. Remove six bolts from saver sub flange.
2. Remove and discard saver sub.
3. Replace o-ring, if necessary.
4. Install new saver sub.
5. Apply Loctite 242 to bolts and install. Tighten in a cross pattern to 28 ft•lb (38 N•m).




Check Drilling Fluid Pump Check Valve

Check fluid pump check valve (shown) o-ring for wear and replace as needed.




Replace Fuses

Change fuses (shown) as needed. Refer to decal inside panels to identify fuses.



j31om035h.eps

Specifications



j31om037h.eps



Dimensions	U.S.	Metric
L, overall machine length	120 in	3.1 m
W, overall machine width	35.9 in	91.2 cm
H, overall machine height	70 in	1.78 m
Operating weight w/150'/45.7 m of drill pipe, anchoring system and anchor	3690 lb	1674 kg

UFE Pipe	U.S.	Metric
Length	59 in	1.5 m
Joint diameter	1.88 in	47.8 mm
Tubing diameter	1.1 in	28 mm
Minimum bend radius	70 ft	21.3 m
Weight	16 lb	7.25 kg

Operational		U.S.	Metric
Maximum spindle speed		195 rpm	195 rpm
Maximum spindle torque		550 ft•lb	746 N•m
Thrust force		4100 lb	18.2 kN
Pullback force		5000 lb	22.2 kN
Carriage travel speed		130 fpm	40 m/min
Minimum bore diameter		2.5 in	63.5 mm
Backream diameter (soil dependent)		4.5 in	114 mm
Ground travel speed			
	forward	1.53 mph	2.46 km/h
	reverse	1.53 mph	2.46 km/h
Ground bearing pressure		6.0 psi	0.42 kg/cm ²

Power		U.S.	Metric
Engine: Kubota D1105, diesel (Use low sulfur or ultra low sulfur fuel only), liquid cooled, EPA Tier 4, EU Stage 4			
Number of cylinders		3	
Displacement		68.6 in ³	1.12 L
Bore		3.07 in	78 mm
Stroke		3.09 in	78.5 mm
Manufacturer's gross power rating (per SAE J1955)		24.8 hp	18.5 kW
Estimated net power rating (per SAE 1348)		23.1 hp	17.2 kW
Rated engine speed		3000 rpm	3000 rpm
Maximum tilt angle, fore and aft*		30°	30°
Maximum tilt angle, side to side*		30°	30°

* Exceeding these operating angles will cause engine damage. This DOES NOT imply that the machine is stable to maximum angle of safe engine operation.

Drilling Fluid System (Onboard)	U.S.	Metric
Maximum drilling fluid flow	0-5 gpm	0-18.9 L/min
Maximum drilling fluid pressure	750 psi	51.7 bar

Fluid Capacities	U.S.	Metric
Fuel tank	13 gal	49 L
Hydraulic reservoir	8 gal	30 L
Engine oil, including filter	4.2 qt	4 L

Battery
SAE reserve capacity rating 85 min, 12V, negative ground, SAE cold crank rating @ 0°F (-18°C), 525 amps.



Noise Levels
Operator ear sound pressure level is 93 dBA sound pressure per ISO 6394 Exterior sound power level is 103 dBA per ISO 6393

Specifications are called out according to SAE recommended practices where indicated. Specifications are general and subject to change without notice. If exact measurements are required, equipment should be weighed and measured. Due to selected options, delivered equipment may not necessarily match that shown.

Support

Procedure

Notify your dealer immediately of any malfunction or failure of Ditch Witch equipment.

Always give model, serial number, and approximate date of your equipment purchase. This information should be recorded and placed on file by the owner at the time of purchase.

Return damaged parts to dealer for inspection and warranty consideration if in warranty time frame.

Order genuine Ditch Witch replacement or repair parts from your authorized Ditch Witch dealer. Use of another manufacturer's parts may void warranty consideration.

Resources

Publications

Contact your Ditch Witch dealer for publications and videos covering safety, operation, service, and repair of your equipment.



Ditch Witch Training

For information about on-site, individualized training, contact your Ditch Witch dealer.

Warranty

Ditch Witch Equipment and Replacement Parts Limited Warranty Policy

Subject to the limitation and exclusions herein, free replacement parts will be provided at any authorized Ditch Witch dealership for any Ditch Witch equipment or parts manufactured by The Charles Machine Works, Inc. (CMW) that fail due to a defect in material or workmanship within one (1) year of first commercial use (Exception: 2 years for all SK5 attachments). Free labor will be provided at any authorized Ditch Witch dealership for installation of parts under this warranty during the first year following "initial commercial" use of the serial-numbered Ditch Witch equipment on which it is installed. The customer is responsible for transporting their equipment to an authorized Ditch Witch dealership for all warranty work.

Exclusions from Product Warranty

- All incidental or consequential damages.
- All defects, damages, or injuries caused by misuse, abuse, improper installation, alteration, neglect, or uses other than those for which products were intended.
- All defects, damages, or injuries caused by improper training, operation, or servicing of products in a manner inconsistent with manufacturer's recommendations.
- All engines and engine accessories (these are covered by original manufacturer's warranty).
- Tires, belts, and other parts which may be subject to another manufacturer's warranty (such warranty will be available to purchaser).
- ALL IMPLIED WARRANTIES NOT EXPRESSLY STATED HEREIN, INCLUDING ANY WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE AND MERCHANTABILITY.

IF THE PRODUCTS ARE PURCHASED FOR COMMERCIAL PURPOSES, AS DEFINED BY THE UNIFORM COMMERCIAL CODE, THEN THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE FACE HEREOF AND THERE ARE NO IMPLIED WARRANTIES OF ANY KIND WHICH EXTEND TO A COMMERCIAL BUYER. ALL OTHER PROVISIONS OF THIS LIMITED WARRANTY APPLY INCLUDING THE DUTIES IMPOSED.

Ditch Witch products have been tested to deliver acceptable performance in most conditions. This does not imply they will deliver acceptable performance in all conditions. Therefore, to assure suitability, products should be operated under anticipated working conditions prior to purchase.

Defects will be determined by an inspection within thirty (30) days of the date of failure of the product or part by CMW or its authorized dealer. CMW will provide the location of its inspection facilities or its nearest authorized dealer upon inquiry. CMW reserves the right to supply remanufactured replacement parts under this warranty as it deems appropriate.

Extended warranties are available upon request from your local Ditch Witch dealer or CMW.

Some states do not allow exclusion or limitation of incidental or consequential damages, so above limitation of exclusion may not apply. Further, some states do not allow exclusion of or limitation of how long an implied warranty lasts, so the above limitation may not apply. This limited warranty gives product owner specific legal rights and the product owner may also have other rights which vary from state to state.

For information regarding this limited warranty, contact CMW's Product Support department, P.O. Box 66, Perry, OK 73077-0066, or contact your local Ditch Witch dealer.

First version: 1/91; Latest version: 7/05

**A Note To
Ditch Witch
Equipment Owners:**

If your equipment was purchased through a Ditch Witch dealer, there is no need to read further.

However, if you purchased from any other source, please fill out the form on the reverse side and return it to us.


This will enable you to receive updates on this equipment as well as information on new products of interest.

Thanks for using Ditch Witch equipment.

(Please Fold Along This Line And Seal At Bottom With Tape)



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO 23 PERRY OKLAHOMA

POSTAGE WILL BE PAID BY

**The Charles Machine Works, Inc.
P.O. Box 66
Perry, Oklahoma 73077-9989**



**A Note To
Ditch Witch
Equipment Owners:**

If your equipment was purchased through a Ditch Witch dealer, there is no need to read further.

However, if you purchased from any other source, please fill out the form on the reverse side and return it to us.


This will enable you to receive updates on this equipment as well as information on new products of interest.

Thanks for using Ditch Witch equipment.

(Please Fold Along This Line And Seal At Bottom With Tape)



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES



BUSINESS REPLY MAIL

FIRST CLASS PERMIT NO 23 PERRY OKLAHOMA

POSTAGE WILL BE PAID BY

**The Charles Machine Works, Inc.
P.O. Box 66
Perry, Oklahoma 73077-9989**



Ditch Witch® Registration Card

Please Type or Print All Information

Purchaser's Company Name		
Attention		
Street Address or P.O. Box		
City	County	
State	Zip	Nation
()		
Phone Number With Area Code		
Model	Serial Number	
Attachments/Accessories	Serial Numbers	
Attachments/Accessories	Serial Numbers	
Attachments/Accessories	Serial Numbers	
Name of Ditch Witch Dealership		
Your Signature		

Ditch Witch® Registration Card

Please Type or Print All Information

Purchaser's Company Name		
Attention		
Street Address or P.O. Box		
City	County	
State	Zip	Nation
()		
Phone Number With Area Code		
Model	Serial Number	
Attachments/Accessories	Serial Numbers	
Attachments/Accessories	Serial Numbers	
Attachments/Accessories	Serial Numbers	
Name of Ditch Witch Dealership		
Your Signature		

Service Record

[illegible]

[illegible]