

Instruction manual

Operating & Maintenance

4812164801_D.pdf

Vibratory roller
CA1300 - CA1400 D/PD

Engine
Kubota V3307-CR-TE4B (IIIB/Tier 4f)
Kubota V3307-CR-TE5B (Stage V)

Serial number
10000159xxA031263 - xA037624
10000185xxA030910 - xA037228
10000169xxA031137 -
10000186xxA031268 -



Translation of original instruction

Table of Contents

Introduction	1
The machine	1
Intended use	1
Signal symbols and meaning	1
Safety information	1
General	3
CE marking and Declaration of conformity	4
Training	4
Safety - General instructions	5
Safety - when operating	7
Work driving	7
Driving near edges	8
Safety (Optional)	9
Strike-off blade	9
Special instructions	11
Standard lubricants and other recommended oils and fluids	11
Higher ambient temperatures, above +40°C (104°F)	11
Temperatures	11
High pressure cleaning	11
Fire fighting	12
Fire extinguisher	12
Roll Over Protective Structure (ROPS)	12
Battery handling	12
Jump starting	13
Technical specifications	15
Vibrations - Operator station	15
Noise level	15
Electrical system	15
Slopes	16
Dimensions, side view (CA1300)	17

Dimensions, top view (CA1300).....	18
Dimensions, side view (CA1400)	19
Dimensions, top view (CA1400).....	20
Weights and volumes.....	21
Working capacity	21
General	22
CO ₂ -emission.....	23
Air Conditioning / Automatic Climate Control (ACC) (Optional)	24
Tightening torque	25
ROPS - bolts	26
Hydraulic system.....	26
Machine description	27
Diesel engine	27
Electrical system	27
Propulsion system/Transmission	27
Brake system	27
Steering system	28
Vibration system.....	28
Cab.....	28
Emergency exit	28
Seat.....	28
FOPS and ROPS	28
Identification	29
Product and component plates	29
Product identification number on the frame	29
Machine plate.....	30
Explanation of 17PIN serial number.....	30
Engine plates	31
Decals.....	32
Location - decals	32

Location - decals, CALIFORNIA	33
Safety decals.....	33
Info decals.....	36
Instruments/Controls	37
Locations - Instruments and controls	37
Locations - Control panel and controls.....	38
Function description	39
Instruments and controls, cab alternative 1	42
Function description of instruments and controls in the cab alternative 1	43
A/C - System Operation	44
Using the controls in cabin alternative 1	47
Defroster	47
Heat	47
Instruments and controls, cab alternative 2	48
Function description of instruments and controls in the cab alternative 2	49
Using the controls in cabin alternative 2	50
Defroster	50
Heat	50
AC.....	50
Electrical system.....	51
Fuses	51
Fuses in cab.....	52
Alternative 1	52
Alternative 2	53
Main fuses.....	54
Relays on machine.....	54
Cab	55
Alternative 1	55

Alternative 2	55
Operation	57
Before starting	57
Battery disconnecter - Switching on	57
Operator's seat - Adjusting	58
Driver seat (Equipment status) - Adjustment	58
Interlock	59
Parking brake	59
Operator position	60
View	60
Windscreen washer fluid - Checking and filling	61
Instruments and lamps - Checking	61
Rear view mirrors - Adjustment	62
Cab windows - de-icing	62
Wiper blade - Replacement	62
Working lights - Adjustment	62
Starting	63
Starting the engine	63
Driving	64
Operating the roller	64
Operation of strike-off blade (Equipment status)	65
Interlock/Emergency stop/Parking brake - Check	65
Regeneration of DPF filter	66
Vibration	67
Vibration On/Off	67
Vibration - Activation	68
Vibration On/Off	68
Braking	69
Service brake	69

Normal braking	69
.....	69
Reserve brake	70
When reserve braking:.....	70
Emergency stop	70
After an emergency stop:.....	70
Switching off	71
Parking	71
Chocking the drums	71
Batterifrånskiljare - Avstängning	72
Long-term parking	73
Engine	73
Battery	73
Air cleaner, exhaust pipe	73
Fuel tank	73
Hydraulic reservoir	73
Steering cylinder, hinges, etc.	74
Tires	74
Hoods, tarpaulin	74
Engine coolant	74
Miscellaneous	75
Lifting	75
Locking the articulation	75
Lifting the roller	75
Unlocking the articulation	76
Towing	76
Short distance towing with the diesel engine switched off/not running (CA1300)	76
Rear axle brake	77
Brake disengagement	77

Releasing the drum brake (CA1300).....	78
Drum motor brake	78
Short distance towing with the diesel engine switched off/not running (CA1400)	79
Brake disengagement pump.....	79
Towing.....	81
Transport	81
Securing CA1300 - CA1400.....	82
Operating instructions - Summary	87
Preventive maintenance	89
Acceptance and delivery inspection.....	89
Warranty.....	89
Maintenance - Lubricants and symbols	91
Maintenance symbols	93
Maintenance - Maintenance schedule	95
Service and maintenance points	95
General	96
Every 10 hours of operation (Daily).....	96
After the FIRST 50 hours of operation	97
Every 50 hours of operation (Weekly).....	97
Every 250 / 750 / 1250 / 1750 hours of operation	97
Every 500 hours of operation	98
Every 1000 hours of operation	99
Every 1500 hours of operation	100
Every 2000 hours of operation	101
Every 12th month (Annually).....	102
Every 24th month (Every other year)	102
Service - Checklist.....	103
Maintenance - Every 10h	105
Scrapers - Check, adjustment.....	106

CA1300 D	106
CA1400 D	106
Scrapers, Pad-drum	107
CA1300 PD	107
CA1400 PD	107
Air circulation - Check	108
Coolant level - Check	109
Fuel tank - Filling	110
Hydraulic reservoir - Check fluid level	110
Air filter indicator - Resetting	110
Windscreen washer fluid - Checking and filling	111
Air cleaner	
Check - Replacement of main filter	111
Diesel engine Check oil level	111
Air cleaner	
- Check hoses and connections	112
Backup filter - Change	112
Air cleaner	
- Cleaning	113
Brakes - Check	114
Control of Emergency Stop	114
Checking the parking brake	114
Maintenance, first 50h	115
Hydraulic filter - Replacement	115
If passage in either direction is blocked:	115
Tires - Air pressure - Wheel nuts - Tightening	117
Drum gear (CA1400)	118
Oil change	118
Oil filling	118
Diesel engine - Oil- and Filter change	119
The engine fuel filter - replacement/cleaning	120

Maintenance - Every 50h	121
Pre-fuel filter - Draining	121
Maintenance - Every 250h	123
Rear axle differential and pinion housing- Check oil level.....	123
Rear axle planetary gears - Check oil level.....	124
Drum - Checking the oil level (CA1300).....	124
When refilling is needed:	124
Drum - Checking the oil level (CA1400).....	126
Drum gearbox - Checking the oil level (CA1400).....	127
Coolers	
Checking - Cleaning.....	127
Replacing belts/Checking the belt tension	128
Rubber elements and fastening screws	
- Check.....	128
Bolted joints - Checking tightening torque.....	129
Maintenance - Every 500h	131
Battery - Check condition	131
Rear axle differential and pinion housing- Check oil level.....	132
Rear axle planetary gears - Check oil level.....	133
Drum - Checking the oil level (CA1300).....	133
When refilling is needed:	133
Drum - Checking the oil level (CA1400).....	135
Coolers	
Checking - Cleaning.....	136
Rubber elements and fastening screws	
- Check.....	136
The engine fuel filter - replacement/cleaning	137
Diesel engine - Oil- and Filter change.....	138
Forward/Reverse controls and joints	
- Check and lubrication	139
Accessing the machine fitted with ROPS	139
Access on machine with cab	139

If the lever begins to become stiff after prolonged used.	139
If the forward/reverse lever still is stiff after the above adjustments:	139
Replacing the diesel engine's oil separator filter.....	140
Lubrication, hinges	141
Cab	141
Hood	141
Air conditioning (Optional) Fresh air filter - Change	142
Cab option 1	142
Cab option 2	142
Air cleaner Check - Replacement of main filter	143
Air filter indicator - Resetting	143
Backup filter - Change.....	143
Air conditioning (Optional) - Check.....	144
Bolted joints - Checking tightening torque.....	144
Compressor belt - Adjustment.....	145
Maintenance - Every 1000h	147
Battery - Check condition	147
Rear axle differential - Oil change.....	148
Differential.....	148
Pinion house	148
Rear axle planetary gear - Oil change	149
Drum - Checking the oil level (CA1300).....	150
When refilling is needed:	150
Drum - Checking the oil level (CA1400).....	152
Coolers Checking - Cleaning.....	153
Rubber elements and fastening screws - Check.....	153

Fuel tank	154
Cleaning.....	154
Draining (Equipment status)	154
Hydraulic reservoir - Draining.....	155
The engine fuel filter - replacement/cleaning	155
Hydraulic filter - Replacement	156
If passage in either direction is blocked:.....	156
Diesel engine - Oil- and Filter change.....	157
Forward/Reverse controls and joints	
- Check and lubrication	158
Accessing the machine fitted with ROPS	158
Access on machine with cab	158
If the lever begins to become stiff after prolonged used.	158
If the forward/reverse lever still is stiff after the above adjustments:	158
Lubrication, hinges	159
Cab	159
Hood	159
Air conditioning (Optional)	
Fresh air filter - Change	160
Cab option 1	160
Cab option 2	160
Air cleaner	
Check - Replacement of main filter	161
Air filter indicator - Resetting	161
Backup filter - Change.....	161
Air conditioning (Optional) - Check.....	162
Compressor belt - Adjustment.....	162
Hydraulic reservoir - Oil change.....	163
Bolted joints - Checking tightening torque.....	164
Drum gear (CA1400).....	164

Oil change.....	164
Oil filling	164
Maintenance - Every 2000h	165
Battery - Check condition	165
Rear axle differential - Oil change.....	166
Differential.....	166
Pinion house	166
Rear axle planetary gear - Oil change	167
Drum - Oil change	168
Coolers	
Checking - Cleaning.....	169
Rubber elements and fastening screws	
- Check.....	169
Bolted joints - Checking tightening torque.....	170
Fuel tank	171
Cleaning.....	171
Draining (Equipment status)	171
The engine fuel filter - replacement/cleaning	172
Diesel engine - Oil- and Filter change.....	173
Forward/Reverse controls and joints	
- Check and lubrication	174
Accessing the machine fitted with ROPS	174
Access on machine with cab	174
If the lever begins to become stiff after prolonged used.	174
If the forward/reverse lever still is stiff after the above	
adjustments:	174
Lubrication, hinges	175
Cab	175
Hood	175
Air conditioning (Optional)	
Fresh air filter - Change	176
Cab option 1	176

Cab option 2	176
Air cleaner	
Check - Replacement of main filter	177
Air filter indicator - Resetting	177
Backup filter - Change.....	177
Automatic Climate Control (Optional)	
- Overhaul	178
Compressor belt - Adjustment.....	178
Hydraulic reservoir - Oil change	179
Drum gear (CA1400).....	180
Oil change.....	180
Oil filling	180
Hydraulic reservoir - Draining.....	180
Hydraulic filter - Replacement	181
If passage in either direction is blocked:.....	181
Steering joint - Check.....	182
Maintenance, every 12th month (Annually)	183
Air cleaner	
Check - Replacement of main filter	183
Air filter indicator - Resetting	183
Backup filter - Change.....	184
Checking the DPF / EGR pipes / the Manifold and connections (Tier 4f / Stage V).....	184
Maintenance, every 24th month (Every other year)	185
Check - Air intake hoses	185
Cooling water system - Check	186
Coolant - Change	186
Replace via coolant hose.....	186
Change via drain plug.....	186

Introduction

The machine

CA1300/1400 are two vibratory rollers in the 5 - 6.5 tonne class intended for compaction work in pipe trenches, on roads and in confined spaces in connection with refilling work.

Intended use

The machines are available in a D (smooth drum) and PD (padfoot) version. The smooth drum version with drum drive (D) ensures good accessibility even on very steep slopes. The PD version, with pads and drum drive, is specially intended for the compaction of silt and loamy soils. The roller can also be used for repair work on dams, power stations, car parks and airfields.

Signal symbols and meaning



WARNING !

Indicates potential hazardous situation/procedure which, if not avoided, could result in death or serious injury.



CAUTION !

Indicates potential hazardous situation/procedure which, if not avoided, could result in minor or moderate injury, damage to the machine or property.

Safety information



It is recommended to at least train operators in handling and daily maintenance of the machine in accordance with the instruction manual. Passengers are not allowed on the machine, and you must sit in the seat when operating the machine.



The safety manual supplied with the machine must be read by all roller operators. Always follow the safety instructions. Do not remove the manual from the machine.



We recommend that the operator reads the safety instructions in this manual carefully. Always follow the safety instructions. Ensure that this manual is always easily accessible.



Read the entire manual before starting the machine and before carrying out any maintenance.



Replace immediately the instruction manuals if lost, damaged or unreadable.



Only the operator is allowed to be on the roller.



Ensure good ventilation (extraction of air by fan) where the engine is run indoors.

CALIFORNIA

Proposition 65

Decal and location of decal shown in section Machine description.

 **WARNING:** Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to www.P65warnings.ca.gov/diesel.

General

This manual contains instructions for machine operation and maintenance.

The machine must be correctly maintained for maximal performance.

The machine should be kept clean so that any leakages, loose bolts and loose connections are discovered at as early a point in time as possible.

Inspect the machine every day, before starting. Inspect the entire machine so that any leakages or other faults are detected.

Check the ground under the machine. Leakages are more easily detected on the ground than on the machine itself.

If faults or suspected damage are detected on the roller, contact the responsible supervisor for any action.



THINK ENVIRONMENT !

Do not release oil, fuel and other environmentally hazardous substances into the environment.

Always send used filters, drain oil and fuel remnants to environmentally correct disposal.

This manual contains instructions for periodic maintenance, where maintenance after every 10 and 50 hours of operation can be performed by the machine operator.

Other maintenance intervals must be carried out by accredited (Dynapac) service personnel.



Additional instructions for the engine can be found in the manufacturer's engine manual. (Supplied in the machine with the other documentation)

Specific maintenance and checks on diesel engines must be performed by engine supplier authorized personnel.

CE marking and Declaration of conformity

(Applies to machines marketed in EU/EEC)

This machine is CE marked. This shows that on delivery it complies with the basic health and safety directives applicable for the machine in accordance with machinery directive 2006/42/EC and that it also complies with other regulations and directives applicable for this machine.

A "Declaration of conformity" is supplied with this machine, which specifies the applicable regulations and directives with supplements, as well as the harmonized standards and other regulations that are applied and according to the regulations must be declared in writing.

Training

The purpose of operator training is to impart the operator the knowledge and skills necessary for proper operation and routine maintenance of the roller according to this manual.

Note to trainer: Further information on operator training can be found in ISO 7130.

Safety - General instructions

(Also read the safety manual)



- The operator must be familiar with the contents of the OPERATION section before starting the roller.
- Ensure that all instructions in the MAINTENANCE section are followed.
- Only the operator is allowed to be on the roller. Remain seated at all times when operating the roller.
- Never use the roller if it is in need of adjustment or repair.
- Only ascend and descend the roller when it is stationary.
Use the intended footsteps, grips and rails.
Always use the three-point grip (both feet and one hand, or one foot and both hands) when ascending or descending the machine.
Never jump down from the machine.
- Dynapac always recommends mounted ROPS (Roll Over Protective Structure), or a ROPS-approved cab and seat belt usage.
- Drive slowly in sharp bends.
- Avoid driving across slopes. Drive straight up or straight down the slope.
- Never operate with the drum outside the edge, the substrate might not have full bearing strength or the edge is close to a slope. Avoid operating close to edges and ditches and the like as well as on poor ground conditions that jeopardizes the bearing strength and capacity to support the roller.
- Make sure that there are no obstacles in the direction of travel, on the ground, in front of or behind the roller, or overhead.
- Drive particularly carefully on uneven ground.
- Keep the roller clean. Clean any dirt or grease that accumulates on the footsteps or operator platform to avoid slipping risk. Keep all signs and decals clean and legible.
- Safety measures before refueling:
 - Stop the engine
 - Do not smoke.
 - No naked flames in the vicinity of the roller.
 - Earth the filling equipment nozzle by keeping it in contact to the tank opening to avoid sparks.
- Before repairs or service:
 - Chock the drums/wheels.
 - Lock the articulation if necessary.
 - Place blocks under overhanging equipment, such as strike-off blade, edge cutter/presser and chip spreader.

- **Hearing protection is recommended if the noise level exceeds 80 dB(A). The noise level can vary depending on the equipment on the machine and the surface the machine is being used on.**
- **Modifications to the roller, including the use of any attachment/equipment, not approved by Dynapac that might compromise safety (including visibility) are not allowed. Any modifications are only to be made after written approval has been given by Dynapac.**
- **Avoid using the roller before the hydraulic fluid has reached its normal working temperature. Braking distances can be longer than normal when the fluid is cold.**
- **For your own protection always wear:**
 - working boots with steel toecaps
 - ear protectors
 - reflecting clothing/high visibility jacket**Also wear:**
 - helmet if no cab or FOPS, or if required by worksite management
 - working gloves if no cab and for work outside operator's platform.
- **If the machine seems to be responding abnormally during travel, stop and check it.**

Safety - when operating



Prevent persons from entering or remaining in the risk zone, i.e. a distance of at least 7 m (23 ft) in all directions from operating machines. The operator may allow a person to remain in the risk zone, however he/she must be attentive and operate the machine only when the person is fully visible or has given a clear indication of where he or she is.



Avoid driving across a slope. Drive straight up and down sloping ground.

Work driving



Dynapac always recommends mounted ROPS (Roll Over Protective Structure) and seat belt usage. On machines with foldable ROPS, make sure that the ROPS is correctly mounted in the upright position during all operation.

Avoid operating close to edges and ditches and the like as well as on poor ground conditions that jeopardizes the bearing strength and capacity to support the roller. Pay attention to potential obstacles above the machine, such as overhead cables and the branches of trees etc.

Pay particular attention to the stability of the substrate when compacting close to edges and holes. Do not compact with a large overlap from the previous track in order to maintain roller stability. Consider other compaction methods such as remote-control or a walk-behind roller close to steep slopes or where the bearing strength of the substrate is unknown.

Driving near edges



Never operate with the drum outside the edge, the substrate might not have full bearing strength or the edge is close to a slope.



***Keep in mind that the machine's center of gravity moves outwards when steering.
For example, the center of gravity moves to the right when you steer to the left.***

Safety (Optional)

Strike-off blade




Fig. Strike-off blade



The operator must make sure that nobody is in the area of operation while the machine is in use.



The strike-off blade must be retracted to the transport position at the end of each working period.

Special instructions

Standard lubricants and other recommended oils and fluids

Before leaving the factory, the systems and components are filled with the oils and fluids specified in the lubricant specification. These are suitable for ambient temperatures in the range -15°C to +40°C (5°F - 105°F).



The maximum ambient temperature for biodegradable hydraulic oil is +35°C (95°F).

Higher ambient temperatures, above +40°C (104°F)

For operation of the machine at higher ambient temperatures, however maximum +50°C (122°F), the following recommendations apply:

The diesel engine and hydraulic system can be run at this temperature using normal oil, but in other components that use transmission oil, Shell Spirax S3 AX85W/140, API GL-5 or equivalent must be used.

Other components that use transmission oil: Shell Spirax AX 85W/140 or equivalent.

Temperatures

The temperature limits apply to standard versions of rollers.

Rollers equipped with additional equipment, such as noise suppression, may need to be more carefully monitored in the higher temperature ranges.

High pressure cleaning

Do not spray directly onto electrical components.



Do not use a high-pressure water jet on the instrument panel/display.



Detergent that can destroy electrical parts, or which is conductive, must not be used.

Place a plastic bag over the fuel filler cap and secure with a rubber band. This is to avoid high pressure water entering the vent hole in the filler cap. This could cause malfunctions, such as the blocking of filters.



Never aim the water jet directly at the fuel tank cap, or into exhaust pipe. This is particularly important when using a high-pressure cleaner.

Fire fighting

If the machine catches fire, use an ABC-class powder fire extinguisher.

A BE-class carbon dioxide fire extinguisher can also be used.

Fire extinguisher

A fire extinguisher can be ordered as an option. Though, different standards are used around the world.

If not using the original fire extinguisher, place your extinguisher as in the picture. A 4 kg extinguisher is recommended.

Mount it appropriately and make sure it does not create any hazards.




Fig. Cab
1. Fire extinguisher

Roll Over Protective Structure (ROPS)



Never carry out any welding or drilling operations of any kind on the Roll Over Protective Structure (ROPS).



Never attempt to repair a damaged ROPS structure. This must be replaced with new ROPS structure.

Battery handling



When removing batteries, always disconnect the negative cable first.



When fitting batteries, always connect the positive cable first.



Dispose of old batteries in an environmentally friendly way. Batteries contain toxic lead.



Do not use a quick-charger for charging the battery. This may shorten battery life.

Jump starting



Do not connect the negative cable to the negative terminal on the dead battery. A spark can ignite the oxy-hydrogen gas formed around the battery.



Check that the battery used for jump starting has the same voltage as the dead battery.




Fig. Jump starting

Turn the ignition and all power consuming equipment off. Switch off the engine on the machine which is providing jump start power.

First connect the jump start battery's positive terminal (1) to the flat battery's positive terminal (2). Then connect the jump start battery's negative terminal (3) to, for example, a bolt (4) or the lifting eye on the machine with the flat battery.

Start the engine on the power providing machine. Let it run for a while. Now try to start the other machine. Disconnect the cables in the reverse order.

Technical specifications

Vibrations - Operator station (ISO 2631)

The vibration levels are measured in accordance with the operational cycle described in EU directive 2000/14/EC on machines equipped for the EU market, with vibration switched on, on soft polymer material and with the operator's seat in the transport position.

Measured whole-body vibrations are below the action value of 0.5 m/s^2 as specified in Directive 2002/44/EC. (Limit is 1.15 m/s^2)

Measured hand/arm vibrations also were below the action level of 2.5 m/s^2 specified in the same directive. (Limit is 5 m/s^2)

Noise level

The noise level is measured in accordance with the operational cycle described in EU directive 2000/14/EC on machines equipped for the EU market, on soft polymer material with vibration switched on and the operator's seat in the transport position.

Guaranteed sound power level, L_{wA}	103	dB (A)
Sound pressure level at the operator's ear (platform), L_{pA}		
• CA1300	85 ± 3	dB (A)
• CA1400	88 ± 3	dB (A)
Sound pressure level at the operator's ear (cab), L_{pA}	82 ± 3	dB (A)

During operation the above values may differ because of the actual operational conditions.

Electrical system

Machines are EMC tested in accordance with EN 13309:2000 'Construction machinery'




Max 20° or 36%

Slopes

The recommended max slope angle is for a machine that runs straight on hard, flat surface.


Unstable ground, vibration on, speed and steering the machine can all cause the machine to topple at smaller angles than specified here.

Dimensions, side view (CA1300)




	Dimensions	mm	in
A	Wheelbase, drum and wheel	1860	73
L	Length, standard equipped roller	3960	156
L 1	Length, with cab	4005	158
L 1	Length, with cab and strike off blade	4286	169
L 2	Length, with strike off blade	4236	167
H ₁	Height with ROPS / Cab	2565	101
H ₂	Height without ROPS / Cab	1925	76
D	Diameter, drum	1000	39
S	Thickness, drum sweep, nominal	22	0.9
P	Height, pads (PD)	76	3
K ₁	Clearance, tractor frame	350	13.7
K ₂	Clearance, drum frame (D)	260	10
K ₂	Clearance, drum frame (PD)	335	13.1

Dimensions, top view (CA1300)




	Dimensions	mm	in
B	Width, standard equipped roller	1495	59
B 2	Width, with strike off blade	1550	61
O ₁	Overhang, left frame side	62	2.4
O ₂	Overhang, right frame side	62	2.4
R ₁	Turn radius, external	3890	153
R ₂	Turn radius, internal	2400	94
W ₁	Width, tractor section	1380	54
W ₂	Width, drum	1370	54
α	Steering angle	± 33°	

Dimensions, side view (CA1400)



	Dimensions	mm	in
A	Wheelbase, drum and wheel	2200	87
L	Length, standard equipped roller	4510	178
H ₁	Height with ROPS / Cab (D)	2700	106
H ₁	Height with ROPS / Cab (PD)	2710	107
H ₂	Height without ROPS (D)	1810	71
H ₂	Height without ROPS (PD)	1812	71
D	Diameter, drum (D)	1219	48
D	Diameter, drum (PD)	1209	47.6
S	Thickness, drum sweep, nominal (D)	22	0.9
S	Thickness, drum sweep, nominal (PD)	17	0.7
P	Height, pads (PD)	76	3
K ₁	Clearance, tractor frame	360	14
K ₂	Clearance, drum frame	360	14

Dimensions, top view (CA1400)



	Dimensions	mm	in
B	Width, standard equipped roller	1870	73
B 2	Width, with strike off blade	1972	78
O_1	Overhang, left frame side	95	4
O_2	Overhang, right frame side	95	4
R_1	Turn radius, external	4580	180
R_2	Turning radius, inner	2900	114
W_1	Width, tractor section	1530	60
W_2	Width, drum	1676	66
α	Steering angle	$\pm 38^\circ$	

Weights and volumes

Fluid volumes

Fuel tank	117 liters	31 gal
Windscreen washer reservoir	2.1 litres	2.2 qts

Weights and volumes

Model		Operating mass (min - max)	Gross machinery mass
CA1300 D	(kg)	4650 - 5800*	6350
	(lbs)	10,250 - 12,800	14,000
CA1300 PD	(kg)	4850 - 5650	6000
	(lbs)	10,700 - 12,500	13,250
CA1400 D	(kg)	6400 - 7500*	7700
	(lbs)	14,100 - 16,550	17,000
CA1400 PD	(kg)	6550 - 6800	7700
	(lbs)	14,400 - 15,000	17,000
		*) Max. operating mass incl. PD-shell	

Operating mass is the value of the machine individual when it was delivered from the factory.
(Beroende på utrustningsnivå)@@

Gross machinery mass is the value of the heaviest possible version of the machine model.

Working capacity

Note: The frequency is measured at high revs. The amplitude is measured as the real value and not the nominal.

Propulsion	D		PD	
Speed range				
• CA1300	0 - 6	km/h	0 - 4	mph
• CA1400	0 - 10	km/h	0 - 6.2	mph
Climbing capacity (theoretical) without vibration, forward	D		PD	
• CA1300	55	%	52	%
• CA1400	56	%	50	%

Weights
D
PD

Static linear load, with ROPS

• CA1300	13 kg/cm	72.8 pli	-
• CA1400	20 kg/cm	114 pli	-

 Static linear load,
with ROPS and Ballast load

• CA1300	15 kg/cm	84 pli	-
----------	----------	--------	---

Amplitude

• CA1300	1.72	mm	0.068	in.	1.45	mm	0.057	in.
• CA1400 (Hi/Lo)	1.7/0.8	mm	0.067/ 0.032	in.	1.6/0.8	mm	0.063/ 0.032	in.

Vibration frequency, amplitude

• CA1300	35 Hz	2,100	vpm	35	Hz	2,100	vpm
• CA1300 (ECO)	30 Hz	1,800	rpm	30	Hz	1,800	rpm
• CA1400	32 Hz	1,920	vpm	32	Hz	1,920	vpm
• CA1400 (ECO)	28 Hz	1,680	rpm	28	Hz	1,680	rpm

Centrifugal force, amplitude

• CA1300	87 kN	19,575 lbs	87	kN	19,575	lbs
• CA1400 (Hi/Lo)	114/55 kN	25,630/ 12,365 lbs	114/55	kN	25,630/ 12,365	lbs

General
Engine

Manufacturer/Model	Kubota V3307 CR-TE4	Turbo diesel
	Kubota V3307 CR-TE5B (Stage V)	Turbo diesel
Power (SAE J1995)	55 kW	75 hp

Engine speed,

• idling	800 rpm
• ECO	1900 rpm
• working/transport	2200 rpm



The Stage V engine requires the use of Ultra Low Sulphur Diesel (ULSD) fuel, which has a sulfur content of 15 ppm (parts per million) or less. A higher sulfur content causes operating problems and puts the useful life of components at risk, which can lead to engine trouble.
In order to satisfy emissions requirements on regulated markets, the sulfur content at most may be 15 ppm.

CO₂-emission

CO₂-emissions measured according to applicable test cycle in Regulation (EU) 2016/1628.

Manufacturer/Model		Test-cycle	CO ₂ -emission (g/kWh)
Kubota V3307-CR-TE5B	Stage V	NRTC	857.6

NRTC: Non-road transient test cycles

Electrical system

Battery	12V 100Ah
Alternator	12V 60A
Fuses	See the Electrical system section - fuses

Bulbs (if mounted)	Watt	Socket
Dipped beam	60/55	H4
Direction lights, front	21	PY21W
Brake-Position lights	21/5	BAY15d
Direction lights, rear	21	BA15s
License plate light	5	SV8.5
Cab lights	10	SV8.5
Parking lights	5W	W5W

Tire	Tire dimensions	Tire pressure
CA1300		
• Std-type	12,5-20	200 kPa (2.0 kp/cm ²) (29 psi).
• Tractor type	12,5-20	200 kPa (2,0kp/cm ²) (29 psi).
CA1400		
Floatation	400/60-22.5, 16 ply	150 kPa (1.5 kp/cm ²) (21.8 psi).
Weight of complete wheel		
• CA1300	85 kg/tyre	187 lbs/tyre
• CA1400 (fluid-filled wheel)	241 kg/tyre	531 lbs/tyre



When servicing, bare in mind the extra weight caused by a complete, fluid-filled tyre.

Air Conditioning / Automatic Climate Control (ACC) (Optional)

The system described in this manual is an AC/ACC type (Automatic Climate Control). ACC is a system that maintains the set temperature in the cab, provided windows and doors are kept closed.

The system contains fluorinated greenhouse gases.

Coolant designation: HFC-134a

Coolant weight when full: 1.600 kg

CO₂-equivalent: 2.288 ton

GWP:1430

Tightening torque

Tightening torque in Nm for oiled or dry bolts tightened with a torque wrench.

Metric coarse screw thread, bright galvanized (fzb):

PROPERTY CLASS:

M - thread	8.8, Oiled	8.8, Dry	10.9, Oiled	10.9, Dry	12.9, Oiled	12.9, Dry
M6	8.4	9.4	12	13.4	14.6	16.3
M8	21	23	28	32	34	38
M10	40	45	56	62	68	76
M12	70	78	98	110	117	131
M14	110	123	156	174	187	208
M16	169	190	240	270	290	320
M20	330	370	470	520	560	620
M22	446	497	626	699	752	839
M24	570	640	800	900	960	1080
M30	1130	1260	1580	1770	1900	2100

Metric coarse thread, zinc-treated (Dacromet/GEOMET):

PROPERTY CLASS:

M - thread	10.9, Oiled	10.9, Dry	12.9, Oiled	12.9, Dry
M6	12.0	15.0	14.6	18.3
M8	28	36	34	43
M10	56	70	68	86
M12	98	124	117	147
M14	156	196	187	234
M16	240	304	290	360
M20	470	585	560	698
M22	626	786	752	944
M24	800	1010	960	1215
M30	1580	1990	1900	2360



ROPS-bolts which are to be torque tightened must be dry.

ROPS - bolts

Bolt dimensions :	M16 (4700500082)
Strength class :	8.8
Tightening torque :	190 Nm

Hydraulic system

Opening pressure	CA1300		CA1400	
	MPa	Psi	MPa	Psi
Drive system	38.5	5,584	38.5	5,584
Supply system	2,0	290	2.0	290
Vibration system	22,7	3,292	34.5	5,004
Control systems	10,0	1,450	17.5	2,538

Release pressure	MPa	Psi
Brake release		
• CA1300	1.4	203
• CA1400	1.5	217

Machine description

Diesel engine

The machine is equipped with a four-cylinder, water-cooled diesel engine with direct injection.

The engine has an overlying camshaft and the cylinder head is shared by all the cylinders.

The engine is also equipped with a system for after-treatment of exhaust fumes (DPF Diesel Particle Filter).

Exhaust after-treatment system

To minimize particles and hydrocarbons, the engine is fitted with a diesel particle filter, as well as a control unit for after-treatment of exhaust fumes. The diesel particle filter incorporates active burnout.

When the engine is running, particles are collected in the DPF, and the particles have to be burned away in order to clean the filter.

During the burnout/regeneration process, the exhaust gas temperature increases significantly above the normal temperature in the exhaust pipe.

Electrical system

The machine has the following control units (ECU, Electronic Control Unit) and electronic units.

- Main ECU (for the machine)
- Diesel engine control unit (ECM)

Propulsion system/Transmission

The propulsion system is a hydrostatic system with a hydraulic pump supplying two motors connected in parallel, one for the rear axle and one for the drum.

The speed of the machine is proportional to the angle of the control lever (the deflection of the forward/reverse lever regulates the speed). A flow divider is available as an option.

Brake system

The brake system comprises a service brake, secondary brake and parking brake. The service brake system produces retardation of the propulsion system, i.e. hydrostatic braking.

Reserve/Parking brake

The reserve and parking brake system consists of sprung multiple disc brakes in the rear axle and the drum drive, which are released by hydraulic pressure.

Steering system

The control system is a mechanical-hydraulic system of the load-sensing type. The control valve on the steering column distributes the flow to the control cylinder at the articulation. The steering angle is proportional to the deflection of the steering wheel.

Vibration system

The vibration system is a hydrostatic system in which a hydraulic motor drives the eccentric shaft, which generates the drum's vibrations.

The amplitude is determined by the direction of rotation of the hydraulic motor.

Cab

The cab has a heating and ventilation system, with defrosters for all windows. The cab can be equipped with air conditioning and meets the requirements of ISO 10263.

Emergency exit

The cab has two emergency exits. The door and rear window can be smashed using the emergency hammer located in the cab.

Seat

Various types of seats are available. The seat always satisfies the applicable requirements in the market where the machine was originally placed.

The seat is tested and complies with safety dimension ISO 11112, SIP ISO 5353, suspension ISO7096, safety belt ISO 6683.

FOPS and ROPS

FOPS is the abbreviation for "Falling Object Protective Structure" (roof protection (ISO 3449)) and ROPS is the abbreviation for "Roll Over Protective Structure" (ISO 3471).

If any part of the protective construction on the cab or FOPS/ROPS structure reveals plastic deformation or cracking, the FOPS/ROPS structure must be replaced immediately.

Never undertake unauthorised modifications on the FOPS/ROPS structure without first having discussed the modification with Dynapac's production unit. Dynapac will resolve whether the modification would invalidate approval in line with FOPS/ROPS standards.





Fig. Right rear cab post
10. Hammer for emergency exit

Identification

Product and component plates



1. Product plate - Product Identification Number (PIN), model/type designation
2. Engine plate - Type description, product and serial numbers
3. Cab/ROPS plate - Certification, product and serial numbers
4. Component plate, rear axle - Product and serial numbers
5. Component plate, drum - Product and serial numbers

Product identification number on the frame

The machine PIN (product identification number) (1) is punched on the right edge of the front frame or the upper edge of the right frameside.




Fig. Front frame
1. PIN

Machine plate

The machine type plate (1) is attached to the front left side of the frame, beside the steering joint.

The plate specifies the manufacturer's name and address, the type of machine, the PIN product identification number (serial number), operating mass, engine power and year of manufacture. (If the machine is delivered outside the EU there are no CE markings, and on some machines the year of manufacture may not be specified.)




Fig. Operator platform
1. Machine plate

 optional QR code		 Dynapac Compaction Equipment AB Box 504, SE-371 23 Karlskrona Sweden		
Product Identification Number		XXXXXXXXXXXXXXXXXX		
Designation	Type	Rated Power	Max axle load front / rear	
XXXXXX	XXXXXX	XXX kW	XXXX/XXXX kg	
Gross machinery mass		Operating mass	Max ballast	[Date of Mfg]
XXXX kg		XXXX kg	XXXX kg	XXXX
Made in Sweden				
4811 0001 33				

Please state the machine's PIN when ordering spares.

Explanation of 17PIN serial number

100	00123	V	x	A	123456
A	B	C	F		

A= Manufacturer

B= Family/Model

C= Check letter

F= Serial number

Engine plates

The engine's type plate (1) is located on top of the cylinder head cover.

The plate specifies the type of engine, its serial number and the engine specification.




Fig. Engine
1. Type plate


Please specify the engine serial number when ordering spares. Refer also to the engine manual.

TYPE :	#####
FAMILY :	#####
APPROVAL NUMBER:	####/#:P:####/#####
Kubota KUBOTA Corporation	
####	

EMISSION CONTROL INFORMATION	
THIS ENGINE MEETS 2012 ##### EMISSION REGULATIONS FOR U.S. EPA AND CALIFORNIA NONROAD ENGINES.	
Kubota KUBOTA Corporation	
MODEL :	##### ENGINE DISP. : #####
FAMILY :	C #####
POWER :	## kW / ### rpm CATEGORY: ## - ## kW
VALVE CLEARANCE (COLD) :	IN ## mm EX ## mm
EGS :	### #####
ULTRA LOW SULFUR DIESEL FUEL ONLY	
DEL ASSY:	#####

Decals

Location - decals



1. Diesel fuel	4811000345	8. Warning, Hot surfaces	4700903424	15. Hydraulic fluid level	4700272373
2. Warning, Rotating engine components	4700903423	9. Battery master switch	4700904835	16. Hydraulic fluid Bio hydraulic fluid	4700272372 4700792772
3. Warning, Read instruction manual	4700903459	10. Lift point	4700588176	17. Sound power level	4700791273
4. Handbook compartment	4700903425	11. Hoisting plate	4700904870	18. Warning, Starting gas	4700791642
5. Warning, Crush zone	4700903422	12. Tie down point	4700382751	19. Fuel with a low sulphur content	4811000344
6. Warning, Locking	4700908229 4812125363	13. Tire pressure	4812117438	20. Starting instructions	4812115918
7. Coolant	4700388449		4700903985	21. Warning lamps	4812117993
				22. Warning, Brake release	4700904895
				23. Emergency exit	4700903590

Location - decals, CALIFORNIA

Proposition 65





Fig. Location

- | | | |
|----|---------------------------------------|------------|
| 1. | Warning, CALIFORNIA
Proposition 65 | 4812129673 |
|----|---------------------------------------|------------|


Safety decals

Always make sure that all safety decals are completely legible, and remove dirt or order new decals if they have become illegible. Use the part number specified on each decal.


If a part is replaced and this part have a decal, make sure to also order the decal.



- 4700903423**
Warning - Rotating engine components.
 Keep your hands at a safe distance.



- 4700903459**
Warning - Read instruction manual
 The operator must read the safety, operation and maintenance instructions before operating the machine.



- 4700903422**
Warning - Crush zone, articulation/drum.
 Maintain a safe distance from the crush zone.




4700908229

Warning - Risk of crushing, apply locking device

The articulation must be locked when lifting.

Read the instruction manual.



4700903424

Warning - Hot surfaces in the engine compartment.

Keep your hands at a safe distance.



4700791642

Warning - Starting gas

Starting gas is not to be used.



4700903590

-Emergency exit



(CA1400)

4700903985

Warning - Ballasted tire.

Read the instruction manual.

More information in section in Technical specifications.

4812129673
Warning

CALIFORNIA - Proposition 65



WARNING

Breathing diesel engine exhaust exposes you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.


- Always start and operate the engine in a well-ventilated area.
- If in an enclosed area, vent the exhaust to the outside.
- Do not modify or tamper with the exhaust system.
- Do not idle the engine except as necessary.

For more information go to
www.P65warnings.ca.gov/diesel

4812129673


Info decals

1. Diesel fuel




4811000345

4. Handbook compartment




4700903425

7. Coolant




4700388449

9. Master switch




4700904835

10. Lifting point




4700357587

11. Hoisting plate




4700904870

12. Tie down point




4700382751

13. Tire pressure (CA1300)




4700355983

13. Tire pressure (CA1400)




4812117438

15. Hydraulic fluid level




4700272373

16. Hydraulic fluid




4700272372

16. Biological hydraulic fluid




4700904601

16. Biological hydraulic fluid




4700792772

17. Sound power level




4700791273

19. Fuel with a low sulphur content




4811000344

20. Starting instructions



4812115918

Warning lamps



Instruments/Controls

Locations - Instruments and controls







Fig. Instruments and control panel

- | | | | |
|----|--|-----|---------------------------------------|
| 1. | Working lights * | 10. | Switch, parked regeneration |
| 2. | Driving lights * | 11. | Strike-off blade * |
| 3. | Hazard lights * | 12. | Amplitude selector, High/Low (CA1400) |
| 4. | Control lamp, water separator | | Vibration On/Off (CA1300) |
| 5. | Control lamp, parked regeneration | 13. | Engine speed selector, LO/ECO/HI |
| 6. | Control panel | 14. | Direction indicator * |
| 7. | Engine diagnostics control light, serious fault | 15. | Parking brake On/Off |
| 8. | Engine diagnostics control light, less serious fault | 16. | Horn |
| 9. | Speed selector, High/Low (CA1400) | 17. | Rotating beacon * |

*) Depending on machine equipment status.




Locations - Control panel and controls






- 11 Strike-off blade
- 12 Vibration Vibration On/Off
- 18 Low fuel level
- 19 Water temperature, engine
- 20 Oil pressure, engine
- 21 Fuel level
- 22 Parking brake
- 23 Glow plug
- 24 Hourmeter/Error codes, engine

- 25 Battery/charging
- 26 Fuse box
- 27 Instrument cover
(For machine equipped with ROPS only).
- 28 Emergency stop
- 29 Starter switch
- 30 Seat switch
- 32 Forward/reverse lever
- 34 Handbook compartment




Function description

No	Designation	Symbol	Function
1.	Working lights, switch		When depressed, the working lights are on
2.	Driving lights, switch		Where the upper position is depressed, the driving lights are on. Where the lower position is, depressed the parking lights are on.
3.	Hazard warning lights, switch		Where depressed, the hazard warning lights are on
4.	Water separator		Yellow control lamp. If the lamp is lit, this indicates that there is water in the tank. Stop the roller and drain the fuel filter. (see chapter "Maintenance procedures 50h")
5.	Regeneration parked		Yellow control lamp. If the lamp flashes, start a parked regeneration.
6.	Control panel		
7.	Engine diagnostics control light, serious fault		Red control lamp. Serious fault: Switch off engine immediately! Error codes are displayed alternating with the hourmeter on the control panel. Rectify before restarting.
8.	Engine diagnostics control light, less serious fault		Yellow control lamp. Less serious fault Rectify as soon as possible. Error codes are displayed alternating with the hourmeter on the control panel
9.	Speed selector, High/Low (CA1400)		The depressed upper position gives Low speed The depressed lower position gives High speed
10.	Regeneration parked, Switch		Parked regeneration is activated in pressed mode. If the indicator in the switch flashes, start a parked regeneration.


No	Designation	Symbol	Function
11.	Strike-off blade, On/Off, switch		When pressed, the strike-off blade is activated. Controls the position of the strike-off blade.
12.	Vibration, switch (CA1300)		Activates the vibration together with the switch in the forward/reverse lever.
	Amplitude selector, High/Low (CA1400)		The depressed upper position gives Low amplitude The depressed lower position gives High amplitude
13.	Electronic speed control regulator		Three-position switch for idling (LOW), fuel optimization (ECO) and working speed (HI). N.B. When starting the machine, the control must be in idling position (LOW).
14.	Direction indicators, switch		When depressed to the left, the left direction indicators are on etc. In the middle position the function is shut off.
15.	Parking brake		To activate the brakes, press the top of the switch to change the position of the lever. To disengage the brakes, press down the red part at the same time as the switch, and change the position of the lever. NOTE: When starting the machine, the parking brake must be activated.
16.	Horn, switch		Press to sound the horn.
17.	Hazard beacon, switch		When depressed, the hazard beacon is on
18.	Warning lamp, low fuel level		The lamp goes on if the fuel level in the diesel tank is low.
19.	Warning lamp, water temperature		The light comes on if the water temperature is too high. Stop the engine immediately and locate the fault.
20.	Warning lamp, oil pressure		This lamp lights if the lubricating pressure in the engine is too low. Stop the engine immediately and locate the fault.
21.	Fuel level		Shows the fuel level in the diesel tank.
22.	Warning lamp, parking brake		The lamp lights when the parking brake is activated.

No	Designation	Symbol	Function
23.	Warning lamp, glow plug		The lamp must go out before the starter switch is moved to position 3c for activation of the starter motor.
24.	Hourmeter / Error codes, engine		Displays the number of working hours for the engine. Any error codes from the diesel engine are also shown here.
25.	Warning lamp, battery charging		If the lamp lights while the engine is running the alternator is not charging. Stop the engine and locate the fault. At a voltage below 12.5 volts, the engine revs will automatically be set to 1300 revs to ensure sufficient charging of the battery. This only applies when the parking brake is activated.
26.	Fuse box (on control column)		Contains fuses for the electrical system. See under the heading 'Electrical system' for a description of fuse functions.
27.	Instrument cover (For machine equipped with ROPS only)		Lowered over the instrument plate to protect the instruments from the weather and sabotage. Lockable
28.	Emergency stop		When pressed, the emergency stop is activated. Brakes the roller and switches off the engine. The power supply goes off. N.B. When starting the machine, the emergency stop must be inactive.
29.	Starter switch	   	Positions 1-2: Shut off position, key can be removed. Position 3a: All instruments and electric controls are supplied with power. Position 3b: Glowing. Hold the starter switch in this position until the lamp goes out. The starter motor is activated in the next position. Position 3c: Starter motor activation.
30.	Seat switch		Remain seated at all times when operating the roller. If the operator stands up during operation, a buzzer sounds. After 3 seconds the brakes are activated and the engine stops.
32.	Forward/Reverse lever		The lever must be in neutral to start the diesel engine. The engine cannot be started if the lever is in any other position. The forward/reverse lever controls both the roller's driving direction and speed. When the lever is moved forward, the roller moves forward etc. The roller's speed is proportional to the distance the lever is from the neutral position. The further the lever is from the neutral position, the higher the speed.
34.	Handbook compartment		Pull up and open the top of the compartment for access to handbooks.

Instruments and controls,
cab alternative 1



Function description of instruments and controls in the cab alternative 1

No	Designation	Symbol	Function
1	Heater control		Turn to the right to increase heating. Turn to the left to reduce heating.
2	Ventilation fan, switch	 	In the left position, the fan is off. Turning the knob to the right increases the volume of air entering the cab.
3	Air conditioning, switch	 	Starts and stops the air conditioning.
4	Cab air recirculation, switch	  	Pressing the top opens the air damper so that fresh air comes into the cab. Pressing the bottom closes the damper so that the air recirculates inside the cab.
5	Front wiper, switch		Press to operate the front screen wiper.
6	Rear wiper, switch		Press to operate the rear screen wiper.
7	Front and rear window screen washers, switch	 	Press the upper edge to activate the front screen washers. Press the lower edge to activate the rear screen washers.
8	Fuse box		Contains fuses for the electrical system in the cab.
14	Defroster nozzle		Turn the nozzle to direct the flow of air.

No	Designation	Symbol	Function
15	Hammer for emergency exit		To escape from the cab in an emergency, release the hammer and break the rear cab window.
11	Leds, switch		Activates the cab's internal leds

A/C - System Operation

NOTE: When using AC, all windows must be closed for the system to function efficiently.

Activating air conditioning

To activate the air conditioning, set the ventilation knob to one of the three following positions:

- Low level - Knob in position 1
- Intermediate level - Knob in position 2
- High level - Knob in position 3




Fig. Air conditioning and cooling mode
1. Air conditioning activation
3. Cooling activation
4. Recirculation activation

Cooling mode

Use the following settings on the control panel for rapid temperature reduction in the cab:

3

- To activate cooling mode (compressor ON), press switch (3) on the AC.

- To activate recirculation of cab air, press switch (4) to close the fresh air vent.

- Set the heater control (1) to minimum and turn up the fan speed (2).

- When the temperature has dropped to a comfortable level, adjust the desired temperature on the heater control (1) and reduce the fan speed (2).

To deactivate cooling mode, set the knob back to the start position.

The LED will turn off, indicating that cooling mode is off.

When the ventilation knob is set to 0 (zero), cooling mode will automatically be switched off.

Fig. Activating cooling





Fig. Heating mode

- 1. Control
- 13. Closed vent
- 14. Open vent

Heating mode


To activate heating mode, turn the control (1) on the right side of the system clockwise. Heat level is proportional to opening the vent using this command.

Airflow direction



Turn the air vents in any direction and adjust the opening using the flanges.

Fig. Diffuser



Activation of LEDs

LEDs (11) will be turned on when the machine door switch is activated, or when the switch (12) is activated. They will be turned off when the switch is activated a second time.

Fig. LEDs
11. LEDs
12. Switch




Fig. Recirculation activation

Air Recirculation

To activate the air recirculation mode (open external air inlet vent), press switch (4). After activation, the LED inside will light up to confirm that the vent is open.

To deactivate air circulation, turn the knob back to position 1. The LED will turn off, indicating that air recirculation mode is turned off.

Using the controls in cabin alternative 1

Defroster

For quick de-icing or demisting, make sure that only the outer air vents are open.

Turn the heater and fan dial to max.

Adjust the nozzle so that it blows on the window to be de-iced, or to remove mist.

Heat

If the cab is unheated, open the air exhaust located in front of the controls for heating and fan.

Turn to max heat and max fan speed.

When the desired heat is reached, turn down the heat and fan speed.

Instruments and controls, cab alternative 2





Fig. Cab roof, front

Fig. Right rear cab post
15. Hammer for emergency exit

Function description of instruments and controls in the cab alternative 2

No	Designation	Symbol	Function
1	Heater control		Turn to the right to increase heating. Turn to the left to reduce heating.
2	Ventilation fan, switch		In the left position, the fan is off. Turning the knob to the right increases the volume of air entering the cab.
3	Air conditioning, switch		Starts and stops the air conditioning.
5	Front wiper, switch		Press to operate the front screen wiper.
6	Rear wiper, switch		Press to operate the rear screen wiper.
7	Front and rear window screen washers, switch		Press the upper edge to activate the front screen washers. Press the lower edge to activate the rear screen washers.
8	Fuse box		Contains fuses for the electrical system in the cab.
14	Defroster nozzle		Turn the nozzle to direct the flow of air.
15	Hammer for emergency exit		To escape from the cab in an emergency, release the hammer and break the opening windows on the right-hand side.




Fig. Instrument panel
1. Air nozzles




Fig. Control panel, AC 1. Heat knob 2.
Fan knob 3. OFF/ON

Using the controls in cabin alternative 2

Defroster

To quickly remove ice or mist:

- Make sure that only the front and rear air nozzles (1) are open.
- Turn the heater and fan dial (1 and 2) to max.
- Adjust the nozzle so that it blows on the window to be de-iced, or to remove mist.

Heat

If the cab is cold:

- Open the lower nozzle on the front columns and the middle nozzles just over the controls for the heater (1) and fan (2).
- Turn to max heat and max fan speed.
- When the required temperature has been reached, open the other nozzles and if necessary turn down the heat and fan speed.

AC

NOTE: When using AC all the windows must be closed for the system to work efficiently

To quickly reduce the temperature in the cab, adjust the following settings on the control panel:

- Turn on AC (3).
- Set the heater control (1) to minimum and turn up the fan speed (2). Keep only the front middle nozzles in the ceiling open.
- When the temperature has dropped to a comfortable level, adjust the required temperature on the heater control (1) and reduce the fan speed (2).
- Now open the remaining nozzles in the roof to achieve a comfortable temperature in the cab.

Electrical system

Fuses

The figure shows the position of the fuses.

The table below gives fuse amperage and function. All fuses are flat pin fuses.




Fig. Fuse boxes
1. Upper
2. Lower

Fuse box, Upper			Fuse box, Lower		
1.	Emergency stop, ECU, Backup alarm, Neutral position, Seat switch, Vibration	15A	1.	Driving lights	20A
2.	Horn, Summer, Instrument panel	10A	2.	Position lights	10A
3.	Hazard beacon, Strike off blade	10A			
4.	Working lights	20A			
5.	Engine ECU	5A			
6.	Alternator, Indication, Preheater	5A			
7.	EGR valve	5A			
8.	Reserve				




Fig. Cab roof fuse box (F7)
(Alternative 1)

1. F7.1	Interior lighting	3A
2. F7.2	Windscreen wiper/washers (front/rear)	15A
3. F7.3	Blower	15A
4. F7.4	Thermostat	5A
5. F7.5	Compressor clutch	5A
6. F7.6	Recircle / Fresh air motor	1A
7. F7.7	Radio	5A

Fuses in cab

Alternative 1

The electrical system in the cab has a separate fuse box located on the front right side of the cab roof.

The figure shows fuse amperage and function.

All fuses are flat pin fuses.





Fig. Instrument panel

- 1. Fuse box**
- 2. Switch, windscreen wiper and washer**



**Fig. Cab roof fuse box (F7)
(Alternative 2)**

1. F7.1	Interior light, Radio	10A
2. F7.2	Windscreen washer (front / rear)	5A
3. F7.3	Windscreen wiper (front)	15A
4. F7.4	Windscreen wiper (rear)	15A
5. F7.5	AC Control panel	10A
6. F7.6	Compressor relay, Heating / Water valve	10A
7. F7.7	Radio	7.5A
8. F7.8	12V Socket / USB charging	10A

Alternative 2

The electrical system in the cab has a separate fuse box (1), located in the front part of the cab roof (above the switches (2)).

The figure shows fuse amperage and function.

All fuses are flat pin fuses.

Main fuses

There is one main fuse (2). It is located behind the battery disconnecter, on the right side inside the engine hood.

The fuse is of the flat pin type.




Fig. Engine compartment

1. Fuse, starter relay (40A) (F4.4)
2. Main fuse (50A) (F4.1)
3. Reserve
4. Fuse, preheating relay (80A) (F4.2)
5. Fuse, engine ECU (20A) (F8)
6. Fuse, 12V socket (10A) (F5)

Relays on machine

Control column

- | | | |
|----|-----|-----------------|
| 1. | K9 | Position lights |
| 2. | K10 | Stop lights |




Fig. Relays Control column




Fig. Relays Engine room

Engine room

1	K1	Starting
2	K2	ECU
3	K5	Preheating




Fig. Relays in cab (Alternative 1)

Cab

Alternative 1

The relays are located behind the plate where the fuse box and switches are located.

- To access the relays, the plate must be unscrewed.

1	K23	Recirc / Fresh air
2	K24	Recirc / Fresh air
3	K25	Compressor
4	K30	Cab

Alternative 2

The compressor and main relays are located under the cab roof (4), on the right side of the compressor.

- To access the relays, the roof plate (4) must be unscrewed.
- Remove the 10 screws (3) that secure the cab roof.
- Remove the roof plate (4).
- When reassembling the roof, repeat steps 2 and 3 in reverse order.




Fig. Relays in cab (Alternative 2)
 1. Compressor relay (K25)
 2. Main relay (K30)
 3. Cab roof
 4. Screw (x10)

1	K25	Compressor relay
2	K30	Main relay

Operation

Before starting

Battery disconnecter - Switching on

Remember to carry out daily maintenance.
Refer to the maintenance instructions.

The battery disconnecter is located on the right side of the operator platform. Turn the key (1) to the On position. The roller is now supplied with power.



The engine hood must be unlocked during operation, unless the battery disconnecter is freely accessible from the outside, so that the battery voltage can be quickly disconnected if necessary.




Fig. Battery disconnecter – the machine equipped with ROPS or cab (Alternative 1) 1. Key 2. Door 3. Padlock (* For machine equipped with ROPS only.)




Fig. Battery disconnecter – the machine is equipped with cab (Alternative 2) 1. Key 2. 12V socket 3. Usb charging socket

Operator's seat - Adjusting

Adjust the operator's seat so that the position is comfortable and so that the controls are within easy reach.

The seat can be adjusted lengthways (1).




Fig. Operator's seat
1. Length adjustment

Driver seat (Equipment status) - Adjustment

Adjust the operator's seat so that the position is comfortable and so that the controls are within easy reach.

The seat can be adjusted as follows.

- - Length adjustment (1)
- - Weight adjustment (2)
- - Back support angle (3)




Fig. Driver seat
1. Lock lever - Length adjustment
2. Weight adjustment
3. Back support angle
4. Seat belt



Always make sure that the seat is secure before beginning operation.



Do not forget to use the seat belt (4).

Interlock

The roller is equipped with Interlock.

The diesel engine will switch off after 4 seconds if the operator gets off the seat when going forwards/backwards.

If the control is in neutral when the operator stands up a buzzer will go on until the parking brake is activated.

If the parking brake is activated, the diesel engine will not stop if the forward/reverse lever is moved out of neutral.

The diesel engine will switch off immediately if for any reason the forward/reverse lever is moved out of neutral when the operator is not sitting down and the parking brake has not been activated.



Sit down for all operations!

Parking brake



Ensure that the parking brake (1) is definitely switched on.




Fig. Control panel
1. Parking brake

Brake is always activated in Neutral position.
(automatic 1.5 sec.)

The parking brake must be activated to start the machine!

Operator position

If a ROPS (2) (Roll Over Protective Structure) or a cab is fitted to the roller, always wear the seat belt (1) provided and wear a protective helmet.

- Always use the existing seat belt (1) along with a protective helmet.




Fig. Operator's station

1. Seat belt
2. ROPS structure
3. Rubber element
4. Anti-slip



Replace the seat belt (1) if it shows signs of wear or has been subjected to high levels of force.



Check that rubber elements (3) on the platform are intact. Worn elements will impair comfort.



Ensure that the anti-slip (4) on the platform is in good condition. Replace where anti-slip friction is poor.



If the machine is fitted with a cab, make sure that the door is closed when in motion.

View

Before starting, make sure that the view forwards and backwards is unobstructed.

All cab windows must be kept clean and rear view mirrors (depending on the roller's equipment level) must be kept clean and adjusted for good visibility.




Fig. view



Windscreen washer fluid - Checking and filling

- Place the roller on a level surface.
- If necessary, top up the washer fluid in the reservoir (1) behind the operator's seat.

The reservoir holds 2.1 litres (2.2 qts)




Fig. Operator's platform
1. Windscreen washer reservoir

Instruments and lamps - Checking



Make sure that the emergency stop (29) is pulled out.

- When the roller is in neutral or there is no load on the operator seat, the automatic brake function is engaged.

- Pull out the emergency stop (29).
- Turn the power switch (30) to position 3a.
- Check that the warning lamps in the warning panel (6) illuminate.




Fig. Instrument panel
6. Warning panel
29. Emergency stop
30. Starter switch




Fig. Rear view mirrors

Rear view mirrors - Adjustment

- Rear view mirrors can be adjusted from the ground, on machines equipped with ROPS.
- Use a step ladder if adjusting rear view mirrors on a machine equipped with a cabin.
- The arm of the rear-view mirror has a stop in the maximum extended position. The mirror may then be adjusted for a good rear view.
- The visibility requirement is fulfilled as per standard ISO 14401.
- All rear view mirrors must be clean and adjusted for good backward visibility.

Cab windows - de-icing

- To de-ice the cab windows, stand steadily on the cab step.
- Use a telescopic ice scraper and de-ice the windows as far as you can reach.
- Adjust the seat to the left position for the best view through the de-iced section of the window.
- Turn on the defroster fully, and the remaining part of the windows will be de-iced within a few minutes.

Wiper blade - Replacement

Ensure that the wiper blades are in good condition. Replace the blades when they no longer wipe the cab windows clean.

Use a ladder for easier access for wiper blade replacement.

Working lights - Adjustment

Use a ladder for easier access to adjust the working lights.

Starting

Starting the engine

- Make sure that the emergency stop (28) is pulled out and the parking brake (22) is activated.
- Set the forward/reverse lever (32) in neutral. The engine can only be started when the lever is in neutral.
- Turn the vibration switch (12) to the Off position (position O).
- Set the engine speed control (13) to idling: Low.





Fig. Control panel
12. Vibration switch
13. Engine speed control
22. Parking brake
23. Glow lamp
28. Emergency stop
29. Starter switch
32. Forward/Reverse lever



Preheating:

- Turn the ignition key to position II.
- When the glow lamp (23) goes out, turn the ignition key to position III.
- As soon as the engine has started, release the ignition key.



Do not run the starter motor for too long. If the engine does not start, wait a minute or so before trying again.

- Idle the engine for a few minutes until it is warm, longer if the ambient temperature is below +10 °C (50 °F)
- At temperatures below 0°C (32°F) the diesel engine and hydraulic system should be warmed up for at least 15 minutes.




Fig. Control panel
 25. Charging lamp
 20. Oil pressure lamp
 22. Brake lamp
 23. Glow plug lamp

- Check while warming the engine that the warning lamps for the oil pressure (20) and charging (25) go out.
- The warning lamp (22) should remain on.



When starting and driving a machine that is cold, remember that the hydraulic fluid is also cold and that braking distances can be longer than normal until the machine reaches the working temperature.



Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.

Driving

Operating the roller



Under no circumstances is the machine to be operated from the ground. The operator must be seated inside the machine during all operation.




Fig. Instrument panel
 13. Engine speed control
 28. Emergency stop
 29. Starter switch
 32. Forward/Reverse lever

- Set the speed control (13) in working position: High or Eco.
- Check that the steering is working correctly by turning the steering wheel once to the right and once to the left while the roller is stationary.



Make sure that the area in front of and behind the roller is clear.

- Carefully move the forward/reverse lever (32) forwards or backwards, depending on which direction of travel is required.
- The speed increases as the lever is moved away from the neutral position.



Test the emergency stop by pressing the emergency stop button (28) while the roller is moving slowly forward. Brace yourself for a sudden stop. The engine will be switched off and the brakes activated.

- Check while driving that the warning lamps have not gone on.

Operation of strike-off blade (Equipment status)




Fig. Forward/reverse lever
1. Joystick, strike-off blade



Before driving, make certain that the blade is in its uppermost position (raised). Inspect the condition of the ground before using the blade.

The joystick (1) has five positions.

- Middle - Neutral.
- Back - Lifting of blade.
- Forward - Lowering of blade.
- Tilting - Right/Left (Equipment status)

Lower the blade to the ground before leaving or parking the roller.



Use the blade only when driving FORWARD.

Interlock/Emergency stop/Parking brake - Check



The interlock, emergency stop and parking brake must be checked daily before operating. A function check of the interlock and emergency stop requires a restart.



The interlock function is checked by the operator standing up from the seat when the roller is moving very slowly forwards/backwards. (Check in both directions). Hold the steering wheel firmly and brace yourself for a sudden stop. A buzzer goes on and after 4 seconds the engine switches off and the brakes are activated.



Check the function of the emergency stop by pressing the emergency stop when the roller is moving slowly forwards/backwards. (Check in both directions). Hold the steering wheel firmly and brace yourself for a sudden stop. The engine switches off and the brakes are activated.




Fig. Control panel
7. Control lamp, fatal error
5. Control lamp, parked regen (regeneration)
10. Switch for parked regen (regeneration) of the DPF filter

Regeneration of DPF filter

The machine is equipped with a diesel particle filter (DPF filter).

The diesel engine does an automatic burnout of carbon when necessary and no indication is shown during normal operation.

If the machine is run frequently with partial load, starting and stopping, and at low temperatures etc., a **parked** regeneration may need to be done.

This is indicated by the lamp for **Parked regen (regeneration) requires (Parked Regen Requested)** (5) starts to flash parallel with the switch (10) and the buzzer sounds.

The operator should park the machine at a suitable place and allow the engine to run.

The parking brake should be activated, the machine should be stationary, and the control lever should be in neutral.

The engine should be warm.

To start the parked regeneration, press the switch for **Parked Regen Requested** (10).

This is done by moving up the yellow lock and pressing the switch.

The switch will spring back afterwards.

The speed of the engine increases and the lamp stops flashing but remains on **Parked regen (regeneration) in progress (Parked Regen Requested)** 5.

The regeneration of the DPF filter takes about 20 minutes, after which the engine returns to low speed and the lamp goes off.

When the regeneration is finished and if the machine is going to be used again, disable the parking brake.

The machine can now be used.

If it is not possible to do a parked regeneration, because the place is not suitable or because the working conditions will not permit this, do as follows:

- Drive the roller as soon as possible to a suitable place.
- Park the roller, enable the parking brake and carry out a parked regeneration.



If the yellow flashing indicators on parked regeneration (5, 10) are ignored, error codes will be displayed and the engine power will be reduced. If the indicators continue to be ignored the red control lamp (7) will go on. Switch off the engine immediately, enable the parking brake and contact a service technician at once.



At a voltage below 12.5 volts, the engine revs will automatically be set to 1300 revs to ensure sufficient charging of the battery. This only applies when the parking brake is activated.



Ensure there is space for good ventilation around the machine. Temperatures in the region of 350°C (662°F) can be generated at the exhaust pipe when performing regen (regeneration) of the DPF filter.



The engine hood should be kept closed while the regeneration is in progress.

Vibration

Vibration On/Off

Activation/deactivation of the vibration is selected with the switch (12).

The operator must activate the vibration via the switch (33) on the underside of the forward/reverse handle. See illustration below.




Fig. Instrument panel
12. Vibration switch.

Vibration - Activation



Never activate vibration when the roller is stationary. This can damage both the surface and the machine.

- Engage and disengage vibration using the switch (33) on the underside of the forward/reverse lever.
- Always switch off vibration before the roller comes to a standstill.




Fig. Forward/Reverse lever
33. Switch, vibration On/Off

Vibration

Vibration On/Off



Never activate vibration when the roller is stationary. This can damage both the surface and the machine.

Activation/deactivation of the vibration is selected with the switch (13).

The operator must engage and disengage vibration using the switch (32) on the underside of the forward/reverse lever.

Switch off vibration before the roller comes to a standstill.




Fig. Instrument panel
13. Vibration On/Off




Fig. Forward/reverse lever
32. Vibration On/Off

Braking

Service brake

- Move the forward/reverse lever (32) to the neutral position to stop the roller.
- Always press down the parking brake (16), before leaving the operator platform.
- If the forward/reverse lever is moved quickly (forwards or backwards) toward/past neutral, the system switches to a rapid braking Mode and the machine stops.
- Activate normal driving Mode again by moving the forward/reverse lever back to neutral.




Fig. Operator platform
32. Forward/reverse lever

Braking

Normal braking

- Press the switch (13) to switch off the vibration.
- Move the forward/reverse lever (32) to the neutral position to stop the roller.
- Set the speed control (14) to idling position: Low.
- Set the parking brake switch (16) in the On position.




Fig. Instrument panel
13. Vibration On/Off
14. Engine speed control
16. Parking brake
29. Emergency stop
30. Key
32. Forward/reverse lever



Always use the parking brake (16) when the machine is stationary on a sloping surface.



When starting and driving a machine that is cold, remember that the hydraulic fluid is also cold and that braking distances can be longer than normal until the machine reaches the working temperature.




Fig. Instrument panel
13. Speed control
15. Parking brake
28. Emergency stop

Reserve brake

- Braking is normally activated using the forward/reverse lever. The hydrostatic transmission brakes the roller when the lever is moved towards the neutral position.
- There is also a brake in the drum motor and rear axle that acts as an emergency brake during operation.
- The diesel engine stops and must be restarted.

When reserve braking:

- Engage the parking brake (15).
- Hold the steering wheel firmly and brace yourself for a sudden stop.
- The brakes are applied and the engine stops.

Emergency stop

- The emergency stop is activated by pressing the button (28).
- Hold the steering wheel firmly and brace yourself for a sudden stop.
- The brakes are applied and the engine stops.

After an emergency stop:

- Return the forward/reverse lever (32) to neutral.
- Pull out the emergency stop (28).
- Enable the parking brake (15).
- Set the speed control (13) to Low.
- The roller is equipped with an Interlock and therefore the operator must sit in the seat to start the engine.




Fig. Instrument panel
6. Panel for warning lamps
28. Instrument guard
30. Starter switch

Switching off

- Check instruments and warning lamps to see if any faults are indicated.
- Switch off all lights and other electrical functions.
- Turn the starter switch (30) to the left to switched off position 1.
- At the end of the shift, lower the instrument cover (6) and lock it.

Parking

Chocking the drums




Fig. Arrangement
1. Chock



Never leave the roller when the engine is running without enabling the parking brake.



Make sure that the roller is parked in a safe place with respect to other road users. Chock the drums if the roller is parked on sloping ground.



Remember that there is a risk of freezing during the winter. Fill the diesel engine's cooling system and screenwash container in the cab with anti-freeze.




Before using the roller again, make sure that the engine is switched off and the parking brake is activated. The brake chocks can then be removed.

Batterifrånskiljare - Avstängning

Before leaving the roller for the day, switch the master switch to the disconnected position and remove the key (1).

This prevents the battery from discharging and makes it difficult for unauthorised persons to start and operate the machine.

On a machine fitted with ROPS, the door (2) must also be locked at the end of the working day.



Battery disconnecter – the machine equipped with ROPS or cab (Alternative 1)

- 1. Key
 - 2. Cover
 - 3. Padlock *
- (* For machine equipped with ROPS only.)




Fig. Battery disconnecter– the machine is equipped with cab (Alternative 2)

- 1. Key
- 2. 12V Socket
- 3. Usb charging socket

Long-term parking



The following instructions should be followed when long term parking (more than one month).




Fig. Roller weather protection

These measures apply when parking for a period of up to 6 months.

Before re-commissioning the roller, the points marked with an asterisk * must be returned to the pre-storage state.

Wash the machine and touch up the paint finish to avoid rusting.

Treat exposed parts with anti-rust agent, lubricate the machine thoroughly and apply grease to unpainted surfaces.

Engine

* Refer to the manufacturer's instructions in the engine manual that is supplied with the roller.

Battery

* Remove the battery from the machine, clean, grease the cable connectors (terminals) and trickle charge the battery once a month. The battery is otherwise maintenance free.

Air cleaner, exhaust pipe

* Cover the air cleaner (see under the heading 'Every 50 hours of operation' or 'Every 1000 hours of operation') or its opening with plastic or tape. Also cover the exhaust pipe opening. This is to avoid moisture entering the engine.

Fuel tank

Fill the fuel tank completely full to prevent condensation.

Hydraulic reservoir

Fill the hydraulic reservoir to the uppermost level mark (see under the heading 'Every 10 hours of operation.')

Steering cylinder, hinges, etc.

Grease the steering cylinder piston with conservation grease.

Grease the hinges on the doors to the engine compartment. Grease both ends of the forward/reverse control (bright parts) (see under the heading 'Every 500 hours of operation').

Tires

Check that the tire pressure is:

- CA1300 200 kPa (2.0 kp/cm²) (29 psi).
- CA1400 150 kPa (1.5 kp/cm²) (21.8 psi).

Hoods, tarpaulin

* Lower the instrument cover over the instrument panel.

* Cover the entire roller with a tarpaulin. A gap must be left between the tarpaulin and the ground.

* If possible, store the roller indoors and ideally in a building where the temperature is constant.

Engine coolant

Check that the coolant mix are within recommended levels and have a freezing temperature lower than expected lowest temperature during the storage period.

Miscellaneous

Lifting

Locking the articulation



Articulation must be locked to prevent inadvertent turning before lifting the roller.




Fig. Articulation in the locked position

- 1. Locking arm
- 2. Locking pin
- 3. Locking stud
- 4. Locking lug

Weight: refer to the hoisting plate on the roller




Fig. Roller prepared for lifting
1. Hoisting plate

Lifting the roller



The machine's gross weight is specified on the hoisting plate (1). Refer also to the Technical specifications.



Lifting equipment such as chains, steel wires, straps and lifting hooks must be dimensioned in accordance with the relevant safety regulations for the lifting equipment.



Stand well clear of the hoisted machine! Make sure that the lifting hooks are properly secured.

Unlocking the articulation




Fig. Articulation in the open position

- 1. Locking arm
- 2. Locking pin
- 3. Locking stud
- 4. Locking lug



Remember to unlock the articulation before operating.

- Fold the locking arm (1) back.
- Secure it in the locking lug (4) with the stud (3).
- Insert the locking pin (2) fitted with a wire, to secure the stud (3).
- The locking lug (4) is located on the tractor frame.

Towing

The roller can be moved up to 300 meters (1,000 ft) using the instructions below.

Short distance towing with the diesel engine switched off/not running (CA1300)



Chock the wheels to prevent the roller from moving when the brakes are hydraulically disengaged.



The machine must not be operated at a speed higher than 3 km/h (2 mph) and must not travel further than 300 metres (330 yards). Failure to comply may result in damage to the drive motors.




Fig. Propulsion pump
1. By-pass valve

- Open the hood and make sure that the propulsion pump is accessible.
- On the pump there are two by-pass valves (1), which should be pressed in to set the system in by-pass mode.
- This function enables a machine to be moved without the drive shaft on the propulsion pump rotating.
- The by-pass pistons (1) are automatically reset when the engine is started and the feed pressure builds up.




Fig. Rear axle
1. Brake release screw (2).

Rear axle brake

The two brake release screws (1) are located on the front and back of the rear axle.




Fig. Brake disengagement
1. Brake release screw
2. O-ring
3. Stop washer

Brake disengagement

- Unscrew the brake release screws (1).
- Remove the stop washers (3).
- The screws must not be completely removed, only unscrewed enough to remove the washers.




Fig. Brake disengagement
1. Brake release screw

- Now tighten the brake release screws (1) alternately until they are fully screwed in.
- The brake is now disengaged.



Reset the drum motor brake after towing.

Releasing the drum brake (CA1300)

Drum motor brake

- Remove the drum brake centre plug (2), which is accessible through the centre hole (1) in the left frame side.




Fig. Left frame side
1. Center hole
2. Center plug




Fig. Cross-section of brake housing
3. Bolt
4. Nut
5. Brake piston

- Screw in the bolt (3) all the way as shown in the figure.
- Now screw in the nut (4) so that it is flush with the washer, and then an additional 0,75 - 1 turns.
- Holding the screw in place (3).
- The brakes are now released and the machine can be towed.



Reset the drum motor brake after towing.

Short distance towing with the diesel engine switched off/not running (CA1400)



Chock the wheels to prevent the roller from moving when the brakes are hydraulically disengaged.




Fig. Propulsion pump
1. By-pass valve

- Open the hood and make sure that the propulsion pump is accessible.
- On the pump there are two by-pass valves (1), which should be pressed in to set the system in by-pass mode.
- This function enables a machine to be moved without the drive shaft on the propulsion pump rotating.
- The by-pass valves (1) are automatically reset when the engine is started and the feed pressure builds up.

Brake disengagement pump

The release pump for the brakes is located in the engine compartment, right side.




Fig. Engine compartment, right side
1. Brake disengagement pump




Fig. Engine room
 1. Belt guard
 2. Hand pump
 3. Screw

For roller equipped with AC

To be able to use the hand pump (2), the belt guard for the compressor has to be removed.

- Unscrew the screws (3) and remove the cover (1).




Fig. Brake disengagement pump
 2. Pump arm
 3. Brake release button

For towing:

- Press in the brake release button (3).
- Pump with the arm (2) until the brakes are released.

The roller can now be towed.



After towing, pull the brake release button (3) out to apply the brakes.




If the diesel engine is once again in working order and starts, the brakes are reactivated if the supply pressure is reached.



The machine must not be moved at a speed higher than 3 km/h (2 mph), and no more than 300 meters (330 yards). Otherwise there is a risk of damaging the drives.

Towing



A towing bar must be used when towing, as the roller has no brakes and can only be slowed and stopped by the vehicle towing the roller.



The roller must be towed slowly, max. 3 km/h (2 mph) and for short distances only, max. 300 m (330 yards).




Fig. Towing the roller
1. Drawbar
2. Lifting eye

When towing/retrieving a machine, the towing bars (1) must be connected to both lifting holes (2). Pulling forces must act longitudinally on the machine as illustrated. Maximum total pulling force per lifting hole is 70 kN (15.740 lbf).

Transport

Tie-down and secure the machine according to the Cargo Securing Certificate for the specific machine if this is available and applicable.

If not, tie down and secure the machine according to the cargo securing rules that are valid for the country where the transport takes place.




Never lash over the machine's articulated joint, nor over the machine's operator platform.

Before securing the machine ensure that :

- the parking brake is applied and in good working condition
- the articulated joint is in closed position
- the machine is centered laterally on the platform
- the lashings are in good condition and fulfills the corresponding rules for transport securing.

Securing CA1300 - CA1400

Securing CA1300 - CA1400 vibratory rollers from Dynapac loaded facing forwards on a trailer for road and Baltic Sea transport (Sea area A).



1 - 3 = double lashings, i.e. one lashing with two parts secured to two different lashing mounts, symmetrically located on the right and left sides.

4 = rubber friction pads

The lashings' permitted distance interval in meters		
(1 - 3: Double lashings, LC at least 1.6 tonnes (1 600 daN))		
Double L ₁	Double L ₂	Double L ₃
0.2 - 2.5	0.3 - 2.5	0.1 - 2.5

L₁ - L₃ are the longitudinal distances between the lashing points on the roller and lashing points on the platform.

Load carrier


- Load the roller in the centre of the platform from the sides (± 5 cm) and facing forwards.
- The parking brake is applied and in good working condition.
- The drums are placed on rubber friction pads (4) to achieve the static friction 0.6 between the surfaces.
- The contact surfaces must be clean, wet or dry, and free from frost, ice and snow. If there is a risk of frost, ice and/or snow the platform has to be salted.
- The lashing mounts on the load carrier have MSL/LC/SWL at least 2 tonnes.

Lashings

- The maximum securing load (MSL/LC/SWL) of the lashings (strap or chain) is at least 1.6 tonnes (1,600 daN) and the lashings are well pre-tensioned during the entire transport.
- Each of lashings 1-3 is either one double or two single lashings. The double lashing is the same lashing in a sling through a lashing eye or round a machinery part down in two different lashing points on the platform.
- Lashings in the same direction are placed in different lashing mounts on the trailer. Lashings that are pulled in opposite directions may be placed in the same lashing mount, however.
- The lashings are as short as possible.
- The lashing hooks must not lose grip if the lashings become slack.
- The lashings are protected against sharp edges and corners.
- The lashings are located symmetrically in pairs on the right and left sides.

Securing CA1300 - CA1400

Securing CA1300 - CA1400 vibratory rollers from Dynapac loaded facing forwards on a trailer for road and North Sea transport (Sea area B).



1 - 3 = double lashings, i.e. one lashing with two parts secured to two different lashing mounts, symmetrically located on the right and left sides.

4 = rubber friction pads

The lashings' permitted distance interval in meters		
(1 - 3: Double lashings, LC at least 1.6 tonnes (1 600 daN))		
Double L ₁	Double L ₂	Double L ₃
0.2 - 2.0	0.3 - 2.0	0.1 - 2.0

L₁ - L₃ are the longitudinal distances between the lashing points on the roller and lashing points on the platform.

Load carrier

- Load the roller in the centre of the platform from the sides (± 5 cm) and facing forwards.
- The parking brake is applied and in good working condition.
- The drums are placed on rubber friction pads (4) to achieve the static friction 0.6 between the surfaces.
- The contact surfaces must be clean, wet or dry, and free from frost, ice and snow. If there is a risk of frost, ice and/or snow the platform has to be salted.
- The lashing mounts on the load carrier have MSL/LC/SWL at least 2 tonnes.

Lashings

- The maximum securing load (MSL/LC/SWL) of the lashings (strap or chain) is at least 1.6 tonnes (1,600 daN) and the lashings are well pre-tensioned during the entire transport.
- Each of lashings 1-3 is either one double or two single lashings. The double lashing is the same lashing in a sling through a lashing eye or round a machinery part down in two different lashing points on the platform.
- Lashings in the same direction are placed in different lashing mounts on the trailer. Lashings that are pulled in opposite directions may be placed in the same lashing mount, however.
- The lashings are as short as possible.
- The lashing hooks must not lose grip if the lashings become slack.
- The lashings are protected against sharp edges and corners.
- The lashings are located symmetrically in pairs on the right and left sides.

Operating instructions - Summary



1. **Follow the SAFETY INSTRUCTIONS specified in the Safety Manual.**
2. Make sure that all instructions in the MAINTENANCE section are followed.
3. Turn the battery disconnecter to ON and ensure that the articulated joint lock is open.
4. Move the forward/reverse lever to the NEUTRAL position.
5. Set the vibration switch in position 0.
6. Set the speed control in the idling position (LOW).
7. Set the emergency stop in the pulled out position.
8. Start the engine and allow it to warm up.
9. Set the speed control to the operating position (ECO or HI).



10. **Drive the roller. Operate the forward/reverse lever with care.**



11. **Test the brakes. Remember that the braking distance will be longer if the roller is cold.**

12. Use vibration only when the roller is in motion.



13. **IN AN EMERGENCY:**
 - **Press the emergency stop**
 - **Hold the steering wheel firmly.**
 - **Brace yourself for a sudden stop.**
 - Press the emergency stop
 - Hold the steering wheel firmly
 - Brace yourself for a sudden stop
14. When parking:
 - Press the emergency stop.
 - Chock the drum and wheels.
 - Press the emergency stop
 - Chock the drum and wheels
15. When lifting: - Refer to the relevant section in the Instruction Manual.
16. When towing: - Refer to the relevant section in the Instruction Manual.
17. When transporting: - Refer to the relevant section in the Instruction Manual.

18. When recovering - Refer to the relevant section in the Instruction Manual.

Preventive maintenance

Complete maintenance is necessary for the machine to function satisfactorily and at the lowest possible cost.

The Maintenance section includes the periodic maintenance that must be carried out on the machine.

The recommended maintenance intervals assume that the machine is used in a normal environment and working conditions.

Acceptance and delivery inspection

The machine is tested and adjusted before it leaves the factory.

On arrival, before delivery to the customer, delivery inspection must be conducted as per the check list in the warranty document.

Any transport damage must be reported immediately to the transport company, as this is not covered by the product warranty.

Warranty

The warranty is only valid if the stipulated delivery inspection and the separate service inspection have been completed as per the warranty document, and when the machine has been registered for starting under the warranty.

The warranty is not valid if damage has been caused by inadequate service, incorrect use of the machine, the use of lubricants and hydraulic fluids other than those specified in the manual, or if any other adjustments have been made without the requisite authorization.

Maintenance - Lubricants and symbols



Always use high-quality lubricants and the amounts recommended. Too much grease or oil can cause overheating, resulting in rapid wear.



Other fuel and lubricants are required when operating in areas with extremely high or extremely low ambient temperatures. See the 'Special instructions' chapter, or consult Dynapac.

	ENGINE OIL	Air temperature -15°C - +50°C (5°F-122°F)	Dynapac Engine Oil 200	P/N 4812161855 (5 liters) P/N 4812161856 (20 liters)
	HYDRAULIC FLUID	Air temperature -15°C - +50°C (5°F-104°F)	Dynapac Hydraulic 300	P/N 4812161868 (20 liters) P/N 4812161869 (209 liters)
		Air temperature over +50°C (104°F)	Shell Tellus S2 V100	
	BIOLOGICAL HYDRAULIC FLUID, PANOLIN	When it leaves the factory, the machine may be filled with biologically degradable fluid. The same type of fluid must be used when changing or topping up.	PANOLIN HLP Synth 46 (www.panolin.com)	
	DRUM OIL	Air temp. -15°C - +40°C (5°F-104°F)	Dynapac gear oil 300	P/N 4812161883 (5 liters), P/N 4812161884 (20 liters)
		Air temp. 0°C (32°F) - above +40°C (104°F)	Shell Spirax AX 85W/140, API GL-5	
	GREASE		for the articulation joint.	Dynapac Roller Grease (0.4 kg), P/N 4812030096
			Shell Retinax LX2 for other grease points.	
	FUEL	See engine manual.	-	-
	TRANSMISSION OIL	Air temperature -15°C - +40°C (5°F-104°F)	Dynapac Gear oil 300	P/N 4812161883 (5 liters), P/N 4812161884 (20 liters)
		Air temperature 0°C (32°F) - above +40°C (104°F)	Shell Spirax AX 85W/140, API GL-5	
	COOLANT	Anti-freeze protection down to about -37°C (-34.6°F)	Dynapac Coolant 100 (mixed 50/50 with water)	P/N 4812161854 (20 liters)
	WASHER FLUID	Use alcohol-based windscreen washer fluid with the concentration recommended by the manufacturer for the expected lowest ambient temperature.		
	COMPRESSOR OIL		RFL-100X	
	AC - GAS REFRIGERANT		R134a	

Fluid volumes

Rear axle

• Differential	4.5 liters	4.8 qts
• Planetary gear	0.9 liters/side	0.95 qts/side
• Pinion housing	0.3 liters	0.32 qts

Drum

• Drum (CA1300)	6,5 liters	6.8 qts
• Drum (CA1400)	10.5 liters	11.1 qts

Fluid volumes

- Drum gear (CA1400) 1.1 liters 1.2 qts

Hydraulic reservoir 32.0 liters 8.5 gal

Oil in hydraulic system

- CA1300 42.0 liters 11.1 gal

- CA1400 52.0 liters 13.7 gal

Diesel engine

- Lubricating oil (incl. change of engine oil filters) 11.7 liters 12.3 qts

Coolant

- without cab 16.0 liters 16.9 qts

- with cab 17.4 liters 18.4 qts

AC gas volume 620 gram

Maintenance symbols

	Engine, oil level		Tyre pressure
	Engine, oil filter		Air filter
	Hydraulic reservoir, level		Battery
	Hydraulic fluid, filter		Recycling
	Transmission, oil level		Fuel filter
	Drum, oil level		Coolant, level
	Oil for lubrication		

Maintenance - Maintenance schedule

Service and maintenance points




Fig. Service and maintenance points

- | | | |
|---|--|---|
| 1. Radiator grille | 14. Scraper | 27. Engine suspension, 4 pcs. |
| 2. Oil level, diesel engine | 15. Drum oil, level plug, 1 pc. | 28. Diesel fuel, filler |
| 3. Fuel filter | 16. Rubber elements and fastening screws | 29. Battery |
| 4. Air filter | 17. Steering joint | 30. Radiator |
| 5. Engine cover, hinges | 18. Steering cylinder, 1 pc. | 31. Drive belt, alternator |
| 6. Hydraulic reservoir, sight glass | 19. Flywheel casing, hydraulic pumps | 32. Forward/reverse lever |
| 7. Bleeding filter | 20. Wheel nuts | 33. Oil separator, diesel engine (CA1400) |
| 8. Hydraulic filter, 1 pcs. | 21. Tires, pressure | 34. Cab |
| 9. Drainage, hydraulic fluid reservoir | 22. Rear axle, differential and pinion housing | 35. Cab, air filter |
| 10. Hydraulic fluid, filling | 23. Rear axle, planetary gears, 2 pcs. | |
| 11. Fuse box | 24. Rear axle suspension, 2 sides | |
| 12. Drum oil, filling | 25. Oil filter, diesel engine | |
| 13. Drum motor (CA1300)
Drum gear (CA1400) | 26. Cleaning, fuel tank | |

General

Periodic maintenance should be carried out after the number of hours specified. Use the daily, weekly etc. periods where number of hours cannot be used.



Remove all dirt before filling, when checking oils and fuel and when lubricating using oil or grease.



The manufacturer's instructions found in the engine manual also apply.

Specific maintenance and checks on diesel engines must be carried out by the engine supplier's certified personnel.

Every 10 hours of operation (Daily)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
	Before starting up for the first time on that day	
14	Check scraper setting	
1	Check for free circulation of cooling air	
30	Check coolant level	
	Checking and filling the windscreen washer fluid	
2	Check the engine oil level	Refer to the engine manual
28	Refuel	
6	Check fluid level in hydraulic reservoir	
	Check the drive belt	Refer to the Instruction manual for the engine
4	Check air cleaner	Replace if necessary
	Check hoses and connections for leaks	
	Test the brakes	

After the FIRST 50 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
8	Change the hydraulic fluid filter	
20	Check the wheel-nuts are tightened	
21	Check the tire pressure	
13	Change the oil in the drum gearbox	CA1400
3	Replace fuel filter	See also engine manual
25	Change diesel engine lubricating oil and oil filter	See also engine manual

Every 50 hours of operation (Weekly)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
3	Draining the fuel prefilter	Performed if the control lamp for the water separator lights on the instrument panel.

Every 250 / 750 / 1250 / 1750 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
23	Check oil level in rear axle/planetary gearing	
22	Check the oil level in the rear axle pinion housing	
15	Check the oil level in the drum	
	Check the oil level in the drum gear box	CA1400 only
30	Clean coolers	
	Adjust the engine drive belt	Refer to the engine manual
	Check the air intake hoses	
16	Check rubber elements and bolted joints	

Every 500 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
23	Check oil level in rear axle/planetary gearing	
22	Check oil level in the rear axle pinion housing	
15	Check oil level in the drum	
30	Clean coolers	
16	Check rubber elements and bolted joints	
29	Check battery	
3	Replace fuel filter	Refer to the engine manual
25	Change the engine oil and oil filter	Refer to the engine manual
31	Adjust the belt tension for the drive system	Refer to the engine manual
	Replace the belt for the drive system	Refer to the engine manual
32	Lubricate controls and joints	
7	Check air cleaner on hydraulic reservoir	
	Lubrication of the hinges on the cab	
29	Check battery	
	Replace cab air filter	
	Check and adjust compressor belt	

Every 1000 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
15	Check oil level in the drum	
13	Change oil in the drum gear	CA1400
30	Check coolers	
	Replace the belt for the drive system	Refer to the engine manual
	Valve adjustment, engine	Refer to the engine manual
16	Check rubber elements and bolted joints	
29	Check battery	
3	Replace fuel filter	Also refer to the engine manual
32	Lubricate controls and joints	
25	Change the engine oil and oil filter	Also refer to the engine manual
7	Check air cleaner on hydraulic reservoir	
31	Check the belt tension for the drive system	Refer to the engine manual
8	Change hydraulic fluid filter	
9	Drain the condensate from hydraulic reservoir	
26	Drain condensate from fuel tank	
22	Change oil in rear axle differential	
22	Change the oil in the rear axle pinion housing	
23	Change oil in the rear axle planetary gearing	
	Check and adjust compressor belt	

Every 1500 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
23	Check oil level in rear axle/planetary gearing	
22	Check oil level in the rear axle pinion housing	
15	Check the oil level in the drum	
30	Clean coolers	
	Cleaning the water separator	
16	Check rubber elements and bolted joints	
29	Check battery	
3	Replace fuel filter	Also refer to the engine manual
32	Lubricate controls and joints	
25	Change the engine oil and oil filter	Also refer to the engine manual
7	Check air cleaner on hydraulic reservoir	
31	Adjust the belt tension for the drive system	Refer to the engine manual
31	Replace the belt for the drive system	Refer to the engine manual
33	Change oil separator element	Also refer to the engine manual
	Check and adjust compressor belt	

Every 2000 hours of operation

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
30	Clean coolers	
20, 24	Check bolted joints	The above applies to new or reconditioned components only
16	Check rubber elements and bolted joints	
29	Check battery	
3	Replace fuel filter	See also engine manual
32	Lubricate controls and joints	
25	Change the engine oil and oil filter	See also engine manual
7	Check air cleaner on hydraulic reservoir	
31	Check the belt tension for the drive system	Refer to the engine manual
	Change the belt for the drive system	Refer to the engine manual
8	Change hydraulic oil filter	
9	Drain the condensate from hydraulic reservoir	
26	Drain the condensate from fuel tank	
22	Change oil in rear axle differential	
22	Change oil in the rear axle pinion housing	
23	Change oil in the rear axle planetary gearing	
9	Change the hydraulic fluid	
12	Change the oil in the drum	
13	Change oil in drum gear	CA1400 only
17	Check the steering joint	
	Check and adjust compressor belt	

Maintenance - Maintenance schedule

Every 12th month (Annually)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
4	Replacing the air filters (main and backup filter)	
	Check the DPF pipes and connections	Contact your local Kubota representative
	Check the EGR pipes and connections	Contact your local Kubota representative
	Check the manifold	Contact your local Kubota representative

Every 24th month (Every other year)

Refer to the contents to find the page number of the sections referred to !

Pos. in fig	Action	Comment
3	Replacing the coolant	
3	Checking cooler hoses and hose clamps	Replace when necessary
	Checking air intake hoses and hose clamps	Replace when necessary

Service - Checklist

Pos	Action	After the first 50 hours of operation (Daily)	Every 10 hours of operation (Daily)	Every 50 hours of operation (Weekly)	Every 250 hours of operation	Every 500 hours of operation	Every 750 hours of operation	Every 1000 hours of operation	Every 1250 hours of operation	Every 1500 hours of operation	Every 1750 hours of operation	Every 2000 hours of operation	Every 2500 hours of operation	Every 2800 hours of operation	NOTE
14	Check scraper setting														
1	Check for free circulation of cooling air														
30	Check coolant level														
	Checking and filling the windshield washer fluid														
2	Check the engine oil level														Refer to the engine manual
28	Refuel														
6	Check fluid level in hydraulic reservoir														
	Check the drive belt														Refer to the instruction manual for the engine
4	Check air cleaner														Replace if necessary
	Check hoses and connections for leaks														
	Test the brakes														
8	Change the hydraulic fluid filter														
20	Check the wheel-nuts are tightened														
21	Check the tire pressure														
13	Change the oil in the drum gearbox														
3	Replace fuel filter														See also engine manual
25	Change diesel engine lubricating oil and oil filter														See also engine manual
3	Draining the fuel prefilter														See also engine manual
23	Check oil level in rear axle/planetary gearing														Performed if the control lamp for the water separator lights on the instrument panel.
22	Check the oil level in the rear axle pinion housing														
15	Check the oil level in the drum														
	Check the oil level in the drum gear box														
30	Clean coolers														See also engine manual
	Adjust the engine drive belt														See also engine manual
	Check the air intake hoses														Refer to the engine manual
16	Check rubber elements and bolted joints														
29	Check battery														
31	Check / Adjust the belt tension for the drive system														Refer to the engine manual
	Replace the belt for the drive system														Refer to the engine manual
32	Lubricate controls and joints														
7	Check air cleaner on hydraulic reservoir														
	Lubrication of the hinges on the cab														
	Replace cab air filter														
	Check and adjust compressor belt														
	Valve adjustment, engine														
9	Drain the condensate from hydraulic reservoir														
26	Drain condensate from fuel tank														
22	Change oil in rear axle differential														
22	Change the oil in the rear axle pinion housing														
22	Change oil in the rear axle planetary gearing														
	Cleaning the water separator														
31	Adjust the belt tension for the drive system														Refer to the engine manual
33	Change oil separator element														Refer to the engine manual
20/24	Check bolted joints														The above applies to new or reconditioned components only
9	Change the hydraulic fluid														
12	Change the oil in the drum														
17	Check the steering joint														
4	Replacing the air filters (main and backup filter)														Replace when necessary
	Check the DPF pipes and connections														Contact your local Kubota representative
	Check the EGR pipes and connections														Contact your local Kubota representative
	Check the manifold														
3	Replacing the coolant														Replace when necessary
3	Checking cooler hoses and hose clamps														Replace when necessary
	Checking air intake hoses and hose clamps														Replace when necessary

Maintenance - Every 10h

Every 10 hours of operation (Daily)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***

Scrapers - Check, adjustment



It is important to consider movement of the drum when the machine turns, i.e., the scrapers can be damaged or wear of the drum may increase if adjustment is made closer than the values stated.

If necessary, adjust distance to the drum as follows:

CA1300 D

- Undo:

- the screws (2)
- the washers (3)
- the nuts (4) on the scraper bracket.

Adjust the scraper blade (1).

- Tighten:

- The screws (2)
- The washers (3)
- The nuts (4) on the scraper bracket.




Fig. Scraper (CA1300 D)

1. Scraper blade
2. Screw
3. Washer
4. Nut
5. Scraper bracket

CA1400 D

- Loosen the screws (2) on the scraper attachment.
- Then adjust the scraper blade (1) to 25 mm (1 in) from the drum.
- Tighten the screws (2).
- Repeat the procedure for the other scraper blades (x4).




Fig. Scraper (CA1400 D)

1. Scraper blade (4)
2. Screws

Scrapers, Pad-drum

CA1300 PD

- Undo:

- The screws (2)
- The washers (3)
- The nuts (4) from the scraper bracket (5)

Adjust the scraper blade to 25 mm (1.0 in) and centre each scraper tooth (1) between the pads when fitting.

- Tighten:

- The screws (2)
- The washers (3)
- The nuts (4) on the scraper bracket (5)




Fig. Scraper (CA1300 PD)
1. Scraper tooth
2. Screw
3. Washer
4. Nut
5. Scraper bracket

CA1400 PD

- Undo the screws (1)
- Adjust each scraper tooth (2) to 25 mm (1.0 in) between scraper tooth and drum.
- Center each scraper tooth (2) between the pads.
- Tighten the screws (1).




Fig. Scraper (CA1400 PD)
1. Screws
2. Scraper teeth (18 pcs)




Fig. Engine hood
1. Hood lock
2. Protective grille

Air circulation - Check

- Ensure that the engine has free circulation of cooling air through the protective grille (2) in the hood.
- To open the engine hood, turn the locking arm (1) upward.
- Raise the hood to its fully open position.
- checking that the red safety catch on the right gas spring is latched.



If the gas-spring for the hood is disengaged and the hood is raised to its upper position - block the hood so that it cannot fall.


**Coolant level - Check**

Fig. Coolant tank
1. Max. level
2. Min. level
3. Filler cap

- Place the roller on a level surface.
- Check that level of the coolant is between the max. and min. marks.



Observe great caution if the radiator cap has to be opened while the engine is hot.
Use the following protective equipment:



Protective gloves



Safety glasses

When refilling:

- Fill with a mixture of 50% water and 50% anti freeze.
- See the lubrication specification in these instructions and in the engine manual.



Water quality is important for the performance of the coolant. A soft, distilled or demineralized water should be used for mixing with the coolant.



Never mix coolants with an extended service life with green coolants.



Never mix coolants of different types and/or colors that have a long service life.



Flush the system every other year and change the coolant. Make sure also that the air flow through the cooler is unobstructed.



Fuel tank - Filling




Fig. Filling with fuel
1. Filler pipe

- Refuel daily
- The fuel is filled up to the lower edge of the filler pipe (1).
- Follow the engine manufacturer's specification with regard to the quality of diesel fuel.



- Stop the diesel engine.

- **Short-circuit (press) the filler gun against a non-insulated part of the roller before filling, and against the filler pipe (1) while filling.**



- Never refuel while the engine is running.

- **Do not smoke and avoid spilling fuel.**

The tank holds 117 liters (31.7 gal) of fuel.



Hydraulic reservoir - Check fluid level




Fig. Sight glass hydraulic reservoir
1. Sight glass

The sight glass is located on the hydraulic tank in the engine compartment. It is accessible and visible from the right side of the roller.

- Place the roller on a flat surface and check the fluid level in the sight glass.
- If the level is too low, top up with the type of hydraulic fluid specified in the lubricant specification.

Air filter indicator - Resetting

The air filter indicator is located on the filter, or in its immediate vicinity.

The air filter indicator must be reset after replacing the air filter.

Press the "button" (1) on the top of the indicator to reset.




Fig. Indicator
1. Button




Fig. Operator's platform
1. Windscreen washer reservoir

Windscreen washer fluid - Checking and filling

- Place the roller on a level surface.
- If necessary, top up the washer fluid in the reservoir (1) behind the operator's seat.

The reservoir holds 2.1 litres (2.2 qts)



Air cleaner Check - Replacement of main filter



Replace the air cleaner's main filter when the indicator shows red. The indicator is mounted on the air cleaner's connecting pipe.



Diesel engine Check oil level



Take care not to touch any hot parts of the engine or the radiator when removing the dipstick.
Risk for burns.




Fig. Engine compartment
1. Dipstick

The dipstick is located on the right side of the engine.

- Pull up the dipstick (1)
- Check that the oil level is between the upper and lower marks.
- For further details, refer to the engine's instruction manual.




Fig. Air cleaner
 1. Clips
 2. Cover
 3. Main filter
 4. Backup filter
 5. Filter housing
 6. Dust valve

Release the clips (1), pull off the cover (2), and pull out the main filter (3).

Do not remove the backup filter (4).

Clean the air cleaner if necessary.
 See section Air cleaner - Cleaning.

When replacing the main filter (3), insert a new filter and refit the air cleaner in the reverse order.

Check the condition of the dust valve (6).
 Replace if necessary.

When refitting the cover, make sure that the dust valve is positioned downwards.



Air cleaner

- Check hoses and connections



Check that the hose clamps between the filter housing and the suction hose are tight and that the hoses are intact. Inspect the entire hose system, all the way to the engine.

Replace if necessary, as damage to hoses/hose clamps can seriously damage the engine



Backup filter - Change

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary.
 See section Air cleaner - Cleaning.





Fig. Air filter
 1. Backup filter


**Air cleaner
- Cleaning**

Wipe clean the inside of the cover (2) and the filter housing (5). See the previous illustration.

Wipe clean on both sides
of the outlet pipe.



Inner edge of
outlet pipe.



Outer edge of outlet
pipe.

Wipe also both surfaces for the outlet pipe.
See adjacent figure.



Check that the hose clamps between the filter housing and the suction hose are tight and that the hoses are intact. Inspect the entire hose system, all the way to the engine.

**Brakes - Check**

Check operation of the brakes as follows:

- Drive the roller slowly forward.
- Hold the steering wheel firmly and brace yourself for a sudden stop.

Control of Emergency Stop

- Press the emergency stop (1).
The roller will stop abruptly and the engine will be switched off.
- After testing the brakes, set the forward/reverse lever in neutral.
- Pull out the emergency stop (1). Start the engine.

Checking the parking brake

- Enable the parking brake (1).
The roller should stop immediately with the engine running.
- After testing the brakes, set the forward/reverse lever in neutral.
- Reset the parking brake (3).
- The roller is now ready for operation.

Refer also to the section in the manual on operation.




Fig. Instrument panel
1. Emergency stop
2. Parking brake lamp

Maintenance, first 50h



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***



Hydraulic filter - Replacement




Fig. Hydraulic reservoir
1. Filler cap/Breather filter

- Release the filler cap/breather filter (1) so that any overpressure inside the reservoir is eliminated.
- Check that the breather filter (1) is not clogged. Air should be able to pass freely through the cap in both directions.

If passage in either direction is blocked:

- Clean the filter with a little diesel oil.
- Blow through with compressed air until the block is removed,
or replace the cap with a new one.



***When working with compressed air.
Use the following protective equipment:***



Safety glasses

- Carefully clean round the filter.




Fig. Hydraulic oil filter (x1)



Remove the oil filter (1) and hand in to an environment-friendly waste disposal station. This is a disposable filter and cannot be cleaned.



Make sure that the old sealing ring is not left on the filter holder. Otherwise, this could cause leakage between the new and old seal.

- Thoroughly clean the sealing surfaces on the filter holder.
- Apply a thin coat of fresh hydraulic fluid to the seals on the new filter.
- Screw tight the filter by hand.



- First tighten the filter until its seal is in contact with the filter attachment.
- Then turn an additional half revolution.
- Do not tighten the filter too hard as this could damage the gasket..

- Start the engine and check that there is no leakage of hydraulic fluid from the filter.
- Check the fluid level in the sight glass and top up if necessary.



Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.


**Tires - Air pressure - Wheel nuts - Tightening**

Fig. Wheels
1. Air valve
2. Wheel nuts

- Check the tire pressures using a pressure gauge.
- If the tires are filled with fluid, the air valve (1) must be in the "12 o'clock" position during pumping.
- Recommended pressure:
See Technical Specifications.
- Check the tire pressure.



When changing the tires it is important that both of them have the same rolling radius. This is necessary to ensure proper functioning of the limited slip differential in the rear axle.

- Check the tightening torque on the wheel nuts (2) with 253 Nm (26 kpm).
- Check both wheels and all nuts. (This only applies to a new machine or newly fitted wheels).



Check the safety manual that accompanies the roller before filling the tires with air.



Drum gear (CA1400)

Oil change

- Place the roller on a level surface.
- Move the machine so the drain/ventilating plugs are in location for drain.
- Wipe clean, unscrew the plugs (2, 3) and drain the oil into a suitable receptacle, capacity about 2 liters (0.5 gal.).




Fig. Oil change - drum gear
1. Drum gear




Fig. Drum gear

Oil filling

- Move the machine until the inspection (2) / filling holes (3) are in position for filling.
- Refill with new transmission oil according to the lubricant specification.
- Ensure that the oil level reaches up to the lower edge of the plug hole (3).
- Clean and refit the plugs.

**Diesel engine - Oil- and Filter change**


**Take great care when draining warm fluid and oil.
Wear following protective equipment:**




Protective goggles



Protective gloves



**Fig. Right side of engine
1. Drain plug**



**Fig. Engine compartment
2. Oil filter**

The oil plug (1) is most easily accessible from the underside of the engine, and is fitted with a hose on the tractor frame.

- Place a receptacle that holds 15 liters (4 gal) under the drain plug.
- Release the hose from its attachment and pull it forward to the tie-down hole.
- Loosen the drain plug (1) and drain the oil, when the engine is warm.
- Tappa av oljan, när motorn är varm.
- Screw back the plug again and refit the hose in its attachment.
- Change the engine oil filter (2) at the same time. Refer also to the Instruction Manual for the engine.



Hand in the drained oil and filter to an environment-friendly waste disposal station.



The engine fuel filter - replacement/cleaning



Place a container underneath to collect fuel that runs out when the filter is released.

- Screw off the fuel filter (1).
- Hand in to environment-friendly station.
The filter is of the disposable type and cannot be cleaned.



Refer to the engine manual for detailed instructions when replacing the fuel filter.

- Unscrew the lower part of the fuel prefilter (2).
- Drain off any water, and then replace the filter unit.
- Start the engine and check that the fuel filters are tight.

N.B. Under no circumstances may new fuel filters be pre-filled with fuel before assembly due to the demands on the cleanliness of the fuel system. Use the hand pump on the fuel prefilter to fill from the machine's fuel system.




Fig. Engine compartment
1. Fuel filter
2. Fuel prefilter

Maintenance - Every 50h

Every 50 hours of operation (Every week)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***


**Pre-fuel filter - Draining**

Fig. Pre-fuel filter
1. Drain plug
2. Hand pump

- Unscrew the drain plug (1) at the bottom of the fuel prefilter.
- With the aid of the secondary hand-operated pump, make certain that all sediment comes out.
- Tighten the drain plug as soon as uncontaminated fuel runs out.

Maintenance - Every 250h

Every 250/750/1250/1750..... hours of operation
(every 3 months)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***

**Rear axle differential and pinion housing-
Check oil level**

***Never work under the roller when
the engine is running.
Park on a level surface.
Block the wheels securely.***

- Wipe clean and remove the level plug (1) and/or (2).
- Check that the oil level reaches the lower edge of the plug hole.
- Top off with transmission oil to the right level if the level is low.
According to the lubricant specification.
- Clean and refit the plug.




Fig. Level check – differential housing
1. Level/Filler plug




Fig. Level check – Pinion housing
2. Level/Filler plug



Rear axle planetary gears - Check oil level




Fig. Level check - planetary gear
 1. Level/Filler plug

- Position the roller with the plug in the planetary gear (1) in the "9 o'clock" position.
- Wipe clean and remove the level plug (1).
- Check that the oil level reaches the lower edge of the plug hole.
- Top off with transmission oil to the right level if the level is low.
 Use oil according to the lubricant specification.
- Clean and refit the plug.
- Check the fluid level in the same way on the rear axle's other planetary gear.



Drum - Checking the oil level (CA1300)




Fig. Drum, left side
 1. Groove
 2. Filler plug
 3. Drain plug/Magnetic plug
 4. Level plug

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.
- Release the level plug (4) and unscrew until oil starts to run out through the plug hole.
- If necessary, release the filler plug (2) and fill with oil until it starts to run out through the level plug (4) hole.
- Clean and screw in the level plug (4).
- Clean and refit the filler plug (2).
- See the lubrication specification for the correct oil grade.

When refilling is needed:

- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk for overheating.



Be sure to use only
 Dynapac gear oil 300 in the roller.




Fig. Roller, left side
1. Filler plug
2. Drain/Magnetic plug
3. Level plug

When refilling is needed:

- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk of overheating.



Be sure to use only
Dynapac gear oil 300 in the roller.



Drum - Checking the oil level (CA1400)

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.




Fig. Left drum side
1. Groove




Fig. Right drum side
2. Filler plug
3. Sight glass

When refilling is needed:

- Release the filler plug (2) and fill up.
- Clean and refit filler plug (2).



Do not overfill with oil - risk for overheating.



Be sure to use only
 Dynapac gear oil 300 in the roller.




Fig. Checking the oil level
- Drum gearbox
1. Drum gearbox

Drum gearbox - Checking the oil level (CA1400)

- Move the machine until the level/filling holes are in position for check/filling.




Fig. Drum gear

- Clean the area around the level plug (2) and loosen the plug.
- Ensure that the oil level reaches up to the lower edge of the plug hole.
- At low oil level fill transmission oil through the filler hole (3) up to the right level.
See lubricant specification.
- Clean and refit the plugs.




Fig. Engine compartment
1. Water cooler
2. Hydraulic fluid cooler

Coolers Checking - Cleaning

- Make sure that the air flow through the coolers (1) and (2) is unobstructed.
- Dirty coolers are blown clean with compressed air or washed clean using a high-pressure water cleaner.
- Blow air or direct water through the cooler in the opposite direction to that of the cooling air.



Take care when using a high-pressure water jet.
Do not hold the nozzle too near the cooler.



When working with compressed air or a high-pressure washer.

Use the following protective equipment:



Safety glasses



Protective gloves

Ear protectors

Replacing belts/Checking the belt tension



Exercise care to stop the engine and remove the key before checking the belt tension.




Fig. Diesel engine

- 1. Belt
- 2. Bolt and nut
- 3. Deflection

To check the belt tension:

- Apply a moderate pressure with your thumb on the belt (between the belt pulleys on the alternator and crankshaft).

The deflection (3) should be:

- A : between 8 and 12 mm (0.31 to 0.47 in.)
- B : between 5 and 8 mm (0.20 to 0.31 in.)
- C : between 7 and 11 mm (0.28 to 0.43 in.)

If the belt tension is not sufficient:

- Loosen the fastening bolts (2) that hold the alternator in place.
- Use a prybar/lever and place it between the alternator and engine block.
- Push the alternator outwards to achieve the required belt tension.
- Tighten the bolts (2) holding the alternator with the correct torque.



If the belt is loose or damaged, it may result in insufficient charging. Adjust or replace the belt.

Rubber elements and fastening screws - Check

- Check all rubber elements (1).
- Replace all of the elements if more than 25% of them on one side of the drum are cracked deeper than 10-15 mm (0.4-0.6 in.).
- Check using a knife blade or pointed object.
- Check also that the screw fasteners (2) are tightened.




Fig. Drum, drive side

- 1. Rubber element
- 2. Attachment screws




Fig. Engine suspension
1. Bolted joint

Bolted joints - Checking tightening torque

- Check that all the bolts for the suspension of the engine and the drive unit are tightened. See under Specifications - tightening torque.
- Check the bolted joint between the motor and the pump drive, and that all the hydraulic components are tightened to the set tightening torque.

(The above applies to new or replaced components only).

Maintenance - Every 500h

Every 500/1500..... hours of operation
(every six months)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***

**Battery - Check condition**

The batteries are sealed and maintenance-free.



***Make sure there is no open flame in the vicinity
when checking the electrolyte level. Explosive gas
is formed when the alternator charges the battery.***



**When disconnecting the battery, always
disconnect the negative cable first. When
connecting the battery, always connect the
positive cable first.**

- The cable shoes should be clean and tightened.
- Corroded cable shoes should be cleaned and greased with acid-proof Vaseline.
- Wipe the top of the battery.




Fig. Battery



Rear axle differential and pinion housing- Check oil level



***Never work under the roller when the engine is running.
Park on a level surface.
Block the wheels securely.***

- Wipe clean and remove the level plug (1) and/or (2).
- Check that the oil level reaches the lower edge of the plug hole.
- Top off with transmission oil to the right level if the level is low.
According to the lubricant specification.
- Clean and refit the plug.




Fig. Level check – differential housing
1. Level/Filler plug




Fig. Level check – Pinion housing
2. Level/Filler plug



Rear axle planetary gears - Check oil level




Fig. Level check - planetary gear
1. Level/Filler plug

- Position the roller with the plug in the planetary gear (1) in the "9 o'clock" position.
- Wipe clean and remove the level plug (1).
- Top off with transmission oil to the right level if the level is low.
According to the lubricant specification.
- Check that the oil level reaches the lower edge of the plug hole.
- Clean and refit the plug.
- Check the fluid level in the same way on the rear axle's other planetary gear.



Drum - Checking the oil level (CA1300)




Fig. Drum, left side
1. Groove
2. Filler plug
3. Drain plug/Magnetic plug
4. Level plug

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.
- Release the level plug (4) and unscrew until oil starts to run out through the plug hole.
- If necessary, release the filler plug (2) and fill with oil until it starts to run out through the level plug (4) hole.
- Clean and screw in the level plug (4).
- Clean and refit the filler plug (2).
- See the lubrication specification for the correct oil grade.

When refilling is needed:


- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk for overheating.



Be sure to use only
Dynapac gear oil 300 in the roller.

**When refilling is needed:**

- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk of overheating.



Be sure to use only
Dynapac gear oil 300 in the roller.

Fig. Roller, left side
1. Filler plug
2. Drain/Magnetic plug
3. Level plug

**Drum - Checking the oil level (CA1400)**

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.




Fig. Left drum side
1. Groove




Fig. Right drum side
2. Filler plug
3. Sight glass

When refilling is needed:

- Release the filler plug (2) and fill up.
- Clean and refit filler plug (2).



Do not overfill with oil - risk for overheating.



Be sure to use only
Dynapac gear oil 300 in the roller.



Coolers Checking - Cleaning

- Make sure that the air flow through the coolers (1) and (2) is unobstructed.
- Dirty coolers are blown clean with compressed air or washed clean using a high-pressure water cleaner.
- Blow air or direct water through the cooler in the opposite direction to that of the cooling air.



Take care when using a high-pressure water jet. Do not hold the nozzle too near the cooler.



When working with compressed air or a high-pressure washer. Use the following protective equipment:



Safety glasses



Protective gloves

Ear protectors




Fig. Engine compartment
 1. Water cooler
 2. Hydraulic fluid cooler




Fig. Drum, drive side
 1. Rubber element
 2. Attachment screws

Rubber elements and fastening screws - Check

- Check all rubber elements (1).
- Replace all of the elements if more than 25% of them on one side of the drum are cracked deeper than 10-15 mm (0.4-0.6 in).
- Check using a knife blade or pointed object.
- Check also that the screw fasteners (2) are tightened.




Fig. Engine compartment
1. Fuel filter
2. Fuel prefilter

The engine fuel filter - replacement/cleaning



Place a container underneath to collect fuel that runs out when the filter is released.

- Screw off the fuel filter (1).
- Hand in to environment-friendly station.
The filter is of the disposable type and cannot be cleaned.



Refer to the engine manual for detailed instructions when replacing the fuel filter.

- Unscrew the lower part of the fuel prefilter (2).
- Drain off any water, and then replace the filter unit.
- Start the engine and check that the fuel filters are tight.

N.B. Under no circumstances may new fuel filters be pre-filled with fuel before assembly due to the demands on the cleanliness of the fuel system. Use the hand pump on the fuel prefilter to fill from the machine's fuel system.



Diesel engine - Oil- and Filter change



Take great care when draining warm fluid and oil.
Use following protection equipment:



Protective goggles



Protective gloves




Fig. Right side of engine
1. Drain plug

The oil plug (1) is most easily accessible from the underside of the engine, and is fitted with a hose on the tractor frame.

- Place a receptacle that holds 15 liters (4 gal) under the drain plug.
- Release the hose from its attachment and pull it forward to the tie-down hole.
- Loosen the drain plug (1) and drain the oil, when the engine is warm.
- Screw back the plug again and refit the hose in its attachment.
- Change the engine oil filter (2) at the same time. Refer also to the Instruction Manual for the engine.




Fig. Engine compartment
2. Oil filter



Hand in the drained oil and filter to an environment-friendly waste disposal station.



Forward/Reverse controls and joints - Check and lubrication

Accessing the machine fitted with ROPS

The easiest way to access the forward/reverse lever pivot points is via the operator's manual pocket on the right-hand side of the driver's seat.




Fig. Forward/reverse lever




Fig. Forward/reverse lever, Cab
1. Forward/Reverse lever
2. Plate
3. Screw

Access on machine with cab

- The forward/reverse lever pivot points are accessed by removing four screws (3) on the plate (2) under the forward/reverse lever (1).
- Check friction of the forward/reverse lever. The friction screws must be sufficiently tightened to retain the forward/reverse lever in the position set during operation. The "0" position of the controls is determined by a screw that engages in the groove on the shaft between the controls.

If the lever begins to become stiff after prolonged used.

- Lubricate the lever at the control cable with a few drops of oil at each point.

If the forward/reverse lever still is stiff after the above adjustments:

- Lubricate the other end of the control cable with a few drops of oil.

The cable is located on the top of the propulsion pump.




Fig. Engine compartment
1. Forward/Reverse-control cable
2. Propulsion pump



Replacing the diesel engine's oil separator filter

(applies to 1500h)

N.B. The engine must be switched off when changing the filter.

- Loosen the filter's bottom cover (2) and remove the filter insert and O-ring (3).



Remove the filter insert (3) and hand in to a waste disposal station.
This is a disposable filter and cannot be cleaned.

- Wipe out any deposits in the bottom cover (2) and filter housing (4).
- Fit the new filter insert with O-ring (3) and
- Refit the bottom cover (2).
- Start the diesel engine and allow it to run at full revs for 30 seconds.
- Check that the filter cap (2) is tight.




Fig. Engine compartment
1. Oil separator filter




Fig. Oil separator filter
2. Cover
3. Filter insert and O-ring
4. Filter housing



Lubrication, hinges

Cab

- Lubricate the hinges (2) on the cab doors with grease. See lubricant specification.




Fig. Cab
2. Hinge, cab




Fig. Engine hood
1. Hood hinge

Hood

- Lubricate the engine hood hinges (1) and the driver's seat slide rails with grease.
- Other pivot points and controls are lubricated with oil.



Air conditioning (Optional) Fresh air filter - Change



Use a step ladder to reach the filter (1). The filter can also be accessed via the right cab window.

There is a fresh air filter (1), located at the front of the cab.

It may be necessary to change the filter more often if the machine is working in a dusty environment.




Fig. Cab 1
 1. Fresh air filter (x 1)
 2. Screws (x 8)

Cab option 1

- Loosen the eight screws (2) and remove the protective cover.
- Remove the air filter element (1) and replace with a new.

Cab option 2

- Loosen the screw (2) and remove the filter housing (3).
- Remove the air filter element (1) from the filter housing (3) and replace it with a new filter element.




Fig. Cab 2
 1. Fresh air filter (x1)
 2. Filter housing (x1)
 3. Screw (x1)

**Air cleaner****Check - Replacement of main filter**

Replace the air cleaner's main filter when the indicator shows red. The indicator is mounted on the air cleaner's connecting pipe.

Air filter indicator - Resetting

The air filter indicator is located on the filter, or in its immediate vicinity.

The air filter indicator must be reset after replacing the air filter.

Press the "button" (1) on the top of the indicator to reset.




Fig. Indicator
1. Button

**Backup filter - Change**

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary.
See section Air cleaner - Cleaning.




Fig. Air filter
1. Backup filter




Fig. Condenser
 1. Condenser element
 2. Brackets (4 pcs)
 3. Screws (4 pcs)
 4. Washers (4 pcs)

Air conditioning (Optional) - Check

- If cooling capacity is noticeably impaired, clean the condenser element (1) located in front of the radiator in the engine compartment (see Radiator, Check - Cleaning).
- Also clean the cooling unit in the cab. See under the heading 2000 hours, air conditioning - overhaul.




Fig. Engine suspension
 1. Bolted joint

Bolted joints - Checking tightening torque

- Check that all the bolts for the suspension of the engine and the drive unit are tightened. See under Specifications - tightening torque.
- Check the bolted joint between the motor and the pump drive, and that all the hydraulic components are tightened to the set tightening torque.

(The above applies to new or replaced components only).




Fig. Compressor
1. Screw
2. Belt

Compressor belt - Adjustment

- Undo the two screws (1) on top of the compressor.
- Undo the screw (1) under the compressor.
- The belt (2) is now slackened and can be adjusted. Tighten the belt to 10 mm (3/8 in.).
- When the belt is tightened, tighten the screws (1) again.

Maintenance - Every 1000h

Every 1000/3000..... hours of operation
(yearly)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***

**Battery - Check condition**

The batteries are sealed and maintenance-free.



***Make sure there is no open flame in the vicinity
when checking the electrolyte level. Explosive gas
is formed when the alternator charges the battery.***



**When disconnecting the battery, always
disconnect the negative cable first. When
connecting the battery, always connect the
positive cable first.**

- The cable shoes should be clean and tightened.
- Corroded cable shoes should be cleaned and greased with acid-proof Vaseline.
- Wipe the top of the battery.




Fig. Battery



Rear axle differential - Oil change



Never work under the roller when the engine is running. Park on a level surface and block the wheels securely.




Fig. Rear axle
1. Level/Filler plug
2. Drain plug

- Wipe clean
- Remove the filler/level plug (1).
- Remove the drain plug (2).
- Drain the oil into a container.

Differential

- The drain plug (2) is on the back of the shaft.
- The volume is approx. 4.5 liters (4.2 qts).

Pinion house

- The drain plug (2) is on the underside of the pinion housing.
- The volume is approx. 0.3 liters (0.32 qts).



Save the oil and hand in to an environment-friendly waste disposal station.




Fig. Rear axle - Pinion house
1. Level/Filler plug
2. Drain plug

- Replace the drain plug and top up with fresh transmission oil to the correct level. See the lubricant specification.
- Reassemble the level/filler plug (1).



Rear axle planetary gear - Oil change

- Position the roller with the plug in the planetary gear at its lowest position, 1.
- Wipe clean, unscrew plug (1) and drain the oil into a container. The volume is approx. 0.9 liters (0.95 qts)/side.



Save the oil and hand in to an environment-friendly waste disposal station.

- Position the roller so that the plug in the planetary gear is in position 2.
- Fill with transmission oil to lower edge of level hole. See lubrication specification.
- Clean and refit the plug.
- Change the oil in the second planetary gear of the rear axle in the same manner.





Fig. Planetary gear
1. Plug, position for draining
2. Plug, position for refilling



Drum - Checking the oil level (CA1300)




Fig. Drum, left side

- 1. Groove**
- 2. Filler plug**
- 3. Drain plug/Magnetic plug**
- 4. Level plug**

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.
- Release the level plug (4) and unscrew until oil starts to run out through the plug hole.
- If necessary, release the filler plug (2) and fill with oil until it starts to run out through the level plug (4) hole.
- Clean and screw in the level plug (4).
- Clean and refit the filler plug (2).
- See the lubrication specification for the correct oil grade.

When refilling is needed:


- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk for overheating.



Be sure to use only Dynapac gear oil 300 in the roller.

**When refilling is needed:**

- Release the filler plug (1) and fill to half the sight glass (2).
- Clean and refit filler plug (1).



Do not overfill with oil - risk of overheating.



Be sure to use only
Dynapac gear oil 300 in the roller.

Fig. Roller, left side
1. Filler plug
2. Drain/Magnetic plug
3. Level plug



Drum - Checking the oil level (CA1400)

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.




Fig. Left drum side
1. Groove




Fig. Right drum side
2. Filler plug
3. Sight glass

When refilling is needed:

- Release the filler plug (2) and fill up.
- Clean and refit filler plug (2).



Do not overfill with oil - risk for overheating.



Be sure to use only
 Dynapac gear oil 300 in the roller.




Fig. Engine compartment
1. Water cooler
2. Hydraulic fluid cooler

Coolers Checking - Cleaning

- Make sure that the air flow through the coolers (1) and (2) is unobstructed.
- Dirty coolers are blown clean with compressed air or washed clean using a high-pressure water cleaner.
- Blow air or direct water through the cooler in the opposite direction to that of the cooling air.



Take care when using a high-pressure water jet. Do not hold the nozzle too near the cooler.



When working with compressed air or a high-pressure washer. Use the following protective equipment:



Safety glasses



Protective gloves

Ear protectors




Fig. Drum, drive side
1. Rubber element
2. Attachment screws

Rubber elements and fastening screws - Check

- Check all rubber elements (1).
- Replace all of the elements if more than 25% of them on one side of the drum are cracked deeper than 10-15 mm (0.4-0.6 in).
- Check using a knife blade or pointed object.
- Check also that the screw fasteners (2) are tightened.



Fuel tank

Cleaning

It is easiest to clean the tank when it is almost empty.

- Pump out any bottom sediment using a suitable pump, such as an oil drain pump.



Collect the fuel and sediment in a container and deliver to environmentally correct handling.



Keep in mind fire risk when handling fuel.



The fuel tank is made of plastic (polyethylene) and is recyclable.




Fig. Fuel tank
1. Oil drain pump

Draining (Equipment status)

Water and sediment in the fuel tank are drained out via the drain plug (1) in the bottom of the fuel tank.



Be very careful during draining.
Do not drop the plug or else
all the fuel will flow out.

Drain the roller after it has been stationary for a long time, e.g. after standing overnight.

The fuel level should be as low as possible.

The roller should preferably have been standing with the drain plug somewhat lower, so that water and sediment collect at the drain plug (1).

Drain as follows:

- Place a container under the plug (1).
- Undo the drain plug (1) and drain out water and sediment until only pure diesel fuel comes out at the plug.
- Screw in the plug again.




Fig. Left underside of the machine
1. Drain plug



Hydraulic reservoir - Draining




Fig. Hydraulic reservoir, bottom
1. Drain plug

Condensate in the hydraulic reservoir is drained via the drain plug (1).

Drain the roller after it has been stationary for a long time, e.g. after standing overnight.

Drain as follows:

- Place a container under the drain hole.
- Remove the plug (1).
- Drain off any condensate.
- Refit the plug.



The engine fuel filter - replacement/cleaning



Place a container underneath to collect fuel that runs out when the filter is released.




Fig. Engine compartment
1. Fuel filter
2. Fuel prefilter

- Screw off the fuel filter (1).
- Hand in to environment-friendly station.
The filter is of the disposable type and cannot be cleaned.



Refer to the engine manual for detailed instructions when replacing the fuel filter.

- Unscrew the lower part of the fuel prefilter (2).
- Drain off any water, and then replace the filter unit.
- Start the engine and check that the fuel filters are tight.

N.B. Under no circumstances may new fuel filters be pre-filled with fuel before assembly due to the demands on the cleanliness of the fuel system. Use the hand pump on the fuel prefilter to fill from the machine's fuel system.






Fig. Hydraulic reservoir
1. Filler cap/Breather filter

Hydraulic filter - Replacement

- Release the filler cap/breather filter (1) so that any overpressure inside the reservoir is eliminated.
- Check that the breather filter (1) is not clogged. Air should be able to pass freely through the cap in both directions.

If passage in either direction is blocked:

- Clean the filter with a little diesel oil.
- Blow through with compressed air until the block is removed,
or replace the cap with a new one.



When working with compressed air.
Use the following protective equipment:



Safety glasses

- Carefully clean round the filter.



Remove the oil filter (1) and hand in to an environment-friendly waste disposal station. This is a disposable filter and cannot be cleaned.



Make sure that the old sealing ring is not left on the filter holder. Otherwise, this could cause leakage between the new and old seal.

- Thoroughly clean the sealing surfaces on the filter holder.
- Apply a thin coat of fresh hydraulic fluid to the seals on the new filter.
- Screw tight the filter by hand.



- First tighten the filter until its seal is in contact with the filter attachment.
- Then turn an additional half revolution.
- Do not tighten the filter too hard as this could damage the gasket..

- Start the engine and check that there is no leakage of hydraulic fluid from the filter.
- Check the fluid level in the sight glass and top up if necessary.




Fig. Hydraulic oil filter (x1)



Ensure that there is good ventilation (air extraction) if the engine is run indoors. Risk of carbon monoxide poisoning.



Diesel engine - Oil- and Filter change



Take great care when draining warm fluid and oil. Use following protection equipment:



Protective goggles



Protective gloves




Fig. Right side of engine
1. Drain plug




Fig. Engine compartment
2. Oil filter

The oil plug (1) is most easily accessible from the underside of the engine, and is fitted with a hose on the tractor frame.

- Place a receptacle that holds 15 liters (4 gal) under the drain plug.
- Release the hose from its attachment and pull it forward to the tie-down hole.
- Loosen the drain plug (1) and drain the oil, when the engine is warm.
- Screw back the plug again and refit the hose in its attachment.
- Change the engine oil filter (2) at the same time. Refer also to the Instruction Manual for the engine.



Hand in the drained oil and filter to an environment-friendly waste disposal station.



Forward/Reverse controls and joints - Check and lubrication

Accessing the machine fitted with ROPS

The easiest way to access the forward/reverse lever pivot points is via the operator's manual pocket on the right-hand side of the driver's seat.




Fig. Forward/reverse lever




Fig. Forward/reverse lever, Cab
 1. Forward/Reverse lever
 2. Plate
 3. Screw

Access on machine with cab

- The forward/reverse lever pivot points are accessed by removing four screws (3) on the plate (2) under the forward/reverse lever (1).
- Check friction of the forward/reverse lever.
 The friction screws must be sufficiently tightened to retain the forward/reverse lever in the position set during operation. The "0" position of the controls is determined by a screw that engages in the groove on the shaft between the controls.

If the lever begins to become stiff after prolonged used.

- Lubricate the lever at the control cable with a few drops of oil at each point.

If the forward/reverse lever still is stiff after the above adjustments:

- Lubricate the other end of the control cable with a few drops of oil.

The cable is located on the top of the propulsion pump.




Fig. Engine compartment
 1. Forward/Reverse-control cable
 2. Propulsion pump



Lubrication, hinges

Cab

- Lubricate the hinges (2) on the cab doors with grease. See lubricant specification.




Fig. Cab
2. Hinge, cab




Fig. Engine hood
1. Hood hinge

Hood

- Lubricate the engine hood hinges (1) and the driver's seat slide rails with grease.
- Other pivot points and controls are lubricated with oil.



Air conditioning (Optional) Fresh air filter - Change



Use a step ladder to reach the filter (1). The filter can also be accessed via the right cab window.

There is a fresh air filter (1), located at the front of the cab.

It may be necessary to change the filter more often if the machine is working in a dusty environment.




Fig. Cab 1
 1. Fresh air filter (x 1)
 2. Screws (x 8)

Cab option 1

- Loosen the eight screws (2) and remove the protective cover.
- Remove the air filter element (1) and replace with a new.

Cab option 2

- Loosen the screw (2) and remove the filter housing (3).
- Remove the air filter element (1) from the filter housing (3) and replace it with a new filter element.




Fig. Cab 2
 1. Fresh air filter (x1)
 2. Filter housing (x1)
 3. Screw (x1)

**Air cleaner****Check - Replacement of main filter**

Replace the air cleaner's main filter when the indicator shows red. The indicator is mounted on the air cleaner's connecting pipe.

Air filter indicator - Resetting

The air filter indicator is located on the filter, or in its immediate vicinity.

The air filter indicator must be reset after replacing the air filter.

Press the "button" (1) on the top of the indicator to reset.




Fig. Indicator
1. Button

**Backup filter - Change**

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary.
See section Air cleaner - Cleaning.




Fig. Air filter
1. Backup filter




Fig. Condenser
 1. Condenser element
 2. Brackets (4 pcs)
 3. Screws (4 pcs)
 4. Washers (4 pcs)

Air conditioning (Optional) - Check

- If cooling capacity is noticeably impaired, clean the condenser element (1) located in front of the radiator in the engine compartment (see Radiator, Check - Cleaning).
- Also clean the cooling unit in the cab. See under the heading 2000 hours, air conditioning - overhaul.




Fig. Compressor
 1. Screw
 2. Belt

Compressor belt - Adjustment

- Undo the two screws (1) on top of the compressor.
- Undo the screw (1) under the compressor.
- The belt (2) is now slackened and can be adjusted. Tighten the belt to 10 mm (3/8 in.).
- When the belt is tightened, tighten the screws (1) again.


**Hydraulic reservoir - Oil change**

Fig. Hydraulic reservoir, bottom
1. Drain plug

- Use a container to collect the used fluid.
The container should hold at least 45 liters (11.8 gal).



Observe caution when draining hot hydraulic fluid.
Use the following protective equipment:



Safety glasses



Protective gloves

- Place the container under the hydraulic reservoir.
- Remove the drain plug (1) and allow the fluid to run down into the container.
- Wipe clean and replace the drain plug (1) in the hydraulic reservoir.



Save the oil and hand in to an environment-friendly waste disposal station.

- Fill up with fresh hydraulic fluid as per the instructions under the heading "Hydraulic reservoir - Check fluid level".
- Replace the hydraulic fluid filter at the same time.
- Start the diesel engine and operate the various hydraulic functions.
- Check the fluid level and top up if necessary.




Fig. Engine suspension
1. Bolted joint

Bolted joints - Checking tightening torque

- Check that all the bolts for the suspension of the engine and the drive unit are tightened. See under Specifications - tightening torque.
- Check the bolted joint between the motor and the pump drive, and that all the hydraulic components are tightened to the set tightening torque.

(The above applies to new or replaced components only).



Drum gear (CA1400)

Oil change

- Place the roller on a level surface.
- Move the machine so the drain/ventilating plugs are in location for drain.
- Wipe clean, unscrew the plugs (2, 3) and drain the oil into a suitable receptacle, capacity about 2 liters (0.5 gal.).




Fig. Oil change - drum gear
1. Drum gear

Oil filling

- Move the machine until the inspection (2) / filling holes (3) are in position for filling.
- Refill with new transmission oil according to the lubricant specification.
- Ensure that the oil level reaches up to the lower edge of the plug hole (3).
- Clean and refit the plugs.




Fig. Drum gear

Maintenance - Every 2000h

Every 2000/4000..... hours of operation
(every two years)



***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***

**Battery - Check condition**

The batteries are sealed and maintenance-free.



***Make sure there is no open flame in the vicinity
when checking the electrolyte level. Explosive gas
is formed when the alternator charges the battery.***



**When disconnecting the battery, always
disconnect the negative cable first. When
connecting the battery, always connect the
positive cable first.**

- The cable shoes should be clean and tightened.
- Corroded cable shoes should be cleaned and greased with acid-proof Vaseline.
- Wipe the top of the battery.




Fig. Battery



Rear axle differential - Oil change



Never work under the roller when the engine is running. Park on a level surface and block the wheels securely.




Fig. Rear axle
1. Level/Filler plug
2. Drain plug

- Wipe clean
- Remove the filler/level plug (1).
- Remove the drain plug (2).
- Drain the oil into a container.

Differential

- The drain plug (2) is on the back of the shaft.
- The volume is approx. 4.5 liters (4.2 qts).

Pinion house

- The drain plug (2) is on the underside of the pinion housing.
- The volume is approx. 0.3 liters (0.32 qts).



Save the oil and hand in to an environment-friendly waste disposal station.





Fig. Rear axle - Pinion house
1. Level/Filler plug
2. Drain plug


- Replace the drain plug and top up with fresh transmission oil to the correct level. See the lubricant specification.
- Reassemble the level/filler plug (1).

**Rear axle planetary gear - Oil change**

- Position the roller with the plug in the planetary gear at its lowest position, 1.
- Wipe clean, unscrew plug (1) and drain the oil into a container. The volume is approx. 0.9 liters (0.95 qts)/side.



Save the oil and hand in to an environment-friendly waste disposal station.



- Position the roller so that the plug in the planetary gear is in position 2.
- Fill with transmission oil to lower edge of level hole. See lubrication specification.
- Clean and refit the plug.
- Change the oil in the second planetary gear of the rear axle in the same manner.

Fig. Planetary gear
1. Plug, position for draining
2. Plug, position for refilling



Drum - Oil change




Fig. Roller, left side

- 1. Groove
- 2. Filler plug
- 3. Drain/Magnetic plug
- 4. Level plug

- Position the roller on a flat surface with the groove (1) on the inside of the drum aligned with the top of the drum frame.
- Place a receptacle that holds 10 liters (2.6 gal) under the drain plug (3).
- Clean and unscrew the filler plug (2).
- Unscrew the drain plug (3) and allow all the oil to run out.



**Observe care when draining hot oil.
Use the following protective equipment:**



Safety glasses



Protective gloves



Save the oil and hand in to an environment-friendly waste disposal station.

- Clean and refit the drain plug (3).
- Fill with oil as per "Drum - Checking the oil level".
- Clean and refit the filler plug (2).




Fig. Engine compartment
 1. Water cooler
 2. Hydraulic fluid cooler

Coolers Checking - Cleaning

- Make sure that the air flow through the coolers (1) and (2) is unobstructed.
- Dirty coolers are blown clean with compressed air or washed clean using a high-pressure water cleaner.
- Blow air or direct water through the cooler in the opposite direction to that of the cooling air.



Take care when using a high-pressure water jet. Do not hold the nozzle too near the cooler.



When working with compressed air or a high-pressure washer. Use the following protective equipment:



Safety glasses



Protective gloves

Ear protectors




Fig. Drum, drive side
 1. Rubber element
 2. Attachment screws

Rubber elements and fastening screws - Check

- Check all rubber elements (1).
- Replace all of the elements if more than 25% of them on one side of the drum are cracked deeper than 10-15 mm (0.4-0.6 in).
- Check using a knife blade or pointed object.
- Check also that the screw fasteners (2) are tightened.




Fig. Engine suspension
1. Bolted joint

Bolted joints - Checking tightening torque

- Check that all the bolts for the suspension of the engine and the drive unit are tightened. See under Specifications - tightening torque.
- Check the bolted joint between the motor and the pump drive, and that all the hydraulic components are tightened to the set tightening torque.

(The above applies to new or replaced components only).



Fuel tank

Cleaning

It is easiest to clean the tank when it is almost empty.

- Pump out any bottom sediment using a suitable pump, such as an oil drain pump.



Collect the fuel and sediment in a container and deliver to environmentally correct handling.



Keep in mind fire risk when handling fuel.



The fuel tank is made of plastic (polyethylene) and is recyclable.




Fig. Fuel tank
1. Oil drain pump

Draining (Equipment status)

Water and sediment in the fuel tank are drained out via the drain plug (1) in the bottom of the fuel tank.



Be very careful during draining.
Do not drop the plug or else
all the fuel will flow out.

Drain the roller after it has been stationary for a long time, e.g. after standing overnight.

The fuel level should be as low as possible.

The roller should preferably have been standing with the drain plug somewhat lower, so that water and sediment collect at the drain plug (1).

Drain as follows:

- Place a container under the plug (1).
- Undo the drain plug (1) and drain out water and sediment until only pure diesel fuel comes out at the plug.
- Screw in the plug again.




Fig. Left underside of the machine
1. Drain plug



The engine fuel filter - replacement/cleaning



Place a container underneath to collect fuel that runs out when the filter is released.

- Screw off the fuel filter (1).
- Hand in to environment-friendly station.
The filter is of the disposable type and cannot be cleaned.



Refer to the engine manual for detailed instructions when replacing the fuel filter.

- Unscrew the lower part of the fuel prefilter (2).
- Drain off any water, and then replace the filter unit.
- Start the engine and check that the fuel filters are tight.

N.B. Under no circumstances may new fuel filters be pre-filled with fuel before assembly due to the demands on the cleanliness of the fuel system. Use the hand pump on the fuel prefilter to fill from the machine's fuel system.




Fig. Engine compartment
1. Fuel filter
2. Fuel prefilter

**Diesel engine - Oil- and Filter change**

**Take great care when draining warm fluid and oil.
Use following protection equipment:**



Protective goggles



Protective gloves




Fig. Right side of engine
1. Drain plug




Fig. Engine compartment
2. Oil filter

The oil plug (1) is most easily accessible from the underside of the engine, and is fitted with a hose on the tractor frame.

- Place a receptacle that holds 15 liters (4 gal) under the drain plug.
- Release the hose from its attachment and pull it forward to the tie-down hole.
- Loosen the drain plug (1) and drain the oil, when the engine is warm.
- Screw back the plug again and refit the hose in its attachment.
- Change the engine oil filter (2) at the same time. Refer also to the Instruction Manual for the engine.



Hand in the drained oil and filter to an environment-friendly waste disposal station.



Forward/Reverse controls and joints - Check and lubrication

Accessing the machine fitted with ROPS

The easiest way to access the forward/reverse lever pivot points is via the operator's manual pocket on the right-hand side of the driver's seat.




Fig. Forward/reverse lever

Access on machine with cab

- The forward/reverse lever pivot points are accessed by removing four screws (3) on the plate (2) under the forward/reverse lever (1).
- Check friction of the forward/reverse lever.
The friction screws must be sufficiently tightened to retain the forward/reverse lever in the position set during operation. The "0" position of the controls is determined by a screw that engages in the groove on the shaft between the controls.




Fig. Forward/reverse lever, Cab
 1. Forward/Reverse lever
 2. Plate
 3. Screw

If the lever begins to become stiff after prolonged used.

- Lubricate the lever at the control cable with a few drops of oil at each point.

If the forward/reverse lever still is stiff after the above adjustments:

- Lubricate the other end of the control cable with a few drops of oil.

The cable is located on the top of the propulsion pump.




Fig. Engine compartment
 1. Forward/Reverse-control cable
 2. Propulsion pump



Lubrication, hinges

Cab

- Lubricate the hinges (2) on the cab doors with grease. See lubricant specification.




Fig. Cab
2. Hinge, cab




Fig. Engine hood
1. Hood hinge

Hood

- Lubricate the engine hood hinges (1) and the driver's seat slide rails with grease.
- Other pivot points and controls are lubricated with oil.



Air conditioning (Optional) Fresh air filter - Change



Use a step ladder to reach the filter (1). The filter can also be accessed via the right cab window.

There is a fresh air filter (1), located at the front of the cab.

It may be necessary to change the filter more often if the machine is working in a dusty environment.




Fig. Cab 1
 1. Fresh air filter (x 1)
 2. Screws (x 8)

Cab option 1

- Loosen the eight screws (2) and remove the protective cover.
- Remove the air filter element (1) and replace with a new.

Cab option 2

- Loosen the screw (2) and remove the filter housing (3).
- Remove the air filter element (1) from the filter housing (3) and replace it with a new filter element.




Fig. Cab 2
 1. Fresh air filter (x1)
 2. Filter housing (x1)
 3. Screw (x1)



Air cleaner Check - Replacement of main filter




Replace the air cleaner's main filter when the indicator shows red. The indicator is mounted on the air cleaner's connecting pipe.

Air filter indicator - Resetting

The air filter indicator is located on the filter, or in its immediate vicinity.

The air filter indicator must be reset after replacing the air filter.

Press the "button" (1) on the top of the indicator to reset.



Backup filter - Change

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary.
See section Air cleaner - Cleaning.




Fig. Air filter
1. Backup filter




Fig. Engine compartment
1. Code element

Automatic Climate Control (Optional) - Overhaul

Regular inspection and maintenance are necessary to ensure satisfactory long-term operation.

- Clean all dust from the condenser element (1) using compressed air. Blow from underneath.



The air jet can damage the element flanges if it is too powerful.



When working with compressed air, use the following protective equipment:



Safety glasses

- Inspect the condenser element attachment.

Compressor belt - Adjustment

- Undo the two screws (1) on top of the compressor.
- Undo the screw (1) under the compressor.
- The belt (2) is now slackened and can be adjusted. Tighten the belt to 10 mm (3/8 in.).
- When the belt is tightened, tighten the screws (1) again.




Fig. Compressor
1. Screw
2. Belt



Hydraulic reservoir - Oil change




Fig. Hydraulic reservoir, bottom
1. Drain plug

- Use a container to collect the used fluid.
The container should hold at least 45 liters (11.8 gal).



Observe caution when draining hot hydraulic fluid.
Use the following protective equipment:



Safety glasses



Protective gloves

- Place the container under the hydraulic reservoir.
- Remove the drain plug (1) and allow the fluid to run down into the container.
- Wipe clean and replace the drain plug (1) in the hydraulic reservoir.



Save the oil and hand in to an environment-friendly waste disposal station.

- Fill up with fresh hydraulic fluid as per the instructions under the heading "Hydraulic reservoir - Check fluid level".
- Replace the hydraulic fluid filter at the same time.
- Start the diesel engine and operate the various hydraulic functions.
- Check the fluid level and top up if necessary.



Drum gear (CA1400)

Oil change

- Place the roller on a level surface.
- Move the machine so the drain/ventilating plugs are in location for drain.
- Wipe clean, unscrew the plugs (2, 3) and drain the oil into a suitable receptacle, capacity about 2 liters (0.5 gal.).




Fig. Oil change - drum gear
1. Drum gear




Fig. Drum gear

Oil filling

- Move the machine until the inspection (2) / filling holes (3) are in position for filling.
- Refill with new transmission oil according to the lubricant specification.
- Ensure that the oil level reaches up to the lower edge of the plug hole (3).
- Clean and refit the plugs.



Hydraulic reservoir - Draining

Condensate in the hydraulic reservoir is drained via the drain plug (1).

Drain the roller after it has been stationary for a long time, e.g. after standing overnight.

Drain as follows:

- Place a container under the drain hole.
- Remove the plug (1).
- Drain off any condensate.
- Refit the plug.




Fig. Hydraulic reservoir, bottom
1. Drain plug



Hydraulic filter - Replacement




Fig. Hydraulic reservoir
1. Filler cap/Breather filter

- Release the filler cap/breather filter (1) so that any overpressure inside the reservoir is eliminated.
- Check that the breather filter (1) is not clogged. Air should be able to pass freely through the cap in both directions.

If passage in either direction is blocked:

- Clean the filter with a little diesel oil.
- Blow through with compressed air until the block is removed, or replace the cap with a new one.



When working with compressed air.
Use the following protective equipment:



Safety glasses

- Carefully clean round the filter.



Remove the oil filter (1) and hand in to an environment-friendly waste disposal station. This is a disposable filter and cannot be cleaned.



Make sure that the old sealing ring is not left on the filter holder. Otherwise, this could cause leakage between the new and old seal.

- Thoroughly clean the sealing surfaces on the filter holder.
- Apply a thin coat of fresh hydraulic fluid to the seals on the new filter.
- Screw tight the filter by hand.



- First tighten the filter until its seal is in contact with the filter attachment.
- Then turn an additional half revolution.
- Do not tighten the filter too hard as this could damage the gasket..

- Start the engine and check that there is no leakage of hydraulic fluid from the filter.




Fig. Hydraulic oil filter (x1)

- Check the fluid level in the sight glass and top up if necessary.



***Ensure that there is good ventilation (air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***




Fig. Steering joint

Steering joint - Check

- Inspect the steering joint to detect any damage or cracks.
- Check and tighten any loose bolts.
- Check also for any stiffness and play.

**Maintenance, every 12th month
(Annually)**


***Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.***



***Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.***

**Air cleaner
Check - Replacement of main filter**

Replace the air cleaner's main filter when the indicator shows red. The indicator is mounted on the air cleaner's connecting pipe.



**Fig. Indicator
1. Button**

Air filter indicator - Resetting

The air filter indicator is located on the filter, or in its immediate vicinity.

The air filter indicator must be reset after replacing the air filter.

Press the "button" (1) on the top of the indicator to reset.


**Backup filter - Change**

Fig. Air filter
1. Backup filter

Change the backup filter with a new filter after every third replacement of the main filter.

To change the backup filter (1), pull the old filter out of its holder, insert a new filter and reassemble the air cleaner in the reverse order.

Clean the air cleaner if necessary.
See section Air cleaner - Cleaning.

**Checking the DPF / EGR pipes / the Manifold and connections
(Tier 4f / Stage V)**

Contact your local Kubota representative for this service

Maintenance, every 24th month (Every other year)



*Park the roller on a level surface.
The engine must be switched off and the parking
brake activated when checking or adjusting the
roller, unless otherwise specified.*



*Ensure that there is good ventilation
(air extraction) if the engine is run indoors.
Risk of carbon monoxide poisoning.*

Check - Air intake hoses

- Check that all hoses/hose connections are intact and tight.





Fig. Engine compartment
1. Air intake hoses



1

Fig. Cooling water container
1. Filler cap

Cooling water system - Check

- Check that all hoses/hose connectors are intact and tight.
- Fill with coolant as specified in the lubricants specification.



Take great care when opening the radiator cap while the engine is hot.
Wear protective gloves and goggles.



Also check the freezing point.
Change the coolant every other year.




Fig. Drain, radiator
1. Radiator hose
2. Drain plug (27 mm)

Coolant - Change

- Put a 22 l (23.2 qts) vessel under the cooling hose (1).

Replace via coolant hose

- Detach the hose (1) and drain the fluid into the vessel.
- When all the fluid has drained into the vessel, attach the hose (1) in its original position.

Change via drain plug

- Loosen the drain plug (27 mm) (2) and drain the fluid into the vessel.
- When all the fluid has drained into the vessel, replace the drain plug (27 mm) (2).



Dispose of the drained coolant in an environmentally friendly manner.

