




Owner's Manual
BF115J • BF140A •
BF150D





WARNING:



The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

Keep this Owner's Manual handy, so you can refer to it at any time. This Owner's Manual is considered a permanent part of the outboard motor and should remain with the outboard motor if resold.

The information and specifications included in this publication were in effect at the time of approval for printing. Honda Motor Co., Ltd. reserves the right, however, to discontinue or change specifications or design at any time without notice and without incurring any obligation whatever. No part of this publication may be reproduced without written permission.

Congratulations on your selection of a Honda outboard motor. We are certain you will be pleased with your purchase of one of the finest outboard motors on the market.

We want to help you get the best results from your new outboard motor and to operate it safely. This manual contains information on how to do that; please read it carefully.

As you read this manual you will find information preceded by a **NOTICE** symbol. That information is intended to help you avoid damage to your outboard motor, other property, or the environment.

We suggest you read the warranty policy to fully understand its coverage and your responsibilities of ownership.

When your outboard motor needs scheduled maintenance, keep in mind that your Honda Marine dealer is specially trained in servicing Honda outboard motors. Your Honda Marine dealer is dedicated to your satisfaction and will be pleased to answer your questions and concerns.

For information regarding the optional equipment, refer to the owner's manual that came with it.

INTRODUCTION

A FEW WORDS ABOUT SAFETY

Your safety and the safety of others are very important. And using this outboard motor safely is an important responsibility.

To help you make informed decisions about safety, we have provided operating procedures and other information on labels and in this manual. This information alerts you to potential hazards that could hurt you or others.

Of course, it is not practical or possible to warn you about all the hazards associated with operating or maintaining an outboard motor. You must use your own good judgment.

You will find important safety information in a variety of forms, including:

- **Safety Labels** – on the outboard motor
- **Safety Messages** – preceded by a safety alert symbol ⚠ and one of three signal words, DANGER, WARNING, or CAUTION.

These signal words mean:

⚠ DANGER

You **WILL** be KILLED or SERIOUSLY HURT if you don't follow instructions.

⚠ WARNING

You **CAN** be KILLED or SERIOUSLY HURT if you don't follow instructions.

⚠ CAUTION

You **CAN** be HURT if you don't follow instructions.

- **Safety Headings** – such as IMPORTANT SAFETY INFORMATION.
- **Safety Section** – such as OUTBOARD MOTOR SAFETY.
- **Instructions** – how to use this outboard motor correctly and safely.

This entire manual is filled with important safety information – please read it carefully.

TRADEMARKS

NMEA2000® is a registered trademark of National Marine Electronics Association, Inc.

CONTENTS	3
OUTBOARD MOTOR SAFETY	7
IMPORTANT SAFETY INFORMATION	7
Operator Responsibility	7
Refuel With Care	8
Carbon Monoxide Hazard	8
Be alert for underwater obstacles	9
SAFETY LABEL LOCATION	10
CONTROLS AND FEATURES	11
CONTROL AND FEATURE IDENTIFICATION	
CODES	11
HOW TO DETERMINE WHICH DIRECTION	
THE PROPELLER SHAFT ROTATES	12
COMPONENT AND CONTROL LOCATIONS	13
Outboard Motor	13
Remote Control Box for DBW type	
(optional equipment)	17
Switch Panel for DBW type	
(optional equipment)	18
Remote Control Box for Mechanical wire type	
(optional equipment)	21
Control panel for Mechanical wire type	
(optional equipment)	23
Tachometer for Mechanical wire type	
(optional equipment)	24

Trolling Control Switch Panel	
(optional equipment)	24
Multi-function Display (optional equipment)	24
CONTROLS	26
Ignition Switch (without START/STOP switch)	26
Power Switch (with START/STOP switch)	27
START/STOP Switch	28
Emergency Stop Switch Clip and	
Emergency Stop Switch	29
Gearshift/Throttle Control Lever (DBW type)	31
Gearshift/Throttle Control Lever	
(Mechanical wire type)	34
Select Switches (DBW type)	40
COMMON CONTROLS	48
Power Trim/Tilt Switch	48
Power Trim/Tilt Switch Panel	50
Power Tilt Switch	51
Manual Relief Valve	52
Tilt Lock Lever	53
TRL (Trolling) Control Switch (optional	
equipment for Mechanical wire type)	54
Engine Cover Latches	55
Trim Tab	55
Tachometer (optional equipment)	55
NMEA Interface Coupler	56
Operating Hour Notification System	56

CONTENTS

INDICATORS	59	STARTING THE ENGINE	72
Alternator (ACG) Indicator	59	DBW type	72
Malfunction Indicator	60	Mechanical wire type	76
Low Oil Pressure Indicator or		STOPPING THE ENGINE	82
Oil Pressure Indicator	61	DBW type	82
Overheat Indicator	62	Mechanical wire type	85
Cooling System Indicator	63	GEARSHIFT AND THROTTLE OPERATION	87
OTHER FEATURES	64	Gearshift/Throttle Control Lever Friction	88
Water Separator Buzzer	64	STEERING	91
Rev Limiter	64	CRUISING	92
Anodes	65	Engine Speed	92
Fuel Priming Bulb	65	Trim	93
Battery Switch OFF Notification	66	Trolling Speed Control (optional equipment	
Power Reduction	66	for Mechanical wire type)	96
BEFORE OPERATION	67	Trim Support Mode (DBW type)	97
ARE YOU READY TO GET UNDERWAY?	67	TROLLING CONTROL MODE (DBW type)	99
Knowledge	67	ONE-LEVER MODE	
Safety	67	(Dual top-mount type for DBW type)	100
IS YOUR OUTBOARD MOTOR READY TO GO?	67	CRUISE CONTROL MODE (DBW type)	101
Safety Inspection	68	SHALLOW WATER OPERATION	102
Maintenance Inspection	69	MOORING, BEACHING, LAUNCHING	103
OPERATION	70	Moorage	105
SAFE OPERATING PRECAUTIONS	70	Automatic Tilt Mode (DBW type)	107
BREAK-IN PROCEDURE	70	Power Tilt Switch (outboard motor panel)	108
FUEL PRIMING	71	Manual Relief Valve	109
INFREQUENT OR OCCASIONAL USE	72	MULTIPLE OUTBOARD MOTORS	109

TURNING WHEN MULTIPLE ENGINES ARE MOUNTED	110	FUEL FILTER WITH WATER SEPARATOR (LOW PRESSURE SIDE) INSPECTION AND REPLACEMENT	134
SERVICING YOUR OUTBOARD MOTOR	113	Inspection	135
THE IMPORTANCE OF MAINTENANCE	113	Replacement	136
MAINTENANCE SAFETY	114	ANODE INSPECTION	137
Safety Precautions	114	PROPELLER REPLACEMENT (Except for JET Drive type)	138
TOOL KIT and OWNER'S MANUAL	115	Removal	138
SPARE EMERGENCY STOP SWITCH CLIP (optional equipment)	116	Installation	138
MAINTENANCE SCHEDULE	116	CLEANING AND FLUSHING	140
TRIM TAB ADJUSTMENT	119	CLEANING AND FLUSHING	140
ENGINE COVER REMOVAL AND INSTALLATION	120	Cleaning	140
Removal	120	Flushing With a Garden Hose (commercially available)	141
Installation	120	STORAGE	143
ENGINE OIL LEVEL CHECK	122	FUEL	143
ENGINE OIL CHANGE	123	Storage Procedure	144
ENGINE OIL RECOMMENDATIONS	124	Adding a Fuel Stabilizer	145
LUBRICATION POINTS	125	Draining the Fuel System	146
SPARK PLUG SERVICE	128	ENGINE OIL	147
Standard Spark Plug (Iridium)	128	HOISTING THE OUTBOARD MOTOR	147
Optional Spark Plug (Nickel)	131	STORAGE PRECAUTIONS	148
REFUELING	132	REMOVAL FROM STORAGE	149
FUEL RECOMMENDATIONS	133	TRANSPORTING	150

CONTENTS

WITH OUTBOARD MOTOR INSTALLED ON BOAT	150
WITH OUTBOARD MOTOR REMOVED FROM BOAT	150
TAKING CARE OF UNEXPECTED PROBLEMS	151
ELECTRIC STARTER WILL NOT OPERATE	151
ENGINE WILL NOT START	152
HARD STARTING OR STALLS AFTER STARTING	153
ENGINE OVERHEATS	154
FUSES	155
Electric Starter Will Not Operate	155
Battery Will Not Charge	155
Fuse Replacement	155
LOW OIL PRESSURE INDICATOR COMES ON or OIL PRESSURE INDICATOR GOES OFF AND ENGINE SPEED IS LIMITED	161
OVERHEAT INDICATOR COMES ON AND ENGINE SPEED IS LIMITED	162
WATER SEPARATOR BUZZER SOUNDS	164
WHEN COLLIDING WITH AN UNDERWATER OBSTACLE	165
SUBMERGED OUTBOARD MOTOR	165
EMERGENCY GEAR SHIFTING (DBW type)	167
TECHNICAL INFORMATION	168
SERIAL NUMBER LOCATIONS	168
BATTERY	169

Minimum Requirements	169
EMISSION CONTROL SYSTEM INFORMATION	170
STAR LABEL	173
US, Puerto Rico, and US Virgin Islands	173
SPECIFICATIONS	175
CONSUMER INFORMATION	179
Dealer Locator Information	179
Honda Publications	179
Customer Service Information	180
Warranty Statements	183
Distributor's Limited Warranty	183
Accessories and Replacement Parts	187
Emission Control System Warranty	190
Distributor's Warranty	196
INDEX	200

IMPORTANT SAFETY INFORMATION

Honda BF115J, BF140A, and BF150D outboard motors are designed for use with boats that have a suitable manufacturer's power recommendation. Other uses can result in injury to the operator or damage to the outboard motor and other property.

Most injuries or property damage can be prevented if you follow all instructions in this manual and on the outboard motor. The most common hazards are discussed in this chapter, along with the best way to protect yourself and others.

Operator Responsibility

- It is the operator's responsibility to provide the necessary safeguards to protect people and property. Know how to stop the engine quickly in case of emergency. Understand the use of all controls.
- Stop the engine immediately if anyone falls overboard, and do not run the engine while the boat is near anyone in the water.
- Always stop the engine if you must leave the controls for any reason.
- Attach the emergency stop switch lanyard securely to the operator.
- Always wear a PFD (Personal Flotation Device) while on the boat.
- Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.
- Be sure that anyone who operates the outboard motor receives proper instruction.
- Be sure the outboard motor is properly mounted on the boat.
- Do not remove the engine cover while the engine is running.

OUTBOARD MOTOR SAFETY

Refuel With Care

- Gasoline is extremely flammable, and gasoline vapor can explode. Refuel outdoors, in a well-ventilated area, with the engine stopped. Never smoke near gasoline, and keep other flames and sparks away.
- Refuel carefully to avoid spilling fuel. Avoid overfilling the fuel tank.
- After refueling, tighten the filler cap securely. If any fuel is spilled, make sure the area is dry before starting the engine.

Carbon Monoxide Hazard

Exhaust contains poisonous carbon monoxide, a colorless, odorless gas. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

If you run the engine in an area that is confined, or even partly enclosed, the air you breathe could contain a dangerous amount of exhaust gas.

Never run your outboard inside a garage or other enclosure.

WARNING

Running the engine of your outboard while in an enclosed or partially enclosed area can cause a rapid build-up of toxic carbon monoxide gas.

Breathing this colorless, odorless gas can quickly cause unconsciousness and lead to death.

Only run your outboard engine when it is located in a well-ventilated area outdoors.

Be alert for underwater obstacles


In waters where there is a risk of collision with underwater obstacles or floating debris, reduce your speed and navigate with caution. If a collision occurs, the impact could lead to a serious accident or personal injury.

- Parts of the damaged outboard motor could come loose and be thrown into the boat.
- Passengers could be thrown out due to sudden deceleration.
- The outboard motor or hull could be damaged.

If you hit an underwater obstacle while underway, stop the engine immediately and inspect the outboard motor for any problems.

(See page 165)

Continued use in a damaged condition may prevent safe cruise and lead to serious consequences.



OUTBOARD MOTOR SAFETY

SAFETY LABEL LOCATION



The labels shown here contain important safety information. Please read them carefully. These labels are considered permanent parts of your outboard motor.

If a label comes off or becomes hard to read, contact an authorized Honda Marine dealer for a replacement.


CONTROL AND FEATURE IDENTIFICATION CODES

Model		BF115J				BF140A						BF150D						
Type		LR□	LD□	XR□	XD□	LR□	LD□	XR□	XD□	XCR□	XCD□	JR□	LR□	LD□	XR□	XD□	XCR□	XCD□
Transom Height	20.0 in (508 mm)	•	•			•	•					•	•	•				
	25.0 in (635 mm)			•	•			•	•	•	•				•	•	•	•
Standard Rotating Propeller Shaft		•	•	•	•	•	•	•	•				•	•	•	•		
Counterrotating Propeller Shaft										•	•						•	•
Mechanical wire		•		•		•		•		•		•	•		•		•	
Drive by Wire (DBW)			•		•		•		•		•			•		•		•

Refer to this chart for an explanation of the Type Codes used in this manual to identify control and feature applications.

For the detailed equipment conditions of optional components, consult your Honda dealer.

TYPE CODE (example)




CONTROLS AND FEATURES

HOW TO DETERMINE WHICH DIRECTION THE PROPELLER SHAFT ROTATES

The direction the propeller shaft rotates can be determined based on whether or not the propeller shaft has a groove.


- With groove: Counter-rotating
- Without groove: Standard rotating



COMPONENT AND CONTROL LOCATIONS


Outboard Motor

Except for JET Drive type




* Illustrations are based on X type

CONTROLS AND FEATURES





JET Drive type



- Jet driven Honda outboard engines are shipped without the lower gear case.
- The jet drive unit must be assembled and attached to the outboard motor by an authorized Honda Marine dealer.
- For assistance with the jet drive unit on your Honda outboard, contact the jet drive manufacturer through an authorized Honda Marine dealer.

CONTROLS AND FEATURES




* The figure above shows the engine with the spark plug cover removed.


CONTROLS AND FEATURES

Remote Control Box for DBW type (optional equipment)


Flush-mount remote control



Single top-mount remote control



Dual top-mount remote control





CONTROLS AND FEATURES



Switch Panel for DBW type (optional equipment)


Switch Panel

(Normal Key with START/STOP switch type)



(Normal Key without START/STOP switch type)






**FLUSH-MOUNT REMOTE
CONTROL TYPE**

NOTICE

- For the switch panel without emergency stop switch type, use it along with the flush-mount type remote control box.


START/STOP Switch Panel

START/STOP SWITCH




**ALL ENGINE START FOR
MULTIPLE OUTBOARD
MOTORS**

START/STOP SWITCH




**SINGLE TYPE
OUTBOARD MOTOR**

INDICATORS



**START/STOP SWITCHES
DUAL TYPE
OUTBOARD MOTOR**

INDICATORS




**START/STOP SWITCHES
TRIPLE TYPE
OUTBOARD MOTOR**


PORT: Port side engine
CENTER: Center engine
STBD: Starboard side engine

CONTROLS AND FEATURES

Power Trim/Tilt Switch Panel




**DUAL TYPE
OUTBOARD MOTOR**



**TRIPLE TYPE
OUTBOARD MOTOR**


PORT: Port side engine
CENTER: Center engine
STBD: Starboard side engine

Emergency Stop Switch Panel




Remote Control Box for Mechanical wire type (optional equipment)

Side-mount remote control




* For TRL (Trolling) control switch equipped type.

Flush-mount remote control




CONTROLS AND FEATURES

Single top-mount remote control



* For TRL (Trolling) control switch equipped type.


Dual top-mount remote control




* For TRL (Trolling) control switch equipped type.

Control panel for Mechanical wire type
(optional equipment)


With indicators type




(Dual outboard motors type)




Without indicators type



(Dual outboard motors type)




(Triple outboard motors type)




For the switch panel without indicators type, use it along with the NMEA2000®-compatible device.

CONTROLS AND FEATURES

Tachometer for Mechanical wire type (optional equipment)




Trolling Control Switch Panel (optional equipment)



Multi-function Display (optional equipment)

Refer to the attached instruction manual about handling.


Honda HD-5



NOTICE

- Some functions are not available on multi-function displays with a software version earlier than "Ver. 0.26". Consult with an authorized marine dealer.

Honda HD-7




CONTROLS AND FEATURES


CONTROLS

Ignition Switch (without START/STOP switch)


(DBW type)



(Side-mount type
(Mechanical wire type))



(Control panel type
(Mechanical wire type))




The ignition switch controls the ignition system and the starter motor.

Turning the ignition switch key to the START position starts the engine. The key automatically returns to the ON position when released from the START position.

The engine will not start unless the gearshift/throttle control lever is in the NEUTRAL position (P.73, P.76, P.80) and the emergency stop switch clip is in the emergency stop switch.

Turning the ignition switch to the OFF position stops the engine.

Power Switch (with START/STOP switch)



This remote control is equipped with a start/stop switch.

- ON: This position allows the engine to start and run.
- OFF: This position stops the engine (Ignition OFF).


NOTICE

- Turn the power off after the engine is stopped. If the power is not turned off after the engine is stopped, the battery will continue to drain until it is depleted.

CONTROLS AND FEATURES


START/STOP Switch

START/STOP SWITCH




ALL ENGINE START/STOP
FOR MULTIPLE OUTBOARD
MOTORS

START/STOP SWITCH



SINGLE TYPE
OUTBOARD MOTOR


INDICATORS



START/STOP SWITCHES

DUAL TYPE (quad-type)
OUTBOARD MOTOR

INDICATORS



START/STOP SWITCHES

TRIPLE TYPE
OUTBOARD MOTOR


To start the engine, be sure the power switch is in the ON position, and then press the start/stop switch button.

For boats with multiple outboard motors and equipped with the ALL ENGINE START/STOP switch, all motors can be started sequentially from the PORT side at the press of one button.


For boats equipped with multiple outboard motors and either the dual type or triple type start/stop switches, each outboard on the boat may be started individually and the corresponding indicator light will turn on after the engine has started.

The starter motor will not work unless the gearshift/throttle control lever is in the NEUTRAL position, and the clip is in the emergency stop switch.



Emergency Stop Switch Clip and Emergency Stop Switch (DBW type)



(Side-mount type (Mechanical wire type)) EMERGENCY STOP SWITCH




(Control panel type (Mechanical wire type)) EMERGENCY STOP SWITCH



The emergency stop switch clip must be inserted in the emergency stop switch in order for the engine to start and run. The emergency stop switch lanyard must be attached securely to the operator or to the operator's PFD (Personal Flotation Device).

When used as described, the emergency stop switch clip and emergency stop switch lanyard system stops the engine if the operator falls away from the controls.

CONTROLS AND FEATURES




SPARE SWITCH CLIP

A spare switch clip should be stored near the controls in case the operator and primary switch clip falls overboard and a passenger needs to pilot the boat during an emergency situation.

Gearshift/Throttle Control Lever (DBW type)

Flush-Mount type



You can use the gearshift/throttle control lever to shift gear into forward, reverse, or neutral, and to adjust the engine speed.

It is necessary to pull up the neutral release lever to operate the gearshift/throttle control lever.

FORWARD:

Moving the lever to the FORWARD position (approximately 20° from the NEUTRAL position) engages the gear into forward. Moving the lever further from the FORWARD position will increase the throttle opening and the boat's forward speed.

NEUTRAL:

Engine power is cut off from the propeller.


REVERSE:

Moving the lever to the REVERSE position (approximately 20° from the NEUTRAL position) engages the gear into reverse. Moving the lever further from the REVERSE position will increase the throttle opening and the boat's reverse speed.

CONTROLS AND FEATURES

Top-Mount type

(Single type)



You can use the gearshift/throttle control lever to shift gear into forward, reverse, or neutral, and to adjust the engine speed.

It is necessary to pull up the neutral release lever to operate the gearshift/throttle control lever.

FORWARD:

Moving the lever to the FORWARD position (approximately 20° from the NEUTRAL position) engages the gear into forward. Moving the lever further from the FORWARD position will increase the throttle opening and the boat's forward speed.

NEUTRAL:


Engine power is cut off from the propeller.

REVERSE:

Moving the lever to the REVERSE position (approximately 20° from the NEUTRAL position) engages the gear into reverse. Moving the lever further from the REVERSE position will increase the throttle opening and the boat's reverse speed.

CONTROLS AND FEATURES

(Dual type)



You can use the gearshift/throttle control lever to shift gear into forward, reverse, or neutral, and to adjust the engine speed.

FORWARD:

Moving the lever to the FORWARD position (approximately 20° from the NEUTRAL position) engages the gear into forward. Moving the lever further from the FORWARD position will increase the throttle opening and the boat's forward speed.

NEUTRAL:

Engine power is cut off from the propeller.


REVERSE:

Moving the lever to the REVERSE position (approximately 20° from the NEUTRAL position) engages the gear into reverse. Moving the lever further from the REVERSE position will increase the throttle opening and the boat's reverse speed.

CONTROLS AND FEATURES

Gearshift/Throttle Control Lever (Mechanical wire type)

Side-Mount type



The gearshift/throttle control lever controls engine speed and selects F (forward), N (neutral), or R (reverse) gears.

Moving the control lever 32° from N (neutral) selects the gear, and further movement increases engine speed.


The control lever automatically locks itself in the N (neutral) position.

To move the lever out of the N (neutral) position, you must squeeze the neutral release lever on the underside of the lever handle.

A friction adjuster adjusts the operating resistance of the control lever(s). (P.90)

Less friction allows easier control lever movement. More friction helps to hold a steady throttle setting while cruising.

Fast Idle Lever



The BF115J, BF140A, and BF150D model uses programmed fuel injection, so this mode will not be needed for starting. After the engine starts and if the outside temperature is below 41°F(5°C), the fast idle mode can be used to accelerate engine warmup.


See page 78 for engine warm-up instructions.

The fast idle lever allows you to increase the idle speed only when the control lever is in the N (neutral) position.

Place the fast idle lever in its lowest position to cancel the fast idle and return the control lever to normal operation.

CONTROLS AND FEATURES

Flush-mount type



The gearshift/throttle control lever controls engine speed and selects F (forward), N (neutral), or R (reverse) gears.

Moving the control lever 35° from N (neutral) selects the gear, and further movement increases engine speed.


The control lever automatically locks itself in the N (neutral) position.

To move the lever out of the N (neutral) position, you must squeeze the neutral release lever on the underside of the lever handle.

A friction adjuster near the base of the control lever adjusts the operating resistance of the control lever. (P.90)

Less friction allows easier control lever movement. More friction helps to hold a steady throttle setting while cruising.

Fast Idle Button



The BF115J, BF140A, and BF150D model uses programmed fuel injection, so this mode will not be needed for starting. After the engine starts and if the outside temperature is below 41°F(5°C), the fast idle mode can be used to accelerate engine warmup.

See page 81 for engine warm-up instructions.


The fast idle button allows you to increase the idle speed without engaging the drive gears. Move the control lever forward or reverse after pushing in the fast idle button to increase the idle speed.

It is necessary to position the control lever in the N (neutral) position to push in the fast idle button.

Return the control lever to N (neutral) position to cancel the fast idle operation.

CONTROLS AND FEATURES

Top-Mount type




The gearshift/throttle control lever(s) controls engine speed and selects F (forward), N (neutral), or R (reverse) gears.

Moving the control lever 35° from N (neutral) selects the gear, and further movement increases engine speed.

A friction adjuster inside the control box adjusts the operating resistance of the control lever(s). (P.90)

Less friction allows easier control lever movement. More friction helps to hold a steady throttle setting while cruising.

Fast Idle Button



The BF115J, BF140A, and BF150D model uses programmed fuel injection, so this mode will not be needed for starting. After the engine starts and if the outside temperature is below 41°F(5°C), the fast idle mode can be used to accelerate engine warmup.

See page 81 for engine warm-up instructions.

The fast idle button allows you to increase the idle speed without engaging the drive gears. Move the control lever forward or reverse after pushing in the fast idle button to increase the idle speed.



It is necessary to position the control lever in the N (neutral) position to push in the fast idle button.

Return the control lever to N (neutral) position to cancel the fast idle operation.



CONTROLS AND FEATURES

Select Switches (DBW type)

(Flush-mount type, Single top-mount type)



(Dual top-mount type)



Select switches are used for operations in the fast idle mode, trolling control mode, one-lever mode, active mode, cruise control mode and trim support mode.

Indicators on select switches

Indicator	On	Flashing	Off
NEUTRAL	The gearshift/throttle control lever is in the NEUTRAL position	Fast idle mode is on	The gearshift/throttle control lever is in the FORWARD or REVERSE position
CRUISE/UP	Cruise control mode is on	Cruise control mode is paused	Cruise control mode is off
TROLL/DN	Trolling control mode is on	Trolling control mode is on And Fast idle mode is on	Trolling control mode is off
TRIM SPT.	Trim support mode is on	Trim support mode is paused	Trim support mode is off
FAST IDLE	-	Fast idle mode is on	Fast idle mode is off
ACTIVE	Active mode is on	-	Active mode is off
1 LEVER	One-lever mode is on	-	One-lever mode is off
ACTIVE/FAST IDLE	Active mode is on And Fast idle mode is off	Active mode is on And Fast idle mode is on	Active mode is off And Fast idle mode is off

CONTROLS AND FEATURES

ACTIVE Switch, ACTIVE/FAST IDLE Switch

For multiple station type, use the ACTIVE switch or ACTIVE/FAST IDLE switch to change the operating remote control (active mode).

If you press the ACTIVE switch or ACTIVE/FAST IDLE switch on the remote control you want to operate the outboard motors when all gearshift/throttle control levers are in the NEUTRAL position, the mode changes to active mode.

This allows the active remote control to control the engine. All other remote controls are switched off.

FAST IDLE Switch, ACTIVE/FAST IDLE Switch


If you press the FAST IDLE switch or ACTIVE/FAST IDLE switch on the remote control in active mode when the gearshift/throttle control levers are in the NEUTRAL position, the mode changes to the fast idle mode. You can adjust the engine speed by lowering the gearshift/throttle control lever to the FORWARD or REVERSE side.

In the case of dual top-mount remote control, the mode changes to the fast idle mode only for an engine whose gearshift/throttle control levers are in the NEUTRAL position.


The BF115J, BF140A, and BF150D models uses programmed fuel injection, so this mode will not be needed for starting. After the engine starts and if the outside temperature is below 41°F (5°C), the fast idle mode can be used to accelerate engine warm-up.

- You cannot turn on the fast idle mode without putting the gearshift/throttle control lever in the NEUTRAL position.
- If remote controls are mounted at two places, changing of fast idle mode can be done only with the remote control that is in active mode (P.42).
- To release the fast idle mode, press the FAST IDLE switch or ACTIVE/FAST IDLE switch with all the gearshift/throttle control levers put in the NEUTRAL position.
- When fast idle mode is released, a short buzz sounds twice.


(Flush-mount type)



(Single top-mount type)




(Dual top-mount type)



CONTROLS AND FEATURES

TROLL/DN Switch

After the engine warms up, when the gearshift/throttle control levers are tilted from the NEUTRAL position to the FORWARD or REVERSE side by about 20° and the TROLL/DN switch of the remote control is pressed, the mode changes to trolling control mode.



The engine speed can be adjusted with the CRUISE/UP switch and TROLL/DN switch when in trolling control mode.

After the mode changes to the trolling mode, the engine speed is 650 rpm.

Engine speed adjusting range:
650 rpm to 900 rpm (in steps of 50 rpm)

When in trolling control mode, trolling control mode is not released even if you put the gearshift/throttle control lever in the NEUTRAL position. By shifting from NEUTRAL to FORWARD or REVERSE again, the boat will cruise at the set engine speed.

⚠ CAUTION

While in trolling control mode, check whether the mode indicator is ON/OFF before shifting the gearshift/throttle control lever from the NEUTRAL position to the FORWARD or REVERSE position. Operating the gearshift/throttle control lever while trolling control mode is ON creates a risk of collision or injury due to an unexpected sudden start, which is caused by the engine starting to cruise at the speed set for trolling control mode, not by how far the throttle is opened.

- If the engine is not finished warming up, it cannot go into trolling mode. So, warm up the engine (P. 74).
- If remote controls are mounted at two places, the changing of trolling control mode can be done only with the remote control that is in active mode (P.75).
- You can force the release of trolling control mode by using the gearshift/throttle control lever to increase the engine speed to 3,000 rpm or higher.
- To release the trolling control mode, press and hold the TROLL/DN switch.
- When the trolling control mode is released, a short buzz sounds twice.

1 LEVER Switch (For dual top-mount type)

Shifting gear and the engine speed adjustment of all the outboard motors can be performed with one gearshift/throttle control lever when in one-lever mode.

If you press the 1 LEVER switch on the remote control in active mode when all gearshift/throttle control levers are in the NEUTRAL position, the mode changes to one-lever mode.

- If remote controls are mounted at two places, the changing of one-lever mode can be done only with the remote control that is in active mode (P.42).

- To release one-lever mode, press and hold the 1 LEVER switch with the gearshift/throttle control lever in the NEUTRAL position.
- When one-lever mode is released, a short buzz sounds twice.
- To use one-lever mode the next time you are boating, turn the engine switch or the power switch off while in one-lever mode so that the next time you go boating the one-lever mode will be on.

CONTROLS AND FEATURES

CRUISE/UP Switch

If you press the CRUISE/UP switch during cruising with all the gearshift/throttle control levers in the FORWARD position, the mode changes to the cruise control mode, which lets the boat cruise at a constant engine speed or velocity.

- Speed can only be adjusted in cruise control mode when equipped with GPS.

NOTICE

- Operations may be inconsistent, depending on the GPS that you are using. Consult your dealer for more information about GPS.

In the cruise control mode, pressing the CRUISE/UP switch increases the engine speed or velocity and pressing the TROLL/DN switch decreases it.

Engine speed adjusting range:

Engine speed at mode change $\pm$ 500 rpm (in steps of 50 rpm)

Velocity adjusting range:

- Velocity at mode change $\pm$ 10 km/h (in steps of 1.0 km/h)
- Velocity at mode change $\pm$ 5 miles/h (in steps of 0.5 miles/h)
- Velocity at mode change $\pm$ 5 knots (in steps of 0.5 knots)

- To select whether to adjust the engine speed or velocity in the cruise control mode, use a Honda multi-function display.
- If remote controls are mounted at two places, the changing of cruise control mode can be done only with the remote control that is in active mode (P.42).
- The mode does not change to the cruise control mode in the following cases.
 - GPS has not been started (Velocity adjustment is selected in the multi-function display)
 - The trolling control mode is on
 - In the case of multiple outboard engines, when even one of the outboard engines has stopped

- The cruise control mode is stopped temporarily if you make a turn or turn the boat continuously.
 - To release the cruise control mode, press and hold the CRUISE/UP switch.
 - When the cruise control mode is released, a short buzz sounds twice.
 - The cruise control mode is released forcibly in the following cases.
 - GPS error or disconnection (Velocity adjustment is selected in the multi-function display)
 - Engine stops or engine is abnormal (overheating, low oil pressure, etc.)
 - If the engine RPM or speed is unstable
- Operate the gearshift/throttle control lever is moved beyond as set amount or shift to the opposite of the set amount.*
- * Operation of a set amount
- If you put the engine speed at 3,000 rpm, switch to cruise control mode, and use the CRUISE/UP switch to adjust to 3,500 rpm
 - The mode is forcibly released by operating the gearshift/throttle control lever to the FORWARD side to increase the engine speed to 3,500 rpm or more.
 - The mode is forcibly released immediately if the gearshift/throttle control lever is operated to the REVERSE side.
- If you put the engine speed at 3,000 rpm, switch to cruise control mode, and use the TROLL/DN switch to adjust to 2,500 rpm
 - When the gearshift/throttle control lever is operated to the REVERSE side and the engine speed exceeds 2,500 rpm, the mode is forcibly released.
 - The mode is forcibly released immediately if the gearshift/throttle control lever is operated to the FORWARD side.
 - The mode is forcibly released immediately by putting the gearshift/throttle control lever in NEUTRAL.

CONTROLS AND FEATURES

TRIM SPT. Switch

Pressing the TRIM SPT. switch changes the mode to the trim support mode, which automatically does trim operations according to the speed or engine RPM.

The conditions that control the trim operation (engine RPM and speed) and the trim angle pattern are set in the multi-function display.

For information about how to use the power trim/tilt switch, see page 48.

- If remote controls are mounted at two places, the changing of trim support mode can be done only with the remote control that is in active mode (P.42).
- To release the trim support mode, press the TRIM SPT. switch.


- When trim support mode is released, a short buzz sounds twice.

COMMON CONTROLS


Power Trim/Tilt Switch

(Flush-mount type(DBW type))

GEARSHIFT/THROTTLE
CONTROL LEVER




(Single top-mount type (DBW type))



POWER TRIM/TILT SWITCH


Dual top-mount type (DBW type)

**GEARSHIFT/THROTTLE
CONTROL LEVERS**




POWER TRIM/TILT SWITCH

(Side-mount type
(Mechanical wire type))




POWER TRIM/TILT SWITCH

(Flush-mount type
(Mechanical wire type))



POWER TRIM/TILT SWITCH

(Single top-mount type
(Mechanical wire type))




POWER TRIM/TILT SWITCH

CONTROLS AND FEATURES

(Dual top-mount type
(Mechanical wire type))

POWER TRIM/TILT SWITCH
(Left and right operations are
interlocked)

**GEARSHIFT/THROTTLE
CONTROL LEVER**



**POWER TRIM/
TILT SWITCH**
(Left side
operation only)

**POWER TRIM/
TILT SWITCH**
(Right side
operation only)

The power trim/tilt switch is located on the gearshift/throttle control lever. It is a rocker switch with UP and DN (down) positions for changing the angle of the outboard motor.

You can use the power trim/tilt switch anytime whether the boat is underway, stopped, or the ignition switch is in the OFF position.


Trim the outboard motor to obtain the best performance and stability. For details about the power trim, see page 93.

Tilt the outboard motor for shallow water operation, beaching, launching, or mooring. For details about the power tilt, see page 103.

For multiple outboard motors, tilt them up at the same time.


Power Trim/Tilt Switch Panel

DUAL TYPE



POWER TRIM/TILT SWITCHES


TRIPLE TYPE



POWER TRIM/TILT SWITCHES

For multiple outboard motors, the trim/tilt angle of all outboard motors is adjusted at the same time by using the power trim/tilt switch on the gearshift/throttle control lever and the trim/tilt angle of each outboard motor is adjusted by using each power trim/tilt switch on the remote control (Top-mount type (Mechanical wire type)) or the panel.

Power Tilt Switch



POWER TILT SWITCH

The power tilt switch is located on the engine pan. It is a rocker switch with UP and DN (down) positions for changing the angle of the outboard motor.

The power tilt switch operates without turning the ignition switch ON.


This switch is used, while the engine is stopped, to raise the outboard motor for mooring, trailering, or maintenance.

⚠ CAUTION

Do not operate the power tilt switch on the outboard motor cover while cruising. You can lose control of your balance, fall, and be injured by the moving outboard, propeller, or boat. Always use the gearshift/throttle control lever or the power trim/tilt switch on the switch panel while under way.

CONTROLS AND FEATURES

Manual Relief Valve



The outboard motor can be tilted manually after opening the manual relief valve. This allows the outboard motor to be tilted down when no battery is connected.

⚠ DANGER

Check that nobody is under the outboard motor before opening the manual relief valve. If the manual relief valve is loosened (turned counterclockwise) when the outboard motor is tilted up, the outboard motor will suddenly tilt down.

⚠ CAUTION

The manual relief valve must be tightened securely before operating the outboard motor otherwise the outboard motor could tilt when operating in reverse.

NOTICE

- If there is not enough clearance to the ground, opening the manual relief valve may cause the outboard motor to contact the ground and be damaged.

Tilt Lock Lever



TILT LOCK LEVER (each side)


The tilt lock levers are used to support the outboard motor in the fully raised position (P.103).

When the boat is to be moored for a long time, tilt the outboard motor up as far as it will go. Then move the tilt lock levers to the LOCK position, and gently lower the outboard motor until the lever contacts the stern bracket.

NOTICE

- Before tilting it up, leave the outboard motor in the running position for one minute after stopping the engine to drain the water from inside the engine.
- Be careful that while the outboard motor is tilted up that it does not collide with the pier or other boats.

TILT LOCK LEVER (each side)




⚠ CAUTION

If you do not secure the outboard motor with the tilt lock levers after tilting it up to the highest position, then the hydraulic pressure of the power trim/tilt may decrease and cause the outboard motor to tilt down.

CONTROLS AND FEATURES


TRL (Trolling) Control Switch (optional equipment for Mechanical wire type)

(Trolling Control Switch Panel)




TRL (Trolling)
CONTROL SWITCH

(Side-mount type)




TRL (Trolling)
CONTROL SWITCH*

(Single top-mount type)



TRL (Trolling)
CONTROL SWITCH*

(Dual top-mount type)



TRL (Trolling)
CONTROL SWITCH*


* For TRL (Trolling) control switch
equipped type.

The TRL (Trolling) control switch is a rocker switch with UP and DN (down) positions to adjust the trolling speed up or down in 50 rpm increments within the range of 650 to 900 rpm.


If you press and hold the TRL control switch while cruising with the throttle closed and the engine in gear, the mode changes to trolling mode (p. 96).

Engine Cover Latches

Front




Side



The engine cover latches fasten the engine cover to the outboard motor. Refer to ENGINE COVER REMOVAL AND INSTALLATION on P.120.

Trim Tab




The trim tab compensates for "torque steer," which is a reaction of the outboard motor to propeller rotation.

If uncompensated, torque steer would make the outboard motor tend to turn to one side.

When the trim tab is correctly adjusted (p. 119), steering effort is equal in either direction.

Tachometer (optional equipment)



TACHOMETER


The tachometer shows engine speed in revolutions per minute.

Refer to the tachometer when using the throttle and power trim/tilt controls to achieve the best performance from the boat.

CONTROLS AND FEATURES

NMEA Interface Coupler

The NMEA2000® interface coupler connects the outboard motor to the boat's NMEA2000® network through an interface cable and transmits information such as engine information and warnings to the control panel and gauges. Contact your dealer for more information.



NMEA INTERFACE COUPLER

Operating Hour Notification System

This outboard motor engine counts the number of operating hours since the last periodic maintenance. When the next periodic maintenance is due, the engine notifies the NMEA2000® network, and a maintenance indication is displayed on an NMEA2000®-compatible device.

After periodic maintenance is performed, reset the hour counter by:

1. Turn ON the power switch or ignition switch.
(The buzzer will sound twice.)
2. Insert and remove the emergency stop switch clip five times within 20 seconds.
 - When reset, the buzzer will sound once.


NOTICE

- The operating hours can be reset when all of the following conditions are met.
 - The engine is stopped
 - The gearshift is in neutral
 - The gearshift/throttle control lever is in the NEUTRAL position
 - Buzzer is not sounding
 - Automatic tilt is not operating
- If the operating hours are not reset, contact the authorized marine dealer.

Periodic maintenance is required when either the operating hours or the time since last maintenance reaches the prescribed limit. Therefore, periodic maintenance may be required based on the number of months since the last maintenance before the alert based on engine operating hours appeared (see MAINTENANCE SCHEDULE on page 116).

Reset the hour counter whenever maintenance is performed, whether based on the time interval or the number of operating hours.

Operating hour notification timing



CONTROLS AND FEATURES

Periodic maintenance display

- Notification about periodic maintenance is displayed on the multi-function display when the power switch or the engine switch is turned on.
- The notification for periodic maintenance remains displayed after the engine is started.
- The display disappears when the gearshift/throttle control lever is put in the FORWARD or REVERSE position.

NMEA2000®-compatible display:

- Follow the instructions on the display.
- If the display allows selection of notification to be preset, select "Notify" (or equivalent).

- Turn on the power supply to the display before turning on the ignition switch of the outboard motor.
- The indication may differ, depending on the type of display.

When "Periodic Maintenance" is indicated:

1. Have the periodic maintenance performed without delay after returning to port.
2. Reset the hour counter. If not reset, the maintenance indication will remain in the display, and the hour count until the next maintenance will be in error.

When the periodic maintenance is conducted before "Periodic Maintenance" is indicated, reset the hour counter. If not reset, the hour count until the next maintenance will be in error.

INDICATORS

DBW type

Check the indicators displayed on the multi-function display. For information about NMEA2000®-compatible device displays, refer to the display device's manual.


Mechanical wire type

The indicator lights come on and the buzzer sounds when you turn the ignition switch ON, allowing you to see that they are working. If an indicator does not light during this test, it cannot alert you if that system develops a problem. Have your Marine dealer check for burned-out bulbs or other problems.


Under normal conditions, the following occur when the ignition switch is turned ON:

1. The ACG, Malfunction, Oil Pressure, and Overheat indicators light.
2. The buzzer will beep twice.
3. The Malfunction, Oil Pressure, and Overheat indicators will go out after the second beep.
4. The ACG indicator will go out after the engine starts.
5. The Oil Pressure indicator will light again after the engine starts and will stay lit to indicate the oil pressure is normal.

Alternator (ACG) Indicator (Multi-function Display)




(Side-mount type (Mechanical wire type))



CONTROLS AND FEATURES

(Control panel with indicators type
(Mechanical wire type))


ACG INDICATOR




The ACG indicator turns on and the buzzer sounds in one-second intervals when the charging system is faulty.

Malfunction Indicator

(Multi-function Display)




(Side-mount type
(Mechanical wire type))



(Control panel with indicators type
(Mechanical wire type))

MALFUNCTION INDICATOR



When the engine control system detects an engine control system malfunction, the malfunction indicator turns on.


When the malfunction indicator turns on, the buzzer sounds continuously with an intermittent long sound.

- If the malfunction indicator lights and the buzzer does not stop sounding: Return to port immediately without continuing your voyage. There is a risk of shift operation failure (see page 167), alert detection failure, or engine start failure.
- If the malfunction indicator lights and the buzzer sounds for only 10 seconds: Return to port as soon as possible because engine speed control and other functions will be limited.

Low Oil Pressure Indicator or Oil Pressure Indicator

Low Oil Pressure Indicator (Multi-function Display)

(Multi-function Display)




If oil pressure becomes low, the indicator comes on, and the engine protection system limit engine speed. Refer to TAKING CARE OF UNEXPECTED PROBLEMS, on P.151.

All models are equipped with a buzzer that sounds continuously when the low oil pressure indicator comes on.

Low oil pressure indicates that the engine oil level is low or that there is a problem with the engine lubrication system.

Oil Pressure Indicator (Side-mount type (Mechanical wire type), Control panel with indicators type (Mechanical wire type))


(Side-mount type (Mechanical wire type))



CONTROLS AND FEATURES

(Control panel with indicators type
(Mechanical wire type))

OIL PRESSURE INDICATOR



When the oil pressure indicator is lit, oil pressure is OK.


If oil pressure becomes low, the indicator will go off, and the engine protection system will limit engine speed. Refer to TAKING CARE OF UNEXPECTED PROBLEMS, on P. 151.

All models are equipped with a buzzer that sounds continuously


when the oil pressure indicator goes off.

Low oil pressure indicates that the engine oil level is low or that there is a problem with the engine lubrication system.

Overheat Indicator (Multi-function Display)




(Side-mount type
(Mechanical wire type))



(Control panel with indicators type
(Mechanical wire type))

OVERHEAT INDICATOR




When the alert triggers, the overheat indicator comes on and the buzzer sounds a steady tone as the engine speed is reduced to 1,800 rpm. If the condition persists for another 20 seconds, the engine shuts off. Refer to TAKING CARE OF UNEXPECTED PROBLEMS, on P.151.

All models are equipped with a buzzer that sounds continuously when the red overheat indicator light comes on.

Engine overheating may be the result of clogged water intakes.

Cooling System Indicator

COOLING SYSTEM INDICATOR



Water should flow from the cooling system indicator while the engine is running. This shows that water is circulating through the cooling system.

If water stops flowing while the engine is running, it indicates a cooling system problem, such as clogged water intakes, which will cause engine overheating.

CONTROLS AND FEATURES


The cooling system indicator discharge port can also become plugged.

If this happens, shut off the engine immediately and inspect the intake screens.

OTHER FEATURES

Water Separator Buzzer

WATER SEPARATOR



The water separator buzzer sounds a rapid, repeating signal when water has accumulated in the water separator.

Rev Limiter


The engine is equipped with a rev limiter to prevent the possibility of mechanical damage from excessive engine speed.

The rev limiter may be activated during operation, limiting engine speed, if the outboard motor is trimmed or tilted up excessively, or when propeller ventilation occurs during a sharp turn.

If the rev limiter is activated, check the trim angle of the outboard motor.

Check to see if the correct propeller is installed.

Anodes



The anodes are made of a sacrificial material that helps to protect the outboard motor from corrosion.


There are two anodes on the gear case, one on the stern bracket (P.137).

Additional anodes are located inside the engine and should be serviced by an authorized Honda Marine servicing dealer according to the MAINTENANCE SCHEDULE (P.116).

NOTICE

- Painting or coating the anodes will defeat their purpose and will lead to rust and corrosion damage to the outboard motor. The anodes must be exposed to the water in order to protect the outboard motor.

Fuel Priming Bulb



A priming bulb is built into the fuel hose that connects the fuel tank to the outboard motor.

Before starting the engine, hold the priming bulb up in the direction of the arrow; then squeeze the priming bulb until it feels firm. This will ensure that fuel is supplied to the engine (P.71).


CONTROLS AND FEATURES

Battery Switch OFF Notification

This function alerts the operator that the boat's battery switch is OFF and must be turned to the ON position. If the battery switch is OFF, a buzzer will sound three times during the following situations.

- When starting the engine
- When using the power trim/tilt switch
- When turning the battery switch OFF while the ignition switch or power switch is ON

Power Reduction



This outboard motor is equipped with the power reduction system which activates when the outboard motor has a serious problem.

The power reduction system decreases the engine speed to protect the engine until the malfunction is corrected.

When one of the two systems of the remote control sensor is faulty, the power reduction system does not decrease the engine speed.

ARE YOU READY TO GET UNDERWAY?

Your safety is your responsibility. A little time spent in preparation will significantly reduce your risk of injury.

Knowledge

Read and understand this manual. Know what the controls do and how to operate them.

Familiarize yourself with the outboard motor and its operation before you get underway. Know what to do in case of an emergency.

Familiarize yourself with all laws and regulations relating to boating and the use of outboard motors.

Safety

Always wear a PFD (Personal Flotation Device) while on the boat.

Attach the emergency stop switch lanyard securely to the operator or to the PFD worn by the operator.

IS YOUR OUTBOARD MOTOR READY TO GO?

For your safety, and to maximize the service life of your equipment, it is very important to take a few moments before you operate the outboard motor to check its condition. Be sure to take care of any problem you find, or have your authorized Marine dealer correct it, before you operate the outboard motor.

BEFORE OPERATION

WARNING

Failure to properly maintain this outboard motor, or failing to correct a problem before operation, could result in a significant malfunction.

Some malfunctions can cause serious injuries or death.

Always perform a pre-operation inspection before each operation and correct any problems.

Normal Key without START/STOP Switch Type

Before beginning your pre-operation checks, be sure the IGNITION switch key is in the OFF position.

Normal Key with START/STOP Switch Type

Before beginning your pre-operation checks, be sure the power switch is in the OFF position.

Safety Inspection

- Before each use, look around and underneath the engine for signs of oil or gasoline leaks.
- Check that the fuel hose is undamaged and properly connected.
- Wipe up any spills before starting the engine.
- Check the stern bracket to be sure the outboard motor is securely installed.
- Check that all controls are operating properly.
- Replace any damaged parts.
- Check that all fasteners are in place and securely tightened.

- Check the emergency stop switch for proper operation. Start the engine (P.72). Make sure the engine stops by pulling the emergency stop switch clip from the emergency stop switch.

Maintenance Inspection

- Check the engine oil level (P.122). Running the engine with a low oil level can cause engine damage. Overfilling the engine can cause the engine to smoke or have oil leaks which can cause engine damage.
- When you check the oil level with the dipstick, you might notice the engine oil appears milky or the oil level has increased. If you notice either condition, change the engine oil.
- Check to be sure the propeller is undamaged and the castle nut is secured with the cotter pin (P.138).
- Check that the anodes are securely attached to the stern bracket and the gear case (P.137) and are not excessively worn. The anodes help protect the outboard motor from corrosion.
- Make sure the tool kit is onboard (P.115). Replace any missing items.
- Check the fuel level in the fuel tank (P.132).
- Check that the battery fluid is between the upper and lower levels, and the battery leads are connected securely.
- Check the fuel filter for water or sediment accumulation (P.135).
- Remove the engine cover and check for water in the outboard motor or evidence of leaks.

OPERATION

SAFE OPERATING PRECAUTIONS

To safely realize the full potential of this outboard motor, you need a complete understanding of its operation and a certain amount of practice with its controls.

Before operating the outboard motor for the first time, please review the IMPORTANT SAFETY INFORMATION on page 7 and the chapter titled BEFORE OPERATION.

For your safety, do not start or run the engine in a confined or partly enclosed area. Your engine's exhaust contains poisonous carbon monoxide, a colorless, odorless gas that can collect rapidly. Breathing carbon monoxide can cause loss of consciousness and may lead to death.

WARNING

Exhaust contains poisonous carbon monoxide gas that can build up to dangerous levels in closed areas.

Breathing carbon monoxide can cause unconsciousness or death.

Never run this product's engine in a closed, or even partly closed area.

BREAK-IN PROCEDURE

Break-in period: 10 hours

Proper break-in operation allows the moving parts to wear in smoothly for best performance and long service life. Avoid continuous operation at a steady speed.

First 15 minutes:

Run the engine at trolling speed. Use the minimum throttle opening necessary to operate the boat at a safe trolling speed.

Next 45 minutes:

Run the engine up to a maximum of 2,000 - 3,000 rpm, which is about 10% to 30% of maximum throttle opening. Operating at a maximum of 2,000 - 3,000 rpm should be limited to 50% of the 45 minutes.

Next 60 minutes:

Run the engine up to a maximum of 4,000 - 5,000 rpm, which is about 50% to 80% of maximum throttle opening. Operating at a maximum of 4,000 - 5,000 rpm should be limited to 50% of the 60 minutes.


30-second full-throttle bursts are OK, but do not operate the engine continuously at full throttle.

For boats that plane easily, bring the boat up on plane, and then reduce the throttle opening to the recommended rpm range.

Next 8 hours:

Do not run the engine at full throttle for more than 5 minutes at a time.

FUEL PRIMING



Hold the priming bulb up in the direction of the arrow; then squeeze the priming bulb several times until it feels firm, indicating that fuel has reached the engine.

Check to be sure there are no fuel leaks before starting the engine.

Do not touch the priming bulb while the engine is running or when tilting up the outboard motor. The vapor separator could overflow.

⚠ WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and let it cool before handling fuel.
- Keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Keep away from your vehicle.
- Wipe up spills immediately.

OPERATION

INFREQUENT OR OCCASIONAL USE


If your outboard motor will be used on an infrequent or intermittent basis, please refer to the fuel section of the STORAGE chapter (P.143) for additional information regarding fuel deterioration.

STARTING THE ENGINE

Make sure the boat's battery switch is ON before turning ON the ignition switch or power switch. If the battery switch is OFF while attempting to start the engine, the buzzer will sound three times.

DBW type

EMERGENCY STOP SWITCH




1. Put the emergency stop switch clip in the emergency stop switch, and attach the emergency stop switch lanyard securely to the operator or to the operator's PFD (Personal Flotation Device).

The engine will not start or run unless the emergency stop switch clip is in the emergency stop switch.


The emergency stop switch clip and emergency stop switch lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.

Always attach the emergency stop switch lanyard securely to the operator or to the operator's PFD before starting the engine.

- Set the control lever in the NEUTRAL position.
The engine will not start if the FORWARD or REVERSE gears are engaged.



(Normal Key without START/STOP Switch Type)



IGNITION SWITCH KEY


- Turn the ignition switch key to the START position until the engine starts.
When the engine starts, release the key, allowing it to return to the ON position.
Go to step 5.

NOTICE

- The starter motor consumes a large amount of current. Do not run it continuously. If the engine does not start, wait at least 10 seconds before running the starter motor again.


OPERATION

(Normal Key with START/STOP Switch Type)



3. Insert the key into the power switch and turn it to the ON position.

START/STOP SWITCH



4. Push the start/stop switch.

NOTICE

- The starter motor consumes a large amount of current. Do not run it continuously. If the engine does not start, wait at least 10 seconds before running the starter motor again.

5. Before getting underway, allow the engine to warm-up sufficiently to ensure good performance.
If the temperature is above 41°F (5°C), allow the engine to idle for at least 3 minutes to warm up.
Below 41°F (5°C), warm-up the engine for at least 5 minutes at 2,000 rpm. Press the fast idle button to activate it, and then use the throttle lever to achieve approximately 2,000 rpm.

NOTICE


- If the engine is not properly warmed up before raising the engine speed, the buzzer and overheat indicator may activate and the engine speed will be automatically reduced.
- The cooling system may freeze in areas where the temperature reaches 32°F (0°C) or below. Cruising at high speed without warming the engine up may cause engine damage.

During the warm-up period, check the low oil pressure indicator (P.61), overheat indicator (P.62), and cooling system indicator (P.63).

If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to TAKING CARE OF UNEXPECTED PROBLEMS on P.151.


Active Mode

(Flush-mount type)




ACTIVE SWITCH

(Single top-mount type)



ACTIVE SWITCH

(Dual top-mount type)



ACTIVE/FAST IDLE SWITCH

For multiple station type, use the ACTIVE switch or ACTIVE/FAST IDLE switch to change the operating remote control (active mode).


If you press the ACTIVE switch or ACTIVE/FAST IDLE switch on the remote control you want to operate the outboard motors when all gearshift/throttle control levers are in the NEUTRAL position, the mode changes to active mode.

OPERATION

Mechanical wire type

Side-Mount Type

EMERGENCY STOP SWITCH



EMERGENCY STOP SWITCH LANYARD


EMERGENCY STOP SWITCH CLIP

1. Put the emergency stop switch clip in the emergency stop switch, and attach the emergency stop switch lanyard securely to the operator or to the operator's PFD (Personal Flotation Device).

The engine will not start or run unless the emergency stop switch clip is in the emergency stop switch.


The emergency stop switch clip and emergency stop switch lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.

Always attach the emergency stop switch lanyard securely to the operator or to the operator's PFD before starting the engine.



GEARSHIFT/THROTTLE CONTROL LEVER


2. Set the control lever in the N (neutral) position.
The engine will not start if the F (forward) or R (reverse) gears are engaged.



3. Leave the fast idle lever in the OFF (fully lowered) position.

The fast idle lever cannot be raised unless the control lever is in the N (neutral) position.

The control lever cannot be moved away from the N (neutral) position unless the fast idle lever is lowered.



4. Turn the ignition switch key to the ON position; the buzzer will sound twice.
5. Turn the ignition switch key to the START position and hold it there until the engine starts.


When the engine starts, release the key, allowing it to return to the ON position.

If the engine fails to start within 5 seconds, release the key and wait at least 10 seconds before operating the starter again.

NOTICE

- The starter motor consumes a large amount of current. Do not run it continuously. If the engine does not start, wait at least 10 seconds before running the starter motor again.

OPERATION



6. Before getting underway, allow the engine to warm-up sufficiently to ensure good performance.

If the temperature is above 41°F (5°C), allow the engine to idle for at least 3 minutes to warm up.

Below 41°F (5°C), warm-up the engine for at least 5 minutes at 2,000 rpm. Raise the fast idle

lever to achieve approximately 2,000 rpm.

NOTICE

- If the engine is not properly warmed up before raising the engine speed, the buzzer and overheat indicator may activate and the engine speed will be automatically reduced.
- The cooling system may freeze in areas where the temperature reaches 32°F (0°C) or below. Cruising at high speed without warming the engine up may cause engine damage.

During the warm-up period, check the oil pressure indicator (P.61), overheat indicator (P.62), and cooling system indicator (P.63).


If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to TAKING CARE OF UNEXPECTED PROBLEMS on P.151.

7. If the fast idle lever was used to warm-up the engine, gradually lower the lever as the engine warms up.

When the fast idle lever is fully lowered, the control lever can be moved away from the N (neutral) position.

Flush-mount type, Top-mount type

EMERGENCY STOP SWITCH



EMERGENCY STOP SWITCH LANYARD

EMERGENCY STOP SWITCH CLIP

1. Put the emergency stop switch clip in the emergency stop switch, and attach the emergency stop switch lanyard securely to the operator or to the operator's PFD (Personal Flotation Device).


The engine will not start or run unless the emergency stop switch clip is in the emergency stop switch.

The emergency stop switch clip and emergency stop switch lanyard system is a safety device that will stop the engine if you fall away from the controls while operating the boat.

Always attach the emergency stop switch lanyard securely to the operator or to the operator's PFD before starting the engine.

(Flush-mount type)


NEUTRAL



GEARSHIFT/THROTTLE CONTROL LEVER

(Top-mount type)


NEUTRAL



GEARSHIFT/THROTTLE CONTROL LEVER

OPERATION

- Set the control lever in the N (neutral) position.
The engine will not start if the F (forward) or R (reverse) gears are engaged.



- Turn the ignition switch key to the ON position; the buzzer will sound twice.
- Turn the ignition switch key to the START position and hold it there until the engine starts.


When the engine starts, release the key, allowing it to return to the ON position.

If the engine fails to start within 5 seconds, release the key and wait at least 10 seconds before operating the starter again.


NOTICE

- The starter motor consumes a large amount of current. Do not run it continuously. If the engine does not start, wait at least 10 seconds before running the starter motor again.

(Flush-mount type)



(Top-mount type)



5. Before getting underway, allow the engine to warm-up sufficiently to ensure good performance.

If the temperature is above 41°F (5°C), allow the engine to idle for at least 3 minutes to warm up.

Below 41°F (5°C), warm-up the engine for at least 5 minutes at 2,000 rpm. Push the fast idle button, and then move the control lever forward or reverse to open the throttle and achieve approximately 2,000 rpm.

NOTICE

- If the engine is not properly warmed up before raising the engine speed, the buzzer and overheat indicator may activate and the engine speed will be automatically reduced.
- The cooling system may freeze in areas where the temperature reaches 32°F (0°C) or below. Cruising at high speed without warming the engine up may cause engine damage.

During the warm-up period, check the oil pressure indicator (P.61), overheat indicator (P.62), and cooling system indicator (P.63).

If the indicators show any abnormal condition, immediately stop the engine and determine the cause of the problem. Refer to TAKING CARE OF UNEXPECTED PROBLEMS on P.151.

6. If the fast idle control was used to warm-up the engine, gradually return the control lever to the N (neutral) position as the engine warms up.

OPERATION


STOPPING THE ENGINE

After stopping the engine, be sure to turn OFF the ignition switch or power switch before turning OFF the boat's battery switch. If the battery switch is turned OFF while the ignition switch or power switch is ON, the buzzer will sound three times briefly.

DBW type

Emergency Engine Stopping

EMERGENCY STOP SWITCH CLIP



EMERGENCY STOP SWITCH LANYARD

To stop the engine in an emergency, pull the emergency stop switch lanyard. To stop the engine in an emergency, pull the emergency stop switch lanyard.

If the emergency stop switch is activated while the engine is running, the engine will shut down abruptly and the boat will quickly decelerate, potentially causing occupants and objects to be thrown forward and/or overboard.

If the emergency stop switch is activated, the emergency stop switch clip must be reinserted before the engine can be restarted.

We suggest that you stop the engine this way occasionally to verify that the emergency stop switch is operating properly.


Before leaving the dock, check the operation of the emergency stop switch.

Turn the ignition switch key to the OFF position after verifying the emergency stop switch operation.

NOTICE


- When you have stopped the engine with the emergency stop switch, be sure to turn off the ignition switch key or the power switch. Leaving the ignition switch key or power switch ON will drain the battery.

Normal Engine Stopping



1. Move the control lever(s) to the NEUTRAL position.
After cruising at full throttle, cool down the engine by idling for a few minutes before stopping the engine.

(Normal Key without START/STOP Switch type)




2. Turn the ignition switch key to the OFF position to stop the engine.
In the event that the engine does not stop when the ignition switch key is turned to the OFF position, pull the emergency stop switch clip out of the emergency stop switch by pulling the emergency stop switch lanyard (P.82).

OPERATION


3. When the boat is not in use, remove and store the ignition switch key and the emergency stop switch clip and lanyard.

(Normal Key with START/STOP Switch Type)

START/STOP SWITCH



2. Push the start/stop switch to stop the engine.



POWER SWITCH

3. Turn the power switch to the OFF position, and then remove and store it.

In the event that the engine does not stop when the power switch is turned to the OFF position, pull the emergency stop switch clip out of the emergency stop switch by pulling its lanyard (P.82).


4. When the boat is not in use, remove and store the emergency stop switch clip and lanyard.

Mechanical wire type

Emergency Engine Stopping

(Side-mount Type)


EMERGENCY STOP SWITCH



EMERGENCY STOP SWITCH CLIP

(Flush-mount type,
Top-mount type)

**EMERGENCY STOP
SWITCH**



EMERGENCY STOP SWITCH CLIP

To stop the engine in an emergency, pull the emergency stop switch clip out of the emergency stop switch by pulling the emergency stop switch lanyard.

If the emergency stop switch is activated while the engine is running, the engine will shut down abruptly and the boat will quickly decelerate, potentially causing occupants and objects to be thrown forward and/or overboard.


If the emergency stop switch is activated, the emergency stop switch clip must be reinserted before the engine can be restarted.

We suggest that you stop the engine this way occasionally to verify that the engine and emergency stop switch are operating properly.

Normal Engine Stopping

(Side-mount Type)


NEUTRAL



**GEARSHIFT/THROTTLE
CONTROL LEVER**

(Flush-mount type)


NEUTRAL



**GEARSHIFT/THROTTLE
CONTROL LEVER**


OPERATION

(Top-mount type)




1. Move the control lever(s) to the NEUTRAL position.
After cruising at full throttle, cool down the engine by idling for a few minutes before stopping the engine.

(Side-mount Type)




(Flush-mount type, Top-mount type)




2. Turn the ignition switch key to the OFF position to stop the engine.
In the event that the engine does not stop when the ignition switch key is turned to the OFF position, pull the emergency stop switch clip out of the emergency stop switch by pulling the emergency stop switch lanyard (P.85).
3. When the boat is not in use, remove and store the ignition switch key and the emergency stop switch clip and lanyard.

GEARSHIFT AND THROTTLE OPERATION


(Flush-mount type (DBW type))



(Single top-mount type (DBW type))




(Dual top-mount type (DBW type))




(Side-Mount type (Mechanical wire type))

GEARSHIFT/THROTTLE CONTROL LEVER




NEUTRAL




OPERATION

(Flush-Mount type
(Mechanical wire type))



(Top-mount type
(Mechanical wire type))



To shift gears, move the control lever to select the FORWARD, NEUTRAL, or REVERSE gear.

The control lever cannot be moved from the NEUTRAL position unless the neutral release lever is squeezed (Side-mount type, Flush-mount type, Single top-mount type(DBW type))

When cruising normally, operate the right and left levers simultaneously or operate in one-lever mode (see one-lever mode on page 100). (Dual top-mount type(DBW type))

When cruising normally, operate the right and left levers simultaneously. (Dual top-mount type(Mechanical wire type))

Moving the control lever beyond the gear selection range increases engine speed.

Gearshift/Throttle Control Lever Friction


Adjust the control lever friction.

NOTICE


- Adjust the control lever friction while the engine is stopped.

Flush-Mount type (DBW type)

1. Insert a screwdriver or similar tool into the grooves on the body cover and remove the tabs securing the body cover.




2. Remove the body cover.




3. Loosen the nut.
4. Turning the control lever friction adjustment bolt clockwise (to the right) makes it heavier.
Turning the bolt counterclockwise (to the left) makes it lighter.
5. Tighten the nut to lock the control lever friction adjustment bolt.


6. Attach the body cover.



Top-Mount type (DBW type)




1. Remove the maintenance cover.



2. Remove the bolt.

OPERATION

REMOTE CONTROL COVER



CONTROL LEVER FRICTION ADJUSTER BOLT


3. Open the remote control cover.
4. Loosen the nut.
5. Turning the control lever friction adjustment bolt clockwise (to the right) makes it heavier. Turning the bolt counterclockwise (to the left) makes it lighter.

6. Tighten the nut to lock the lever friction.
7. Reinstall the remote control cover.
8. Install and tighten the bolt.
9. Reinstall the maintenance cover.


Mechanical wire type

(Side-mount type)


CONTROL LEVER FRICTION ADJUSTER




(Flush-mount type)



(Single top-mount type)



(Dual top-mount type)



Adjust the control lever friction adjuster so the control lever will hold a constant throttle setting while cruising.


STEERING

Steer the boat in the same manner as an automobile.

Under normal conditions, turning the steering wheel counterclockwise will make the boat turn left and turning the steering wheel clockwise will make the boat turn right.

If steering effort is not equal in both directions, adjust the trim tab to compensate for "torque steer," which is the reaction of the outboard motor to propeller rotation.

OPERATION



Adjust the trim tab with the engine stopped. Loosen the bolt above the trim tab, turn the trim tab, and then tighten the bolt securely.

When the trim tab is correctly adjusted, steering effort will be equal in both directions.

Refer to TRIM TAB ADJUSTMENT on P.119.

CRUISING

Engine Speed

For best fuel economy, limit the throttle opening to 80%. Use the throttle friction control (P.88) to help you hold a steady speed.

For rough water conditions or large waves, slow down to prevent the propeller from rising out of the water.

The engine is equipped with a rev limiter to prevent the possibility of mechanical damage from excessive engine speed.

If, for example, the outboard motor is tilted excessively or propeller ventilation occurs during a sharp turn, the engine may overrev, activating the rev limiter. If engine speed becomes unstable at high speed due to activation of the rev limiter, reduce speed

and check the trim angle of the outboard motor.

⚠ WARNING

Traveling at high speeds may cause the boat to loss of control in some water conditions, which could result in damage to the outboard motor and injury to the occupants. Always travel at safe speeds for the water conditions.

Trim

Use the power trim/tilt switch to trim the outboard motor for the best performance and stability.

You can use the power trim/tilt switch at any time, whether the boat is underway or stopped.

Press the UP or DN (down) side of the switch to adjust the angle of the outboard motor.

Refer to the multi-function display, NMEA2000®-compatible display for an indication of whether the outboard motor is trimmed high or low.

It is necessary to trim the angle of the outboard motor to compensate for changes in boat load, weight distribution, water conditions, and propeller selection.

Under normal conditions, the boat will perform best when the anti-cavitation plate is level with the water surface.


When cruising into a high wind, trim the outboard motor down slightly to level the boat and improve stability. With a tail wind, trim the outboard motor up slightly.

NOTICE

- Excessive trim/tilt angle during operation can cause propeller ventilation, overheating, and water pump damage.

Flush-mount Type (DBW type)

**GEARSHIFT/THROTTLE
CONTROL LEVER**




POWER TRIM/TILT SWITCH

OPERATION


Top-mount type (DBW type)

(Single type)



POWER TRIM/TILT SWITCH

(Dual type)




POWER TRIM/TILT SWITCH

Side-mount type (Mechanical wire type)



POWER TRIM/TILT SWITCH

Flush-mount type (Mechanical wire type)



POWER TRIM/TILT SWITCH


Top-mount type (Mechanical wire type)

(Single type)



POWER TRIM/TILT SWITCH

(Dual type)




(LEFT) (RIGHT)
POWER TRIM/TILT SWITCH

Power Trim/Tilt Switch Panel

DUAL TYPE

Press UP to raise bow.




Press DN to lower bow.

POWER TRIM/TILT SWITCHES

TRIPLE TYPE

Press UP to raise bow.




POWER TRIM/TILT SWITCHES


Press DN to lower bow.

For multiple outboard motors, the trim/tilt angle of all outboard motors is adjusted at the same time by using the power trim/tilt switch on the gearshift/throttle control lever and the trim/tilt angle of each outboard motor is adjusted by using each power trim/tilt switch on the panel.


OUTBOARD MOTOR TRIMMED TOO LOW



OUTBOARD MOTOR TRIMMED TOO HIGH




OUTBOARD MOTOR TRIMMED CORRECTLY



OPERATION


BOW TOO LOW DUE TO

1. LOAD IN THE FRONT
2. OUTBOARD MOTOR TRIMMED TOO LOW




BOW TOO HIGH DUE TO

1. LOAD IN THE REAR
2. OUTBOARD MOTOR TRIMMED TOO HIGH




Trolling Speed Control (optional equipment for Mechanical wire type)

(Trolling Control Switch Panel)




TRL (Trolling)
CONTROL SWITCH

(Side-mount type)




TRL (Trolling)
CONTROL SWITCH*

(Single top-mount type)



TRL (Trolling)
CONTROL SWITCH*

(Dual top-mount type)



TRL (Trolling)
CONTROL SWITCH*

* For TRL (Trolling) control switch
equipped type.

DN: Reduce engine speed
UP: Increase engine speed

The engine must be fully warmed up before you can activate the Trolling Speed Control. Place the outboard motor in-gear with the throttle control in the fully closed (idle) position. Press and hold the UP or DN side of the TRL control switch to activate the Trolling Speed Control. The buzzer will make one long sound indicating activation. The initial trolling speed is set at 650 rpm.

The engine speed can be adjusted in 50 rpm increments by pressing the UP or DN side of the TRL control switch. A short sound of the buzzer occurs each time the engine speed is adjusted. In Trolling Speed Control mode, the engine speed can be adjusted between 650 and 900 rpm.

Continuing to press the switch when at either of these limits will result in two short sounds from the buzzer.

The throttle control will operate when in the Trolling Speed Control mode, but once the speed reaches 3,000 rpm, the Trolling Speed Control is deactivated. If 3,000 rpm is not reached and the throttle is closed, the engine speed will decrease to the Trolling Speed Control setting.

Trim Support Mode (DBW type)

(Flush-mount type)


POWER TRIM/TILT SWITCH

Press UP to raise bow.

Press DN to lower bow.

GEARSHIFT/THROTTLE
CONTROL LEVER

TRIM SPT. SWITCH




OPERATION

(Top-mount type)

POWER TRIM/TILT SWITCH

Press UP to
raise bow.

Press DN to
lower bow.



TRIM SPT. SWITCH

GEARSHIFT/THROTTLE CONTROL LEVER

Pressing the TRIM SPT. switch changes the mode to the trim support mode, which automatically does trim operations according to the speed or engine RPM.

Adjusting the trim angle to an optimum position automatically during acceleration or cruising improves acceleration performance, top speed, steering stability, fuel efficiency, etc.

The conditions that control the trim angle pattern is set in the Honda multi-function display.

You can finely adjust the trim angle manually while in trim support mode.

In the case of a single outboard motor, if you press the power trim/tilt switch of the remote control while in trim support mode, you can fine-tune the trim angle.

In the case of multiple outboard motors, if you press the power trim/tilt switch of the remote control in the trim support mode, you can fine-tune the trim angles of all the outboard motors simultaneously.

The finely adjusted angle is temporarily overwritten with the preset pattern, and returns to the pattern before overwriting when the trim support mode is released or the engine switch or power switch is turned off.


If you use the cruise control mode while in the trim support mode, the trim support mode is temporarily stopped.

The trim support mode is forcibly canceled in the following cases.


- Trim angle is adjusted beyond the trim area by the power trim/tilt switch
- GPS error or disconnection
- Engine malfunction (overheating, low oil pressure, etc.)
- Trim operation abnormality
- Accelerating or decelerating so quickly as to put a load on trim

TROLLING CONTROL MODE (DBW type)

(Flush-mount type)



(Top-mount type)



TROLL/DN Switch: Reduce engine speed
CRUISE/UP Switch: Increase engine speed

OPERATION

After the engine warms up, when the gearshift/throttle control levers are tilted from the NEUTRAL position to the FORWARD or REVERSE side by about 20° and the TROLL/DN switch of the remote control is pressed, the mode changes to trolling control mode.

A long buzz sounds once. When the mode is changed to trolling control mode, the engine speed is 650 rpm.

You can adjust the engine speed by 50 rpm every time you press the switch once. You will hear a short buzz. The engine speed can be adjusted within the range of 650 – 900 rpm.

Continuing to press the switch will not decrease or increase the engine speed beyond the lower (650 rpm) or higher (900 rpm) limit.

If you try to do this, a short buzz sounds twice.

The throttle may be operated while in trolling control mode.

ONE-LEVER MODE (Dual top-mount type for DBW type)




Shifting gear and the engine speed adjustment of all the outboard motors can be performed with one gearshift/throttle control lever when in one-lever mode.


If you press the 1 LEVER switch when all gearshift/throttle control levers are in the NEUTRAL position, the mode changes to one-lever mode.
A long buzz sounds once.

CRUISE CONTROL MODE (DBW type)

(Flush-mount type)



(Top-mount type)



TROLL/DN Switch: Reduce engine speed or velocity
CRUISE/UP Switch: Increase engine speed or velocity

OPERATION

If you press the CRUISE/UP switch during cruising with all the gearshift/throttle control levers in the FORWARD position, the mode changes to the cruise control mode, which lets the boat cruise at a constant engine speed or velocity.

A long buzz sounds once.

- Boat speed can only be adjusted in cruise control mode when equipped with GPS.

You can adjust the engine speed or velocity by every time you press the switch once. You will hear a short buzz.

Continuing to press the switch will not decrease or increase the engine speed beyond the lower or higher limit.

If you try to do this, a short buzz sounds twice.

Engine speed adjusting range:

Engine speed at mode change ± 500 rpm (in steps of 50 rpm)

Velocity adjusting range:

- Velocity at mode change ± 10 km/h (in steps of 1.0 km/h)
- Velocity at mode change ± 5 miles/h (in steps of 0.5 miles/h)
- Velocity at mode change ± 5 knots (in steps of 0.5 knots)

The cruise control mode is released forcibly in the following cases.

- GPS error or disconnection (Velocity adjustment is selected in the multifunction display)
- Operate the gearshift/throttle control lever a certain amount from the position for changing modes
- Engine stops or engine is abnormal (overheating, low oil pressure, etc.)
- If the engine RPM or speed is unstable


SHALLOW WATER OPERATION

When operating in shallow water, use the power trim/tilt switch (P.93) to tilt the outboard motor so that the propeller and gear case won't hit the bottom.

Proceed at low speed, and monitor water flow from the cooling system indicator (P.63) to be sure the outboard motor is not tilted so high that the water intakes are out of the water.

NOTICE

- An excessive trim/tilt angle during operation can cause propeller ventilation, overheating, and water pump damage. This type of damage is not covered by the Distributor's Limited Warranty (U.S.) (P.183) /Distributor's Warranty (CA.) (P.196).



MOORING, BEACHING, LAUNCHING

Stop the engine before tilting the outboard motor.

Before tilting an outboard motor up, leave it in the running position for one minute after stopping the engine to drain the water from inside the engine.

NOTICE

- Use the tilt lock lever when mooring for long periods of time (P. 105).

1. Move the gearshift/throttle control lever to the NEUTRAL position and stop the engine.
2. Press UP on the power trim/tilt switch and tilt the outboard motor to the best position according to cruising conditions.


Pressing UP on the power trim/tilt switch on the gearshift/throttle control lever or power trim/tilt switch panel twice in succession tilts up the outboard motor to the set tilt angle automatically.

NOTICE

- Do not tilt up the outboard motor before shutting off the engine, or it may cause malfunction.

Flush-mount Type (DBW type)

GEARSHIFT/THROTTLE CONTROL LEVER




POWER TRIM/TILT SWITCH

OPERATION


Top-mount type (DBW type)

(Single type)



POWER TRIM/TILT SWITCH

(Dual type)




POWER TRIM/TILT SWITCH

Side-mount type (Mechanical wire type)



POWER TRIM/TILT SWITCH

Flush-mount type (Mechanical wire type)



POWER TRIM/TILT SWITCH


Top-mount type (Mechanical wire type)

(Single type)



POWER TRIM/TILT SWITCH


(Dual type)



(LEFT) (RIGHT)
POWER TRIM/TILT SWITCH


Power Trim/Tilt Switch Panel

(Dual type)



POWER TRIM/TILT SWITCHES

(Triple type)




POWER TRIM/TILT SWITCHES

NOTICE

- For multiple outboard motors, the trim/tilt angle of all outboard motors is adjusted at the same time by using the power trim/tilt switch on the gearshift/throttle control lever and the trim/tilt angle of each outboard motor is adjusted by using each power trim/tilt switch on the remote control (Top-mount type (Mechanical wire type)) or the panel.

Moorage



TILT LOCK LEVER (each side)

Tilt up the outboard motor using the tilt lock levers when mooring the boat. Shift the gearshift/throttle control lever into the NEUTRAL position and stop the engine before tilting up the outboard motor.

OPERATION


NOTICE

- Before tilting it up, leave the outboard motor in the running position for one minute after stopping the engine to drain the water from inside the engine.

Stop the engine before tilting the outboard motor.

1. Tilt the outboard motor up to its highest position using the power trim/tilt switch (P.48).
2. Move the tilt lock levers to the LOCK position and lower the outboard motor until the lock levers contact the stern bracket.


TILT LOCK LEVER (each side)



⚠ CAUTION

If you do not secure the outboard motor with the tilt lock levers after tilting it up to the highest position, then the hydraulic pressure of the power trim/tilt may decrease and cause the outboard motor to tilt down.

TRIM RODS



3. Press DN (down) on the power trim/tilt switch to fully shorten the trim rods.

4. To tilt down, raise the outboard motor as far as it goes using the power trim/tilt switch, move the tilt lock levers to the FREE position, and lower the outboard motor to the designated position.

NOTICE

- Do not start the engine while the tilt lock lever is locked. There is a risk of damaging the engine.

Pressing DN on the power trim/tilt switch on the gearshift/throttle control lever or power trim/tilt switch panel twice in succession tilts the outboard motor down to the set tilt angle automatically (P.107).

Automatic Tilt Mode (DBW type)

If you press the power trim/tilt switch twice in succession while the boat is stopped, the automatic tilt mode is turned on, automatically tilting the outboard motor up or down.

When the "UP" side of the power trim/tilt switch is pressed twice in succession, the buzzer sounds once at a long interval, and the tilt is automatically raised to the preset tilt limit position. The buzzer continues to sound at short intervals while the outboard motor is tilted up.

When you press "DN" on the power trim/tilt switch twice in succession, the buzzer sounds once at a long interval, and the outboard motor is automatically tilted down to the preset tilt limit position. The buzzer continues to sound at short intervals while the outboard motor is tilted down.

Even during automatic tilting, automatic tilt will be forcibly canceled and the outboard motor will stop being tilted in the following cases.

- The power trim/tilt switch is pressed during automatic tilt operations
- The power tilt switch (outboard motor panel) is pressed and held in the opposite direction of the tilt direction during automatic tilt operations
- Any of the engines are started

OPERATION


- Any of the engines are abnormal (overheating, low oil pressure, etc.)

Before you can use the automatic tilt function, you need to set it in the Honda multi-function display.

For multiple outboard motors, the power trim/tilt switch on the gearshift/throttle control lever side can turn on the automatic tilt mode for all the outboard motors and the power trim/tilt switch on the power trim/tilt switch panel can turn on the automatic tilt mode for each individual outboard motor.

The power trim/tilt switch on the gearshift/throttle control lever side turns on the automatic tilt mode even if the power switch or engine switch is off.

Power Tilt Switch (outboard motor panel)



POWER TILT SWITCH

When you are away from the power trim/tilt switch on the gearshift/throttle control lever, you can operate the power tilt switch on the outboard motor.

- Press the switch on the "UP" side to increase the tilt angle.
- Press the switch on the "DN" side to decrease the tilt angle.


CAUTION

Do not operate the power tilt switch on the outboard motor while cruising. You can lose control of your balance, fall, and be injured by the moving outboard, propeller, or boat. Always use the gearshift/throttle control lever or the power trim/tilt switch on the switch panel while under way.

NOTICE

- Do not attempt to use the power tilt switch to tilt the outboard motor down while the tilt lock levers are in the LOCK position. Damage to the power tilt system may occur.

Manual Relief Valve



If the power trim/tilt switch cannot be used, you can open this valve to do manual tilt-down.

For manual tilting, use a screwdriver to turn the valve counterclockwise 1 or 2 turns. Close the valve firmly after positioning the engine.

Be sure the valve is closed before operating the outboard motor. If the valve is not closed, the

outboard motor will tilt up when operated in reverse.

⚠ DANGER

Check that nobody is under the outboard motor before opening the manual relief valve. If the manual relief valve is loosened (turned counterclockwise) when the outboard motor is tilted up, the outboard motor will suddenly tilt down.

NOTICE

- If there is not enough clearance to the ground, opening the manual relief valve may cause the outboard motor to contact the ground and be damaged.

MULTIPLE OUTBOARD MOTORS

On boats equipped with more than one outboard motor, all motors normally operate at the same time.

If one or more motor(s) is stopped while the other(s) is running, put the stopped motor in NEUTRAL and tilt it up so its propeller is above the water's surface.

If the propeller of the stopped motor is left in the water, it may turn as the boat moves through the water, causing a reverse flow of water from the exhaust side. This reverse flow will happen if the stopped engine's propeller is in the water, its gearshift is in "R" (reverse), and the boat is moving forward.

Reverse flow can cause an engine malfunction.

OPERATION

NOTICE

- If one outboard is down and another outboard is tilted all the way up, it may cause extreme steering angles that can cause the outboard cowlings to touch and damage each other.
- Never use the tilt lock lever if a stopped motor is tilted up. There is a risk of damaging the motor if you use the tilt lock lever while cruising.


TURNING WHEN MULTIPLE ENGINES ARE MOUNTED

When maneuvering in narrow waters, the action of the outboard motors allows the boat to turn more easily if you operate the left and right control levers separately. Contact the dealer where you purchased your outboard motors or authorized Marine dealer.


WARNING

When cruising normally, shift the left and right control levers at the same time. If you shift them one at a time, the boat may become unstable and capsize.


Turning right (forward)




(DBW type)




(Mechanical wire type)




Turning left (forward)




(DBW type)




(Mechanical wire type)




Turning right (reverse)




(DBW type)




(Mechanical wire type)




Turning left (reverse)



(DBW type)



(Mechanical wire type)




OPERATION


Turning right (spin)



(DBW type)




(Mechanical wire type)




Turning left (spin)



(DBW type)



(Mechanical wire type)



In the following cases, the boat cannot be turned by operating the throttle.

- When only a single engine is mounted
- When using one-lever mode (DBW type only)

THE IMPORTANCE OF MAINTENANCE

Proper maintenance is essential for safe, economical, and trouble-free operation. It will also help reduce air pollution.

WARNING

Failure to properly maintain this outboard motor, or failing to correct a problem before operation, could result in a significant malfunction.

Some malfunctions can cause serious injuries or death.

Always follow the inspection and maintenance recommendations and schedules in this owner's manual.

To help you properly care for your outboard motor, the following pages include a maintenance schedule, routine inspection procedures, and simple maintenance procedures using basic hand tools. Other service tasks that are more difficult or require special tools are best handled by professionals and are normally performed by a Honda technician or other qualified mechanic.

The maintenance schedule applies to normal operating conditions. If you operate your outboard motor under unusual conditions, consult an authorized Honda Marine dealer for recommendations applicable to your individual needs and use.

Remember that your authorized Honda Marine dealer knows your outboard motor best and is fully equipped to maintain and repair it.

To ensure the best quality and reliability, use only new, Honda Genuine parts or their equivalents for repair and replacement.

Maintenance, replacement, or repair of the emission control devices and systems may be performed by any marine engine repair establishment or individual, using parts that are "certified" to EPA standards.

SERVICING YOUR OUTBOARD MOTOR

MAINTENANCE SAFETY

Some of the most important safety precautions follow. However, we cannot warn you of every conceivable hazard that can arise in performing maintenance. Only you can decide whether or not you should perform a given task.

WARNING

Improper maintenance can cause an unsafe condition.

Failure to properly follow maintenance instructions and precautions can cause serious injuries or death.


Always follow the procedures and precautions in this owner's manual.

Safety Precautions


- Make sure the engine is off before you begin any maintenance or repairs. This will eliminate several potential hazards:
 - **Carbon monoxide poisoning from engine exhaust.**
Do not start or run the engine in a confined or partly enclosed area.
 - **Burns from hot parts.**
Let the engine and exhaust system cool before touching them.
 - **Injury from moving parts.**
Do not run the engine unless instructed to do so.
- Read the instructions before you begin, and make sure you have the tools and skills required.
- To reduce the possibility of fire or explosion, be careful when working around gasoline. Use only a nonflammable solvent, not gasoline, to clean parts. Keep cigarettes, sparks, and flames away from all fuel-related parts.
- Wear gloves when handling the propeller to protect your hands from sharp edges.

SERVICING YOUR OUTBOARD MOTOR

TOOL KIT and OWNER'S MANUAL



OWNER'S MANUAL



TOOL BAG




**PHILLIPS/FLAT
SCREWDRIVER**




6 mm HEX. WRENCH



GRIP



EYE WRENCH




SPARK PLUG WRENCH

The tool kit can be used for simple maintenance procedures and emergency repairs. Keep these items on the boat so that they will always be available if you need them.

If your tool kit needs replacement, it is not available as a kit and each item must be ordered individually.

SERVICING YOUR OUTBOARD MOTOR

SPARE EMERGENCY STOP SWITCH CLIP (optional equipment)



Always carry a spare emergency stop switch clip onboard. The spare clip may either be stored in the tool bag or near the controls in case the operator and primary switch clip falls overboard and a passenger needs to pilot the boat during an emergency situation.

MAINTENANCE SCHEDULE

Follow the MAINTENANCE SCHEDULE table and service your outboard motor accordingly. Please note, a claim for warranty coverage will not be denied simply because the maintenance schedule for your outboard motor was not followed. However, any part(s) that fails specifically due to lack of maintenance, or improperly performed maintenance, would not be covered under the Distributor's Limited Warranty (U.S.) / Distributor's Warranty (CA.).

SERVICING YOUR OUTBOARD MOTOR

ITEM	REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first.	Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.	Refer to page
Engine oil	Check level	o						122
	Change			o	o			123
Engine oil filter	Replace					o (2)		—
Gear case oil	Change			o (2)	o (2)			—
ACG belt	Check-adjust					o (2)		—
Throttle linkage and Control Cable (11)	Check-adjust			o (2)	o (2)			—
Valve clearance	Check-adjust						o (2)(8)	—
Spark plug (standard: iridium)	Check/Replace					o (9)		128 - 131
Spark plug (option: nickel)	Check				o			131
	Cleaning				o			
	Adjust				o			
	Replace				o (10)			
Propeller and cotter pin	Check	o						138
Anode metal (Outside engine)	Check	o				o (6)		137
Anode metal (Inside engine)	Check/Replace						o (2)	—
Idle speed	Check-adjust			o (2)	o (2)			—
Lubrication	Grease			o (1)	o (1)			125
Fuel filter with water separator (Low pressure side)	Check	o			o			135
	Replace						o	136

- (1) Lubricate more frequently when used in salt water.
- (2) These items should be serviced by your servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda Shop Manual for service procedures. See "Honda Publications" on P.179 for ordering information.
- (3) For professional commercial use, log hours of operation to determine proper maintenance intervals.
- (6) Replace the anodes when they have been reduced to about two-thirds of their original size, or if they are crumbling.
- (8) If there are no problems such as increased tappet noise, idling instability/engine stalls, etc., there is no need for inspection.
- (9) If the electrodes of the iridium plugs are covered with dust, etc., replace them without cleaning. If it is worn out, replace it without adjusting the electrode clearance.
- (10) If the center electrode has rounded corners or the outer electrode is worn unevenly, replace it with a new one.
- (11) Mechanical wire type only.

SERVICING YOUR OUTBOARD MOTOR

ITEM	REGULAR SERVICE PERIOD (3) Perform at every indicated month or operating hour interval, whichever comes first.	Each use	After use	First month or 20 hrs.	Every 6 months or 100 hrs.	Every year or 200 hrs.	Every 2 years or 400 hrs.	Refer to page
Fuel filter (High pressure side)	Replace						o (2)	—
Thermostat and thermostat cover	Check/Replace					o (2)		—
Fuel line	Check	o (7)						69
	Replace	Every 2 years (if necessary) (2)						—
Battery and cable connection	Check level-tightness	o						69
Bolts and nuts	Check-tightness			o (2)	o (2)			—
Crankcase breather tube	Check					o (2)		—
Cooling water passages	Clean		o (4)					140
Cooling water leak	Check	o						69
Water pump	Check					o (2)		—
Emergency stop switch	Check	o						69
Engine oil leak	Check	o						—
Each operating part	Check	o						—
Engine condition (5)	Check	o						—
Power Trim/Tilt	Check				o (2)			—
Shift Cable (11)	Check-adjust			o (2)	o (2)			—

(2) These items should be serviced by your servicing dealer, unless you have the proper tools and are mechanically proficient. Refer to the Honda Shop Manual for service procedures. See "Honda Publications" on P.179 for ordering information.

(3) For professional commercial use, log hours of operation to determine proper maintenance intervals.

(4) When operating in salt water, turbid or muddy water, the engine should be flushed with clean water after each use.

(5) Upon starting, check for unusual engine sounds and cooling water flowing freely from the check hole.

(7) Check the fuel line for leaks, cracks, or damage. If it is leaking, cracked, or damaged, take it to your servicing dealer for replacement before using your outboard.

(11) Mechanical wire type only.


TRIM TAB ADJUSTMENT

The trim tab compensates for "torque steer," which is a reaction of the outboard motor to propeller rotation.


If uncompensated, torque steer would make the outboard motor tend to turn to one side.

When the trim tab is correctly adjusted, steering effort is equal in either direction.

If steering effort is unequal, loosen the trim tab bolt and adjust the angle of the trim tab. Retighten the trim tab bolt securely.



If less effort is required to make left turns, move the back of the trim tab left.



If less effort is required to make right turns, move the back of the trim tab right.

Adjust the trim tab in small increments, and retest steering effort with the boat evenly loaded and running at cruising speed.


SERVICING YOUR OUTBOARD MOTOR

ENGINE COVER REMOVAL AND INSTALLATION

Tilt up the outboard motor as necessary while removing or installing the engine cover.


Removal

Front



ENGINE COVER LATCH

Side




ENGINE COVER LATCH
(each side)

1. Pull all the engine cover latches.
2. Remove the engine cover by lifting it straight up from the outboard motor.


Installation

Front



ENGINE COVER LATCH


Side





ENGINE COVER LATCH
(each side)

1. Place the engine cover on the main body.

SERVICING YOUR OUTBOARD MOTOR



2. Slide the engine cover so that the cover lock on the cover is mated with the lock in the main body.



3. Push the engine cover until any gap between the engine cover and main body is eliminated.

4. Push all the engine cover latches to lock them.
5. Check that the engine cover is securely installed.

Lubricate the engine cover rubber sealing ring with silicone spray to make installation easier.

The cover should be tight when fully seated position. If the cover is loose or difficult to secure, an adjustment may be necessary. Please see the shop manual or your Marine dealer for adjustment.

⚠ CAUTION

If the engine cover is not installed correctly, water may enter the engine cover and damage the engine. In addition, off the engine cover may blow when cruising at high speeds.

SERVICING YOUR OUTBOARD MOTOR


ENGINE OIL LEVEL CHECK

Check the engine oil level with the engine stopped and the outboard motor in the vertical position.

1. Unlock and remove the engine cover (P.120).
2. Remove the oil level dipstick by pulling it. Wipe the oil level dipstick clean.

OIL LEVEL DIPSTICK


UPPER LIMIT



LOWER LIMIT

3. Insert the dipstick all the way in, then remove it and check the oil level shown on the dipstick.

OIL FILLER CAP



4. If near or below the lower level mark, remove the oil filler cap and fill to the upper level mark with the recommended oil. Use the oil recommended on P.124.

NOTICE

- Running the engine with a low oil level can cause engine damage.
- Do not overfill. Overfilling the engine will cause it to smoke or have oil leaks.

5. Insert the dipstick all the way in. Install the oil filler cap and tighten it securely. Do not overtighten.
6. Install and lock the engine cover.

When you check the oil level with the dipstick, you might notice the engine oil appears milky or the oil level has increased. If you notice either condition, change the engine oil.

SERVICING YOUR OUTBOARD MOTOR

NOTICE

- Engine oil may deteriorate prematurely when used under certain conditions. Deteriorated engine oil can cause the outboard motor to malfunction, so if the outboard motor is used under the following conditions, change the engine oil at intervals of half the normal periodic maintenance time.
 - Frequent starting and stopping within a short period of less than 5 minutes.
 - Running the engine at 3,000 rpm or less for more than 30% of the time after changing the engine oil.

ENGINE OIL CHANGE

An engine oil evacuation/filling device may be used to remove/add the engine oil.

Drain the used oil while the engine is warm. Warm oil drains quickly and completely.

1. Unlock and remove the engine cover (P.120).

SEALING WASHER (Replace)

OIL DRAIN GUIDE



DRAIN BOLT

2. Place a suitable container below the oil drain guide to catch the used oil, and then remove the oil filler cap, drain bolt, and sealing washer.

SERVICING YOUR OUTBOARD MOTOR

3. Allow the used oil to drain completely. Use a new sealing washer, and then reinstall the engine oil drain bolt using a new washer.
Tighten the drain bolt securely.

TIGHTENING TORQUE:
17 lbf·ft (23 N·m, 2.3 kgf·m)


NOTICE

- Improper disposal of engine oil can be harmful to the environment. If you change your own oil, please dispose of the used oil properly. Put it in a sealed container, and take it to a recycling center. Do not throw it in the trash, pour it on the ground or down a drain.

4. With the outboard motor in a vertical position, fill to the upper limit mark on the dipstick (P.122) with the recommended oil.
Engine oil refill capacity:
6.9 US qt (6.5 L)
5. Install the oil filler cap and tighten it securely.
6. Install and lock the engine cover (P.120).

ENGINE OIL RECOMMENDATIONS

Oil is a major factor affecting performance and service life. Use 4-stroke detergent oil.



AMBIENT TEMPERATURE

Honda 10W-30 FC-W® outboard motor oil is recommended for general use.

FC-W® is a registered trademark of the National Marine Manufacturers Association.

If Honda 10W-30 FC-W oil is not available, Honda recommends that you use API service category SG, SH, SJ or SL oil. The SAE oil viscosity and service category are in the API label on the oil container.

LUBRICATION POINTS


Apply Honda Marine waterproof grease to the parts shown below:

NOTICE

- Apply anticorrosion oil to pivot surfaces where grease cannot penetrate.

Apply Honda Marine Corrosion Inhibitor (or equivalent) to all areas under the engine cover and any exposed metal surfaces except the belts.


SERVICING YOUR OUTBOARD MOTOR




* Apply grease to the back of the engine cover lock plate as well.

SERVICING YOUR OUTBOARD MOTOR


**THROTTLE LINK/
PIVOT/PLATE
(Mechanical wire type)**




**THROTTLE ROD/LINK
(Mechanical wire type)**




**SHIFT PIVOT/
BRACKET/SHIFT ARM/
CLICK ARM ROLLER
(DBW type)**




**THROTTLE ARM/
SHIFT ARM/
PIVOT PLATE/
NEUTRAL SWITCH/
CLICK ARM ROLLER
(Mechanical wire type)**




TILT SHAFT THREAD




SWIVEL CASE



**LOWER CYLINDER
BUSH/COLLAR**



TILT BRACKET



SERVICING YOUR OUTBOARD MOTOR

SPARK PLUG SERVICE

NOTICE

- As the voltage required by a spark plug that is approaching the end of its life increases, it puts a strain on the ignition coil and other parts, which in turn affects engine performance. Spark plugs should be inspected and replaced correctly according to the maintenance schedule.

Standard Spark Plug (Iridium)


RECOMMENDED SPARK PLUGS:
IZFR6K11 (NGK)

NOTICE

- Incorrect spark plugs can cause engine damage.


Inspection and Replacement

1. Disconnect the battery negative (-) terminal.
2. Unlock and remove the engine cover (P.120).



3. Remove the two bolts with the 6 mm hex. wrench, and remove the spark plug cover.

WIRE CONNECTOR




4. Remove the bolt from the ignition coil. Rotate the ignition coil to a position that allows removal of the wire connector easily.
5. Disconnect the wire connector from the ignition coil by pushing on the lock tab and pulling on the connector. Pull on the plastic connector, not the wires.
6. Remove the ignition coil by pulling it up slightly.

SERVICING YOUR OUTBOARD MOTOR

NOTICE

- Do not strike or drop the ignition coil, or it may be damaged and require replacement.


EYE WRENCH





SPARK PLUG WRENCH

7. Remove the spark plugs with a spark plug wrench and eye wrench.

New plug



Plug needing replacement




8. Inspect the spark plugs.

- ① If the electrodes are heavily corroded or carbon-soiled, replace the spark plug with a new one.

- ② Replace a spark plug if the center electrode is worn. The spark plug can wear out in different ways. If the sealing washer shows signs of wear, or if the insulators are cracked or chipped, replace the spark plug.

SERVICING YOUR OUTBOARD MOTOR



Use a wire type plug gauge to measure the gap (spark gap) between the center electrode and the side electrode.

- Use a wire-type plug gauge to prevent damage to the iridium center electrode.

Check that the $\Phi 0.051$ in (1.3 mm) plug gauge does not fit into the gap.

The gap should be 0.039 – 0.051 inches (1.0 – 1.3 mm).

9. These spark plugs have an iridium coated center electrode.

Be sure to observe the following when servicing iridium spark plugs.

- Do not clean the spark plugs. If an electrode is contaminated with accumulated material or dirt, replace the spark plug with a new one.
- Use only a "wire-type feeler gauge" to check the spark plug gap if necessary. To prevent damaging the iridium coating of the center electrode, never use a "leaf-type feeler gauge."

- Do not adjust the spark plug gap. If the gap is out of specification, replace the spark plug with a new one.

10. Install the spark plugs carefully, by hand, to avoid cross-threading.

11. After each spark plug is seated, tighten it with the spark plug wrench supplied in the tool kit to compress the sealing washer.

TIGHTENING TORQUE:

12 - 14 lbf·ft (16 - 20 N·m , 1.6 - 2.0 kgf·m)

If you do not have a torque wrench, tighten as follows:
If reinstalling used spark plugs, tighten 1/8 - 1/4 turn after the spark plugs are seated.
If installing new spark plugs, tighten 1/2 turn after the spark plugs are seated.

NOTICE

- Loose spark plugs can overheat and damage the engine. Overtightening the spark plugs can damage the threads in the cylinder head.

12. Install the ignition coil.
Reinstall the bolt.

TIGHTENING TORQUE:

7.2 - 10 lbf·ft (10 - 14 N·m , 1.0 - 1.4 kgf·m)

13. Push the wire connector onto the ignition coil. Make sure it locks in place.
14. Repeat this procedure for the other three spark plugs.
15. Reinstall the covers. When reinstalling the covers, make sure not to pinch the wire harnesses between the covers and engine case.

Optional Spark Plug (Nickel)


RECOMMENDED SPARK PLUGS:
ZFR6K-11 (NGK)

NOTICE

- Incorrect spark plugs can cause engine damage.

Inspection and Cleaning

Installation and removal procedure of the optional spark plugs are the same as the standard spark plugs.



SERVICING YOUR OUTBOARD MOTOR

Measure the spark plug electrode gap with a feeler gauge. Correct the gap, if necessary, by carefully bending the side electrode.

The gap should be:
0.039 – 0.043 in (1.0 – 1.1 mm)

Replacement

Replacement procedure of the optional spark plugs are the same as the standard spark plugs.

REFUELING

If you do not anticipate cycling through at least one complete tank of fuel within a 30 day period, we recommend adding Honda Marine Fuel Stabilizer each time you refuel.

Check the fuel level and refill it if necessary. Do not fill the fuel tank above the UPPER LIMIT. Refer to the boat manufacturer's instructions.

WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and let it cool before handling fuel.
- Keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Keep away from your vehicle.
- Wipe up spills immediately.

Never refill the fuel tank inside a building where gasoline fumes may reach flames or sparks. Keep gasoline away from appliance pilot lights, barbecues, electric appliances, power tools, etc.

Spilled fuel is not only a fire hazard, it also causes environmental damage. Wipe up spills immediately.

NOTICE

- Fuel can damage paint and plastic. Be careful not to spill fuel when filling your fuel tank. Damage caused by spilled fuel is not covered under the Distributor's Limited Warranty (U.S.) / Distributor's Warranty (CA.).

FUEL RECOMMENDATIONS

Use unleaded gasoline with a pump octane rating of 86 or higher.

Your outboard motor is certified to operate on unleaded gasoline. Unleaded gasoline produces fewer engine and spark plug deposits and extends exhaust system life.

Never use gasoline that is stale, contaminated, or mixed with oil. Avoid getting dirt or water in the fuel tank.

You may use unleaded gasoline containing no more than 10% ethanol (E10) or 5% methanol by volume. In addition, methanol must contain cosolvents and corrosion inhibitors.


Use of fuels with content of ethanol or methanol greater than shown above may cause starting and/or performance problems. It may also damage metal, rubber, and plastic parts of the fuel system.

Engine damage or performance problems that result from using a fuel with percentages of ethanol or methanol greater than shown above are not covered under warranty.

SERVICING YOUR OUTBOARD MOTOR

If your outboard motor will be used on an infrequent or intermittent basis, please refer to the fuel section of the STORAGE chapter (P.143) for additional information regarding fuel deterioration.

FUEL FILTER WITH WATER SEPARATOR (LOW PRESSURE SIDE) INSPECTION AND REPLACEMENT



**FUEL FILTER with WATER
SEPARATOR
(LOW PRESSURE SIDE)**

The fuel filter with water separator is located below the intake manifold.

Water or sediment accumulation in the fuel filter with water separator can cause loss of power or difficult starting.

To prevent engine malfunction, inspect the fuel filter with water separator and replace it when necessary.

Clean the filter or consult with an authorized Honda Marine dealer for cleaning.


WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and let it cool before handling fuel.
- Keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Keep away from your vehicle.
- Wipe up spills immediately.

Inspection



FUEL FILTER with WATER SEPARATOR (LOW PRESSURE SIDE)

1. Remove the engine cover (P.120).


2. Looking through the translucent strainer cup, check for accumulation of water or sediment.

If the fuel filter with water separator is clogged, refer to fuel filter with water separator replacement procedure (P.136) to remove the filter and clean it.


If water is present in the fuel filter with water separator, refer to fuel filter with water separator replacement procedure to remove the strainer cup and empty the water from the inside of the cup.

SERVICING YOUR OUTBOARD MOTOR

Replacement




1. Remove the engine cover (P.120).
2. Remove the suspension strap from the fuel filter with water separator bracket.
3. Disconnect the 2-pin coupler (blue).
 - ① Remove the 2-pin coupler (blue) from the bracket.
 - ② Remove the harness from the clip.
 - ③ Disconnect the 2-pin coupler (blue).



4. Turn the fuel filter cup with water separator to the left to remove it, and then remove any water or sediment from inside the cup.
5. Thoroughly clean the cup. If the fuel filter is clogged, or has reached the end of its replacement period, replace it with a new one.
6. Reassemble the fuel filter with water separator in the reverse order of removal.
Use a new O-ring.

SERVICING YOUR OUTBOARD MOTOR




7. When attaching the suspension strap to the fuel filter with water separator, align the positioning rib of the suspension strap with the OUT side hose connection in the strainer body, as shown in the diagram.
8. Prime the engine using the priming bulb (P.71). Check for fuel leaks. Repair any fuel leaks if necessary.

If the buzzer sounds or water or sediment accumulation is found in the fuel filter with water separator, inspect the fuel tank.

Clean the fuel tank and tank filter if necessary. The fuel tank may need to be drained completely and refilled with fresh gasoline.

ANODE INSPECTION



The anodes are located on each side of the gear case and on the stern bracket. They are made of a sacrificial material that helps to protect the outboard motor from corrosion.

Replace the anodes when they have been reduced to about two-thirds their original size, or if they are crumbling.


SERVICING YOUR OUTBOARD MOTOR

PROPELLER REPLACEMENT (Except for JET Drive type)

Before replacing the propeller, remove the emergency stop switch clip from the emergency stop switch to prevent any possibility of the engine being started while you are working with the propeller.

The propeller blades may have sharp edges, so wear heavy gloves to protect your hands.

Operating the outboard motor at higher altitudes will reduce available power. This may require decreasing the propeller pitch to maintain correct engine RPM.



When replacing the propeller, put a suitable block or piece of wood between the propeller and the anti-cavitation plate to prevent the propeller from rotating.

Removal

1. Remove the cotter pin, unscrew the castle nut, remove the washer, and then remove the propeller and thrust washer.
2. Inspect the propeller shaft for any fishing line or debris.

Installation

Some propeller brands require specific mounting hardware. Refer to your specific propeller manufacturer's instructions for proper installation.

1. Apply marine grade grease to the propeller shaft.

SERVICING YOUR OUTBOARD MOTOR


2. Install the thrust washer with the grooved side toward the gear case.
3. Install the propeller.
4. Install the washer as shown below.
5. Lightly tighten the castle nut by hand or wrench until the propeller has no free play.
6. Tighten the castle nut using a torque wrench.
TIGHTENING TORQUE:
41 lbf·ft (56 N·m, 5.7 kgf·m)
7. Then, using a torque wrench, tighten the castle nut until the first available groove in the castle nut aligns with the cotter pin hole. Do not tighten past the first alignment of the castle nut groove and the cotter pin hole.

NOTICE

- **TIGHTENING TORQUE LIMIT:**
94 lbf·ft (128 N·m, 13 kgf·m)
Do not tighten the castle nut above the TIGHTENING TORQUE LIMIT, or the propeller and shaft may be damaged.

8. Be sure to replace the cotter pin with a new one.
 - Use a Honda Genuine stainless steel cotter pin or equivalent cotter pin and to lock the pin in place bend the pin ends.

Note that the castle nut wrench is not included with the tool set that comes with the outboard motor. Contact your authorized Honda Marine dealer for additional tool information.



CLEANING AND FLUSHING

CLEANING AND FLUSHING

After each use in salt water or dirty water, thoroughly clean and rinse the outboard motor with fresh water.

Touch up any damaged paint, and coat areas that may rust with Honda Corrosion Inhibitor, or equivalent.

Lubricate controls with a silicone spray lubricant.

NOTICE

- Do not apply water or corrosion inhibitor directly to the electrical components under the engine cover, such as the AC generator, O₂ sensor, or the AC generator belt. If water or corrosion inhibitor penetrates these components, they may be damaged. Before applying a corrosion inhibitor, cover the AC generator, belt and O₂ sensor with a protective material to prevent damage.

Cleaning

Wash the outside of the outboard motor with clean, fresh water, and flush the cooling system as follows.

Cleaning of the outside of the outboard motor should be performed with the engine cover installed.

AIR INTAKES



NOTICE

- Be careful not to spray water into the air intake. If water penetrates inside the engine cover from the air intake, it may cause malfunction.


Flushing With a Garden Hose (commercially available)

NOTICE

- Do not run the engine when flushing the outboard motor with a garden hose or the outboard motor may be damaged.


For safety, remove the emergency stop switch clip so the engine cannot be started while you are standing near the propeller.

1. Tilt down the outboard motor.
2. Clean and wash the outside of the outboard motor with fresh water.



FLUSH PORT CONNECTOR


3. Disconnect the flush port connector.



4. Screw the flush port connector onto the garden hose.

CLEANING AND FLUSHING

**COOLING WATER INTAKE
PORT (each side)**



EXHAUST PORT

5. Turn on the fresh water supply and flush the outboard motor for at least 10 minutes. Check that water is draining from the cooling system indicator, the cooling water intake port and the exhaust port.

NOTICE

- Do not start the engine while flushing, or it may cause malfunction.
6. After flushing, disconnect the garden hose and reconnect the flush port connector.
 7. Tilt up the outboard motor and move the tilt lock levers to the LOCK position (P.53).

FUEL

NOTICE

- Depending on the region where you operate your outboard, fuel formulations may deteriorate and oxidize rapidly. Fuel deterioration and oxidation can occur in as little as 15 days and may cause damage to the fuel system. Please check with your servicing dealer for local storage recommendations.

Gasoline will oxidize and deteriorate in storage. Old gasoline will cause hard starting, and it leaves gum deposits that clog the fuel system. If the gasoline in your fuel tank and vapor separator deteriorates during storage, you may need to have the vapor separator and other fuel system components serviced or replaced.

The length of time that gasoline can be left in your fuel tank and vapor separator without causing functional problems will vary with such factors as gasoline blend, your storage temperatures, and whether the fuel tank is partially or completely filled.

The air in a partially filled fuel tank promotes fuel deterioration. Very warm storage temperatures accelerate fuel deterioration. Fuel deterioration problems may occur in less than 15 days, if the gasoline was not fresh when you filled the fuel tank.

You can extend fuel storage life by adding a gasoline stabilizer that is formulated for that purpose, or you can avoid fuel deterioration problems by draining all the fuel from the fuel tank and vapor separator.

STORAGE

The Distributor's Limited Warranty (U.S.) (P.183) / Distributor's Warranty (CA.) (P.196) does not cover fuel system damage or engine performance problems resulting from neglected storage preparation. See page 133 for additional information on fuel recommendations.

Storage Procedure

WARNING

Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and let it cool before handling fuel.
- Keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Keep away from your vehicle.
- Wipe up spills immediately.

1. Remove the engine cover (P.120).

2. Inspect the fuel filter with water separator (low-pressure side).

If water has collected inside it or there is a clog, such as sediment in the cup, then remove the water or replace the filter. (P.136)

3. Drain the gasoline from the drain screw of the vapor separator. (P.146)

4. Confirm that there is no water or dirt mixed in with the gasoline that you remove.

5. Do the following operation if you find water or dirt mixed in with the gasoline that you remove.

- ① Confirm that the drain screw has been tightened.
- ② Keep the motor level as you connect a gas tank that has fresh gasoline.
- ③ Use the primer bulb to supply fresh gasoline to the vapor separator.

CAUTION

Always operate the primer bulb while the drain screw is tight. If the drain screw is loose, then gas will leak.

- ④ Start the engine and run it at idle for 1 minute.

NOTICE

- Always start the engine under normal operating conditions (while the propeller is in the water). Never start it while the propeller is out of the water. Doing so will damage the engine.

- ⑤ Drain the gasoline from the drain screw of the vapor separator. (P.146)
- ⑥ Confirm that there is no water or dirt mixed in with the gasoline that you remove.

- ⑦ If you find water or dirt in the gasoline that you remove, then repeat steps ① to ⑥ until you can confirm there is no water or dirt.

Adding a Fuel Stabilizer

When adding a fuel stabilizer, fill the fuel tank with fresh gasoline. If only partially filled, air in the tank will promote fuel deterioration during storage. If you keep an additional container of gasoline for refueling, be sure that it contains only fresh gasoline.

1. Drain the vapor separator before adding fuel stabilizer.
2. Add Honda Marine fuel stabilizer or equivalent following the instructions on the label.
3. After adding a fuel stabilizer, run the engine in water for 10 minutes to be sure that the treated gasoline has replaced the untreated gasoline in the vapor separator.
4. Turn the engine OFF.

STORAGE

Draining the Fuel System

⚠ WARNING



Gasoline is highly flammable and explosive.

You can be burned or seriously injured when handling fuel.

- Stop the engine and let it cool before handling fuel.
- Keep heat, sparks, and flame away.
- Handle fuel only outdoors.
- Keep away from your vehicle.
- Wipe up spills immediately.


You can avoid fuel deterioration problems by draining the fuel tank and vapor separator.

Drain the fuel into a suitable fuel container.



1. Remove the engine cover (P.120)
2. Unhook the drain hose from the clamp.

3. Set the end of the hose toward the outside of the outboard motor. Draining the fuel becomes easier when the front end of the drain tube is as low as possible.
4. Loosen the vapor separator drain screw.
5. Tilt the outboard motor up.
6. After the fuel starts flowing out the drain hose, tilt the outboard motor down to the vertical position and allow the vapor separator to finish draining.




7. After draining thoroughly, tighten the drain screw securely.
8. Attach the drain hose on the clamp.
9. Drain the fuel tank into an approved gasoline container, or if you need to store fuel in the fuel tank, you can extend fuel storage life by filling the fuel tank with fresh gasoline and adding Honda Marine fuel stabilizer or equivalent following the directions on the container.

ENGINE OIL

1. Change the engine oil (P.123).
2. Remove the emergency stop switch clip from the emergency stop switch, and remove the spark plugs (P.128).
3. Pour 1 – 2 teaspoons (5 – 10 cm³) of clean engine oil into each cylinder.
4. Rotate the engine a few revolutions to distribute the oil in the cylinders.
5. Reinstall the spark plugs (P.128).

HOISTING THE OUTBOARD MOTOR

1. Remove the engine cover (P.120)



HOIST HOOKS


2. Attach the hoist hooks to the engine hangers.
3. Disconnect the outboard motor from the boat, hoist the outboard motor, and move it to the storage area.
4. After the outboard motor is placed in storage and disconnected from the hoist, install the engine cover (P.120).

STORAGE

STORAGE PRECAUTIONS


Select a well-ventilated storage area. If possible, avoid storage areas with high humidity.

If storing a container of gasoline, store it away from any appliance that operates with a flame, such as a furnace, water heater, or clothes dryer. Also avoid any area with a spark producing electric motor, or where power tools are operated.



OUTBOARD MOTOR STAND

If the outboard motor will be removed from the boat for storage, store it vertically by mounting it on a commercially available stand.



If it is necessary to store the outboard motor horizontally, drain the vapor separator (P.146), and drain the engine oil (P.123), before removing the outboard motor from the boat.

Place the outboard motor starboard side down on the cushion of protective material.

Cover the outboard motor to keep out dust. Do not use a plastic sheet as a dust cover. A nonporous cover will trap moisture, promoting rust and corrosion.

REMOVAL FROM STORAGE

Check your outboard motor as described in the *BEFORE OPERATION* chapter of this manual.

If the cylinders were coated with oil during storage preparation, the engine may smoke briefly at startup. This is normal.

TRANSPORTING

WITH OUTBOARD MOTOR INSTALLED ON BOAT

Use an outboard motor support bar to prevent the outboard motor from moving while trailering the boat.

Refer to the manufacturer's instructions for using an outboard motor support bar.

The preferred method is to leave the engine in the normal running position, but if there is insufficient road clearance, you can tilt the outboard motor using a commercially available outboard motor support bar available through your dealer. Refer to the manufacturer's instructions for using an outboard motor support bar.



**OUTBOARD MOTOR SUPPORT
BAR (commercially available)**

WITH OUTBOARD MOTOR REMOVED FROM BOAT

Secure the outboard motor in the vertical position shown on P.148.

TAKING CARE OF UNEXPECTED PROBLEMS

First, do the following inspections yourself. If any troubles remain after that, take the outboard motor to an authorized Marine dealer. Do not casually disassemble the outboard motor.

ELECTRIC STARTER WILL NOT OPERATE

Possible Cause	Correction
Battery connections loose or corroded.	Clean and tighten battery connections.
Battery discharged.	Recharge battery.
Fuse(s) blown.	Replace fuse(s) (P.155).
Fuel system malfunction, fuel pump failure, ignition malfunction, stuck valves, starter malfunction, switch malfunction, or electrical problem in the starting circuit, etc.	Use starting procedure (P.72) if engine still will not start, then take outboard motor to an authorized Marine dealer, or refer to the shop manual.

TAKING CARE OF UNEXPECTED PROBLEMS

ENGINE WILL NOT START

Possible Cause	Correction
Clip not inserted in emergency stop switch.	Insert clip in emergency stop switch.
Control lever not in neutral position.	Shift to neutral.
Out of fuel.	Refuel (P.132).
Fuel hose not primed.	Squeeze priming bulb (P.71).
Fuel filter with water separator or fuel tank filter clogged.	Replace fuel filters (P.136).
Bad fuel, outboard motor stored without treating or draining gasoline, or refueled with bad gasoline.	Drain fuel tank and vapor separator (P.146). Refill with fresh gasoline (P.132).
Water separator full of accumulated water.	Clean water separator (P.135).
Spark plugs faulty, fouled, or improperly gapped.	Gap (non-iridium type) or replace spark plugs (P.128).
Spark plugs wet with fuel (flooded engine).	Dry and reinstall spark plugs. Start engine with the throttle open.
Fuel system malfunction, fuel pump failure, ignition malfunction, etc.	Take outboard motor to an authorized Marine dealer, or refer to the shop manual.
Fast idle lever raised (Side-Mount type (Mechanical wire type)).	Leave fast idle lever OFF (P.77).

TAKING CARE OF UNEXPECTED PROBLEMS

HARD STARTING OR STALLS AFTER STARTING

Possible Cause	Correction
Fuel hose not primed.	Squeeze priming bulb (P.71).
Fuel filter or fuel tank filter clogged.	Replace fuel filters (P.136).
Bad fuel; outboard motor stored without treating or draining gasoline, or refueled with bad fuel.	Drain fuel tank and vapor separator (P.146). Refill with fresh gasoline (P.132).
Water separator full of accumulated water.	Clean water separator (P.134).
Fast idle lever raised (Side-Mount type (Mechanical wire type)).	Leave fast idle lever OFF (P.77).

TAKING CARE OF UNEXPECTED PROBLEMS

ENGINE OVERHEATS

Possible Cause	Correction
Water intake screens clogged.	Clean water intake screens.
Faulty thermostat or water pump.	Take outboard motor to an authorized Marine dealer, or refer to the shop manual.

FUSES

Electric Starter Will Not Operate

The 7.5 A, 10 A, 15 A, and 30 A main fuses protect the electric starter relay and related circuits.

The main fuse protects the ignition switch and related circuits. If this fuse blows, the engine will not start or run, and the power trim/tilt switch will not activate the trim/tilt mechanism.

The 40 A fuse is in the power harness connected to the battery. If this fuse blows, the engine will not start or run.

Battery Will Not Charge

A 100 A ACG fuse protects the alternator circuit. If the ACG fuse blows, the engine will not charge the battery. Refer to P.160.

Fuse Replacement


NOTICE

- Disconnect the battery cable at the battery negative (-) terminal before replacing the fuse. Failure to do so may cause a short circuit.

TAKING CARE OF UNEXPECTED PROBLEMS

Power Harness

FUSE HOLDER COVER




1. Stop the engine.
2. Disconnect the battery cable and the power harness.
3. Open the fuse holder cover.
4. Pull the old fuse out of the clip with the fuse puller supplied in the fuse holder (P.158).
5. Push a new fuse (40A) into the clip.
6. Close the fuse holder cover.

Main Fuse

A spare fuse is located on the reverse side of the junction box lid.

1. Stop the engine and disconnect the battery cable.
2. Remove the engine cover. (P.120)
3. Remove the junction box lid.
 - ① Open the junction box lid.
 - ② Remove the junction box lid by lifting it.




4. Use the fuse puller from the fuse holder to remove the fuses (P.158, P.159). If a fuse is blown, install a replacement fuse of the same specified rating.


The outboard motor is supplied with spare fuses in the junction box lid.

MAIN FUSE RATINGS:

- DBW type:
7.5A, 10A, 15A, 30A
- Mechanical wire type:
10A, 15A, 30A



BLOWN FUSE



5. Reinstall the junction box lid, and the engine cover.
6. Reconnect the battery.

NOTICE


- Never use a fuse with a rating greater than specified. Serious damage to the electrical system could result.

If a blown fuse is found, try to determine and correct the electrical problem that caused the blown fuse. An uncorrected electrical problem may cause the fuse to blow again.

If fuses continue to blow, take the outboard motor to an authorized Marine dealer for inspection and service, or refer to the shop manual.

TAKING CARE OF UNEXPECTED PROBLEMS


(DBW type)



Fuse No.	Rating	Component(s) or Circuit(s) Protected
1	100 A	ACG, Battery
2	15 A	GROUND
3	7.5 A	Accessory
4	30 A	Main relay, Starter relay
5	7.5 A	Remote control system
6	30 A	Shift actuator
7	15 A	Throttle body
8	10 A	Fuel pump (High pressure side)
9	10 A	Sensors, ECU, DLC, SVS
10	15 A	Injectors, Ignition coils
11	15 A	Injectors, Ignition coils
	3 A	Power tilt switch, VST Relay

TAKING CARE OF UNEXPECTED PROBLEMS



(Mechanical wire type)



Fuse No.	Rating	Component(s) or Circuit(s) Protected
1	100 A	ACG, Battery
4	30 A	Main relay, Starter relay
5	10 A	Remote control system
8	10 A	Fuel pump (High pressure side)
9	10 A	Sensors, ECU, DLC, SVS
10	15 A	Injectors, Ignition coils
11	15 A	Injectors, Ignition coils
	3 A	Power tilt switch, VST Relay

TAKING CARE OF UNEXPECTED PROBLEMS

3 A Fuse




A spare fuse is located on the reverse side of the junction box lid.

1. Stop the engine and disconnect the battery cable.
2. Remove the engine cover. (P.120)
3. Remove the junction box lid. (P.156)
4. Remove the fuse case from the bracket.
5. Remove the fuse case lid.
6. Remove the old fuse out of the fuse case with the fuse puller supplied in the fuse holder. (P.158, P.159)
7. Install a new fuse. The outboard motor is supplied with spare fuse in the junction box lid.
FUSE RATING:
3 A
8. Be sure the fuse case lid is securely locked.
9. Reinstall the fuse case into the bracket.

10. Reinstall the junction box lid, and the engine cover.

11. Reconnect the battery.

ACG Fuse




TAKING CARE OF UNEXPECTED PROBLEMS

A spare fuse is located in the fuse holder.


1. Stop the engine and disconnect the battery cable.
2. Remove the engine cover. (P.120)
3. Remove the junction box lid. (P.156)
4. Remove the old fuse by removing two 5 mm screws.
5. Install a new fuse by tightening two 5 mm screws.
ACG FUSE: 100 A
6. Reinstall the junction box lid, and the engine cover.
7. Reconnect the battery.

LOW OIL PRESSURE INDICATOR COMES ON or OIL PRESSURE INDICATOR GOES OFF AND ENGINE SPEED IS LIMITED

(Multi-function Display)




(Side-mount type
(Mechanical wire type))



(Control panel with indicators type
(Mechanical wire type))

OIL PRESSURE INDICATOR



TAKING CARE OF UNEXPECTED PROBLEMS

For information about NMEA2000®-compatible device displays, refer to the display device's manual.

If oil pressure becomes low, the low oil pressure indicator comes on or the oil pressure indicator will go off, and the engine protection system limit engine speed. If you are at cruising speed, engine speed will decrease automatically.

The low oil pressure indicator is also equipped with a buzzer that sounds when the low oil pressure indicator comes on.

Low oil pressure may be the result of a low engine oil level, or there may be a problem with the engine lubrication system.

If the throttle is closed suddenly after full throttle operation, engine speed may drop below the specified idle rpm, and that could activate the engine protection system momentarily.


If low oil pressure activates the engine protection system, stop the engine, check the engine oil level (P.122), and add oil if needed.

With the engine oil at the recommended level, restart the engine. If the lubrication system is OK, the low oil pressure indicator does not come on or the oil pressure indicator should come on, and the engine will respond normally to throttle control lever operation.

If the engine protection system remains activated after 30 seconds, return to the nearest boat landing, and have the outboard motor inspected by an authorized Marine dealer.

OVERHEAT INDICATOR COMES ON AND ENGINE SPEED IS LIMITED

(Multi-function Display)




TAKING CARE OF UNEXPECTED PROBLEMS

(Side-mount type
(Mechanical wire type))

**OVERHEAT
INDICATOR**



(RED)




(Control panel with indicators type
(Mechanical wire type))

**OVERHEAT
INDICATOR**



(RED)



For information about NMEA2000®-compatible device displays, refer to the display device's manual.


If the engine overheats, the overheat indicator will come on, and the engine will stop in 20 seconds after the engine protection system limits engine speed. If you are at cruising speed, engine speed will decrease automatically.

All types are equipped with a buzzer that sounds when the overheat indicator comes on.

Engine overheating may be the result of restricted water intake screens, or there may be a problem with the cooling system thermostat or water pump.

If the engine is stopped after running at full throttle, and then restarted soon afterward, that could activate the engine protection system momentarily.

COOLING SYSTEM INDICATOR



If overheating activates the engine protection system, idle the engine in neutral, and check the cooling system indicator.


TAKING CARE OF UNEXPECTED PROBLEMS

If water is flowing from the cooling system indicator, continue idling for 30 seconds. If the cooling system is OK, the overheat indicator should go off within 30 seconds, and the engine will respond normally to throttle control lever operation.

If there is no water flowing from the cooling system indicator, stop the engine, and tilt the outboard motor to inspect the water intake screens. If restricted, clean the water intake screens, return the outboard motor to the running position, restart the engine, and check the cooling system indicator again.

If there is still no water flowing from the cooling system indicator, or if the engine protection system remains activated after 30 seconds, return to the nearest boat landing, and have the outboard motor inspected by an authorized Marine dealer.

WATER SEPARATOR BUZZER SOUNDS



WATER SEPARATOR

When the water separator buzzer sounds (a rapid, repeating signal):

Check the water separator for water contamination. If water is present, stop the engine, and clean the water separator following the instructions on P.134, or consult with an authorized Honda Marine dealer.

WHEN COLLIDING WITH AN UNDERWATER OBSTACLE

If you hit an underwater obstacle while underway, stop the engine immediately and inspect the outboard motor for any damage. If there are any abnormalities or if you cannot determine whether there is an abnormality, proceed slowly to the nearest port with extreme caution.

After arriving at the port, have the outboard motor inspected and any necessary repairs carried out by a dealer or service center before restarting the engine.

SUBMERGED OUTBOARD MOTOR

A submerged outboard motor must be serviced immediately after it is recovered from the water in order to minimize corrosion.


As soon as possible, take the outboard motor to an authorized Marine dealer for inspection and service.

Take the following measures until the outboard motor can be disassembled and serviced.

1. Remove the engine cover (P.120), and rinse the outboard motor with fresh water to remove salt water, sand, mud, etc.
2. Drain the vapor separator as described on P.146.
3. Change the engine oil on P.123. If there was water in the engine crankcase, or if the used engine oil showed signs of water contamination, then a second engine oil change should be performed after running the engine for half an hour.

TAKING CARE OF UNEXPECTED PROBLEMS

4. Remove all spark plugs (P.128), and remove the emergency stop switch clip from the emergency stop switch. Operate the starter to expel water from the engine's cylinder.



5. Put a teaspoon of engine oil into each spark plug hole to lubricate the inside of the cylinders. Reinstall the spark plugs.

If the engine was running when it submerged, there may be mechanical damage, such as bent connecting rods. If the engine binds when cranked, do not attempt to run the engine until it has been repaired.

6. Attempt to start the engine. Be sure the water level is at least 2 inches (5 cm) above the anti-cavitation plate.

NOTICE

- Running the outboard motor without sufficient cooling water will damage the water pump and overheat the engine.

If the engine fails to start, remove the spark plugs and dry them, then reinstall the spark plugs and attempt to start the engine again.

If the engine starts, and no mechanical damage is evident, continue to run the engine for a half hour or longer. Be sure the water level is at least 2 inches (5 cm) above the anti-cavitation plate to avoid overheating and water pump damage.


7. As soon as possible, take the outboard motor to an authorized Marine dealer for inspection and service.

EMERGENCY GEAR SHIFTING (DBW type)

If shifting cannot be performed with the control lever and the shift actuator is electrically damaged or malfunctioning, manual shifting may be available. Perform the shift operation according to the following procedure, return to port at low speed and consult your servicing dealer.

1. Set the gearshift/throttle control lever in the NEUTRAL position (P.31-33).
2. Stop the engine (P.82).
3. Remove the engine cover (P.120).
4. Shift gear into neutral by inserting the phillips screwdriver with the grip of the tool kit (P.115) into the hole of the shift pivot and moving the shaft.
5. Start the engine (P.72).
6. Shift gear into FORWARD or REVERSE by moving the shift pivot with the Phillips head screwdriver with the grip from the tool kit.

After returning to port, stop the engine and anchor the boat.




TECHNICAL INFORMATION

SERIAL NUMBER LOCATIONS

Record the frame serial number, the engine serial number, and the date of purchase in the space provided on this page. You will need these numbers when ordering parts, and when making technical or warranty inquiries (P.179).

FRAME SERIAL NUMBER




The frame serial number is stamped on a plate attached to the right side of the stern bracket.

Frame Serial Number:

Date of purchase:

ENGINE SERIAL NUMBER



The engine serial number is stamped on the upper right side of the engine.

Engine serial number:

BATTERY

WARNING

The battery contains sulfuric acid (electrolyte), which is highly corrosive and poisonous.

Getting electrolyte in your eyes or on your skin can cause serious burns.

Wear protective clothing and eye protection when working near the battery.

KEEP CHILDREN AWAY FROM THE BATTERY.

For complete information, refer to the battery manufacturer's instructions.

Minimum Requirements

12 V – 64 Ah/5 HR (80 Ah/20 HR)
(CCA622)

NOTICE

- Be careful to avoid connecting the battery in reverse polarity, as this will damage the battery-charging system in the outboard motor.
- Do not disconnect the battery cables while the engine is running. Disconnecting the cables while the engine is running will damage the outboard motor's electrical system.

NOTICE

- Battery cable extension: Extending the original battery cable will cause the battery voltage to drop due to the increased length of the cable and number of connections. This voltage drop may cause the buzzer to sound momentarily when engaging the starter motor and may prevent the engine from starting. If the engine starts and the buzzer sounds momentarily, there may be barely sufficient voltage reaching the engine.

WARNING

Battery posts, terminals, and related accessories contain lead and lead compounds.

Wash hands after handling.

EMISSION CONTROL SYSTEM INFORMATION

Source of Emissions

The combustion process produces carbon monoxide, oxides of nitrogen, and hydrocarbons. Control of hydrocarbons and oxides of nitrogen is very important because, under certain conditions, they react to form photochemical smog when subjected to sunlight. Carbon monoxide does not react in the same way, but it is toxic.

Honda utilizes appropriate air/fuel ratios and other emissions control systems to reduce the emissions of carbon monoxide, oxides of nitrogen, and hydrocarbons.

PGM-FI System

The PGM-FI system uses sequential multiport fuel injection. It has three subsystems: Air Intake, Engine Control, and Fuel Control. The Engine Control Module (ECM) uses various sensors to determine how much air is going into the engine. It then controls how much fuel to inject under all operating conditions.

Ignition Timing Control System

The system constantly adjusts the ignition timing, reducing the amount of HC, CO, and NOx produced.

The U.S., California Clean Air Acts, and Canadian Environmental Protection Act

EPA, California, and Canadian regulations require all manufacturers to furnish written instructions describing the operation and maintenance of emission control systems.

The following instructions and procedures must be followed in order to keep the emissions from your Honda engine within the emission standards.

Tampering and Altering

NOTICE

- Tampering is a violation of federal and California law.

Tampering with or altering the emission control system may increase emissions beyond the legal limit. Among those acts that constitute tampering are:

- Alterations that would cause the engine to operate outside its design parameters.
- Removal or alteration of any part of the intake, fuel, or exhaust systems.

Problems That May Affect Emissions

If you are aware of any of the following symptoms, have your engine inspected and repaired by your servicing dealer.

- Hard starting or stalling after starting
- Rough idle
- Misfiring or backfiring under load
- Afterburning (backfiring)
- Black exhaust smoke or high fuel consumption

TECHNICAL INFORMATION

Replacement Parts

The emission control systems on your Honda engine were designed, built, and certified to conform with EPA, California, and Canadian emission regulations. We recommend the use of Honda Genuine parts whenever you have maintenance done. These original-design replacement parts are manufactured to the same standards as the original parts, so you can be confident of their performance.

Honda cannot deny coverage under the emission warranty solely for the use of non-Honda replacement parts or service performed at a location other than an authorized Honda dealership; you may use comparable EPA certified parts, and have service performed at non-Honda locations. However, the use of replacement parts that are not of the original design and quality

may impair the effectiveness of your emissions control system.

A manufacturer of an aftermarket part assumes the responsibility that the part will not adversely affect emission performance. The manufacturer or rebuilder of the part must certify that use of the part will not result in a failure of the engine to comply with emission regulations.

Maintenance

As the outboard engine owner, you are responsible for completing all required maintenance listed in your owner's manual. Honda recommends that you retain all receipts covering maintenance on your outboard engine, but Honda cannot deny warranty coverage solely for the lack of receipts or for your failure to ensure that all scheduled maintenance has been completed.

Follow the MAINTENANCE SCHEDULE on page 116. Remember that this schedule is based on the assumption that your machine will be used for its designed purpose. Sustained high-load operation, or use in unusual conditions, will require more frequent service.

STAR LABEL

US, Puerto Rico, and US Virgin Islands

A Star label was applied to this outboard motor in accordance with the requirements of the California Air Resources Board.

The Star Label means Cleaner Marine Engine

This engine has been certified as a:



The Symbol for Cleaner Marine Engines:

Cleaner Air and Water - for healthier lifestyle and environment.

Better Fuel Economy - burns up to 30 - 40 percent less gas and oil than conventional carbureted two-stroke engines, saving money and resources.

Longer Emission Warranty - protects consumer for worry-free operation.

TECHNICAL INFORMATION



**One Star
Low Emission**

The one-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2001 exhaust emission standards. Engines meeting these standards have 75% lower emissions than conventional carbureted two-stroke engines. These engines are equivalent to the U.S. EPA's 2006 standards for marine engines.



**Two Stars
Very Low
Emission**

The two-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2004 exhaust emission standards. Engines meeting these standards have 20% lower emissions than One Star-Low Emission engines.



**Three Stars
Ultra Low
Emission**

The three-star label identifies engines that meet the Air Resources Board's Personal Watercraft and Outboard marine engine 2008 exhaust emission standards or the Sterndrive and Inboard marine engine 2003-2008 exhaust emission standards. Engines meeting these standards have 65% lower emissions than One Star-Low Emission engines.



**Four Stars
Super Ultra
Low Emission**

The four-star label identifies engines that meet the Air Resources Board's Sterndrive and Inboard marine engine 2009 exhaust emission standards. Personal Watercraft and Outboard marine engines may also comply with these standards. Engines meeting these standards have 90% lower emissions than One Star-Low Emission engines.

Cleaner Watercraft - Get the Facts
1-800-END-SMOG
www.arb.ca.gov

SPECIFICATIONS

MODEL	BF115JK1			
Description Code	BBWJ			
Type	LRA	LDA	XRA	XDA
Overall length	35.9 in (913 mm)			
Overall width	24.3 in (618 mm)			
Overall height	66.5 in (1,688 mm)		71.5 in (1,815 mm)	
Transom height (when transom angle at 12°)	20.0 in (508 mm)		25.0 in (635 mm)	
Dry mass (weight)*	487 lbs (221 kg)	494 lbs (224 kg)		500 lbs (227 kg)
Rated power	85.8 kW (115 HP)			
Full throttle range	4,500 – 6,000 rpm			
Engine type	4 stroke DOHC in-line 4-cylinder			
Displacement	143.6 cu-in (2,354 cm ³)			
Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)			
Starter system	Electric starter			
Ignition system	Fully transistorized, battery ignition			
Lubrication system	Trochoid pump pressure lubrication			
Specified oil	Engine: API standard (SG, SH, SJ, SL) SAE/FC-W 10W-30			
	Gear case: API standard (GL-4) SAE 90 Hypoid gear oil			

MODEL	BF115JK1
Oil capacity	Engine: 7.77 US qt (7.35 L) (When oil change: 6.9 US qt (6.5 L)) Gear case: 1.04 US qt (0.98 L)
CARB star label	ULTRA · LOW EMISSION
D.C. output	12V – 40A
Cooling system	Water cooling with thermostat
Exhaust system	Water exhaust
Spark plugs	IZFR6K11 (NGK)
Fuel pump	Low pressure side: mechanical type High pressure side: electromagnetic type
Fuel	Unleaded gasoline (86 pump octane or higher)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	30° right and left
Tilt angle (transom angle at 12°)	68° (Stageless)
Trim angle (transom angle at 12°)	– 4° to 16°

* Without battery cable, with propeller
 Honda outboard motors are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL INFORMATION

MODEL	BF140AK1				
Description Code	BBUJ				
Type	LRA	LDA	XRA	XDA XCRA	XCDA
Overall length	35.9 in (913 mm)				
Overall width	24.3 in (618 mm)				
Overall height	66.5 in (1,688 mm)		71.5 in (1,815 mm)		
Transom height (when transom angle at 12°)	20.0 in (508 mm)		25.0 in (635 mm)		
Dry mass (weight)*	487 lbs (221 kg)	494 lbs (224 kg)	500 lbs (227 kg)	507 lbs (230 kg)	
Rated power	104.4 kW (140 HP)				
Full throttle range	5,000 – 6,000 rpm				
Engine type	4 stroke DOHC VTEC in-line 4-cylinder				
Displacement	143.6 cu-in (2,354 cm ³)				
Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)				
Starter system	Electric starter				
Ignition system	Fully transistorized, battery ignition				
Lubrication system	Trochoid pump pressure lubrication				
Specified oil	Engine: API standard (SG, SH, SJ, SL) SAE/FC-W 10W-30 Gear case: API standard (GL-4) SAE 90 Hypoid gear oil				

MODEL	BF140AK1
Oil capacity	Engine: 7.77 US qt (7.35 L) (When oil change: 6.9 US qt (6.5 L)) Gear case: 1.04 US qt (0.98 L)
CARB star label	ULTRA · LOW EMISSION
D.C. output	12V – 40A
Cooling system	Water cooling with thermostat
Exhaust system	Water exhaust
Spark plugs	IZFR6K11 (NGK)
Fuel pump	Low pressure side: mechanical type High pressure side: electromagnetic type
Fuel	Unleaded gasoline (86 pump octane or higher)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	30° right and left
Tilt angle (transom angle at 12°)	68° (Stageless)
Trim angle (transom angle at 12°)	– 4° to 16°

* Without battery cable, with propeller
 Honda outboard motors are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL INFORMATION

MODEL	BF150DK1					
Description Code	BBTJ					
Type	JRA	LRA	LDA	XRA	XDA XCRA	XCDA
Overall length	35.9 in (913 mm)					
Overall width	24.3 in (618 mm)					
Overall height	46.3 in (1,177 mm)	66.5 in (1,688 mm)		71.5 in (1,815 mm)		
Transom height (when transom angle at 12°)	20.0 in (508 mm)			25.0 in (635 mm)		
Dry mass (weight)*	485 lbs (220 kg)	487 lbs (221 kg)	494 lbs (224 kg)		500 lbs (227 kg)	507 lbs (230 kg)
Rated power	111.9 kW (150 HP)					
Full throttle range	5,000 – 6,000 rpm					
Engine type	4 stroke DOHC VTEC in-line 4-cylinder					
Displacement	143.6 cu-in (2,354 cm ³)					
Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)					
Starter system	Electric starter					
Ignition system	Fully transistorized, battery ignition					
Lubrication system	Trochoid pump pressure lubrication					
Specified oil	Engine: API standard (SG, SH, SJ, SL) SAE/FC-W 10W-30					
	Gear case: API standard (GL-4) SAE 90 Hypoid gear oil					

MODEL	BF150DK1
Oil capacity	Engine: 7.77 US qt (7.35 L) (When oil change: 6.9 US qt (6.5 L)) Gear case: 1.04 US qt (0.98 L)
CARB star label	ULTRA · LOW EMISSION
D.C. output	12V – 40A
Cooling system	Water cooling with thermostat
Exhaust system	Water exhaust
Spark plugs	IZFR6K11 (NGK)
Fuel pump	Low pressure side: mechanical type High pressure side: electromagnetic type
Fuel	Unleaded gasoline (86 pump octane or higher)
Gear change	Forward-Neutral-Reverse (dog type)
Steering angle	30° right and left
Tilt angle (transom angle at 12°)	68° (Stageless)
Trim angle (transom angle at 12°)	– 4° to 16°

* Without battery cable, with propeller
 Honda outboard motors are power rated in accordance with NMMA procedures and using the ICOMIA standard 28/23.

TECHNICAL INFORMATION

BF115J Tune up

Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)	See page 128
Idle speed	750 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.23 ± 0.02 mm Exhaust: 0.30 ± 0.02 mm	See shop manual
Other specifications	No other adjustments needed	

BF140A Tune up

Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)	See page 128
Idle speed	750 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.23 ± 0.02 mm Exhaust: 0.30 ± 0.02 mm	See shop manual
Other specifications	No other adjustments needed	

BF150D Tune up

Spark plug gap	0.039 – 0.043 in (1.0 – 1.1 mm)	See page 128
Idle speed	750 ± 50 rpm	See shop manual
Valve clearance (cold)	Intake: 0.23 ± 0.02 mm Exhaust: 0.30 ± 0.02 mm	See shop manual
Other specifications	No other adjustments needed	

Dealer Locator Information

To find an authorized Honda
Servicing Dealer

For USA:
Visit our website:
<http://marine.honda.com> and click
on Find a Dealer

For Canada:
Call 1-888-946-6329 or visit our
website:
English
[http://marine.honda.ca/
dealerlocator](http://marine.honda.ca/dealerlocator)
French
[http://marine.honda.ca/trouver-
concessionnaire](http://marine.honda.ca/trouver-concessionnaire)

Honda Publications

These publications will give
you additional information for
maintaining and repairing your
outboard motor.

Shop Manual

This manual covers complete
maintenance and overhaul
procedures. It is intended to be
used by a skilled technician.

For USA:
Shop manuals are available
through your Honda
Marine dealer or visit [http://
marine.honda.com /Service &
Support](http://marine.honda.com/Service&Support) and click on Shop
Manuals

For Canada:
Contact your dealer for
information on the Shop Manual.

Parts Catalog

For USA:
This manual provides complete,
illustrated parts lists. The
catalog is available through your
Honda Marine dealer or visit
[http://marine.honda.com/Parts &
Accessories](http://marine.honda.com/Parts&Accessories) and click on Look Up
Parts

For Canada:
Contact your dealer for
information on Parts.

Accessory Catalog:
See page 180.

CONSUMER INFORMATION

Accessory Catalog

Your authorized Honda Marine dealer offers a wide selection of accessories (optional equipment, oils, and lubricants) to enhance your boating experience.

For USA:

Visit <http://marine.honda.com> and click on PARTS & ACCESSORIES to see the entire catalog of accessories.

For Canada:

Check with your dealer or visit www.honda.ca and select the Parts and Accessories tab under the Honda Marine segment to view the range of accessories available.

Customer Service Information

Contacting Honda

Your Owner's Manual was written to cover most of the questions you might ask about your Honda. Any questions not answered in the Owner's Manual can be answered by your Honda dealer. If your dealer doesn't have an immediate answer, they should be able to get it for you.

If you have a difference of opinion with your dealer, please remember that each dealership is independently owned and operated. That's why it's important to work to resolve any differences at the dealership level. If the service personnel are unable to assist you, please discuss your concerns with the dealer management such as the Service

Manager or the dealership's owner.

If you need to contact Honda regarding your experiences with your Honda product or with your dealer, please contact the Honda office in your region:

American Honda Motor Co., Inc.

Marine Division
Customer Relations Office
4900 Marconi Drive Alpharetta, GA
30005-8847
Telephone (770) 497 – 6400
M-F 9:00 am-7:30 pm (Eastern Time Zone)

In Canada:

Honda Canada Inc.

Customer Relations Department

180 Honda Boulevard

Markham, Ontario L6C 0H9

Tel: 1-888-946-6329 (Toll free)

Fax: 1-877-939-0909 (Toll free)

Please include the following information in your communication:

- Your name, address and telephone number (complete with area code)
- Model and complete serial number
- Date of purchase
- Name and location of selling dealer
- Name and location of servicing dealer (if different)
- A detailed description of your concerns

We will likely ask your Honda dealer to respond, or possibly acknowledge your comments directly.

Warranty Coverage

Your new Honda is covered by the following warranties:

- Distributor's Limited Warranty
- Emission Control System Warranty

Please read the warranty statements contained in this manual. There are responsibilities, restrictions, and exclusions that apply to these warranties.

To obtain warranty service you must take your Honda outboard motor, together with proof of original retail purchase date, at your expense, to a Honda engine dealer or distributor authorized to sell that product in the United States, Puerto Rico, the U.S. Virgin Islands or Canada.

It is important to realize that your warranty applies to defects in material or workmanship of your Honda. Your warranty coverage does not apply to normal wear or deterioration associated with using your Honda outboard motor.

CONSUMER INFORMATION

Your warranty coverage will not be voided if you choose to perform your own maintenance. However, you should have the proper tools and service information and be mechanically qualified. Failures that occur due to modifications, improper maintenance, or service are not covered.

Warranty Service

Please remember that recommended maintenance interval servicing is not included in your warranty coverage. Additionally, your warranty does not apply to the normal wear of items (such as spark plug(s), water pump, etc.).

As the owner of a Honda product, your servicing dealer may ask you to authorize an inspection. If the problem is covered under warranty, your dealer will perform any warranty repairs for you at no cost. However, you may be responsible for additional non-warranty charges.

If you have questions about warranty coverage or the nature of the repair, it is best to talk to the service manager of your Honda dealer.

Sometimes, in spite of the best intentions of all concerned, a misunderstanding may occur. If you aren't satisfied with your dealer's handling of the situation, we suggest you discuss your problem with the appropriate member of the dealership's management team. If the problem has already been reviewed with the appropriate manager of the Service, Parts, or Sales department, contact the owner of the dealership or their designated representative.

Warranty Statements

The American Honda Distributor's Limited Warranty applies to outboards purchased in the United States, Puerto Rico, or the U.S. Virgin Islands. The Honda Canada Distributor's Warranty applies to outboards purchased in Canada. The product warranty is only valid in the country where the product was purchased.

United States, Puerto Rico and U.S. Virgin Islands

Distributor's Limited Warranty

This warranty is limited to Honda Outboard Motors and related original equipment distributed by American Honda Motor Co., Inc., Power Sports and Products Division, 4900 Marconi Drive, Alpharetta, Georgia 30005-8847.

Products Covered by Warranty:	Length of Warranty: (from date of original retail purchase)		
	NON-COMMERCIAL/ NON-RENTAL	COMMERCIAL/RENTAL	STATE/LOCAL/ FEDERAL GOVERNMENT
All models purchased on or after Jan. 1, 2016 (2)	60 months	24 months	36 months
All models purchased between July 1, 2008 and December 31, 2015 (2)	60 months	12 months	24 months
All models purchased on or before June 30, 2008 (1)(2)	36 months	12 months	24 months
Related original equipment items: BF5 through BF20 models: Portable fuel tank and original propeller. All models: Primer bulb/fuel line assembly and tiller handle.	The same duration as the outboard with which they were purchased.(3)		

(1) Models purchased prior to July 1, 2008 (unless previously purchased with True-5 warranty from a participating dealer).

(2) 40, 65, & 105 Jet models: Jet pump assembly is a dealer installed option. Jet pump warranty is provided by Specialty Manufacturing Co. (Outboard Jets).

(3) Portable fuel tanks: 24 months or the same duration as the outboard they were purchased with, whichever is longer.

CONSUMER INFORMATION

To Qualify for This Warranty:

The Honda Outboard Motor must be purchased from American Honda or a dealer authorized by American Honda to sell Honda Outboard Motors in the United States, Puerto Rico, or the U.S. Virgin Islands. This limited warranty applies to the first retail purchaser and each subsequent owner during the applicable warranty time period.

What American Honda Will Repair or Replace Under Warranty:

American Honda will repair or replace, at its option, any part that is proven to be defective in material or workmanship under normal use during the applicable warranty time period. Warranty repairs and replacements will be made without charge for parts or labor. Anything replaced under warranty becomes the property of American Honda Motor Co., Inc. All parts replaced under warranty will be considered as part of the original product and any warranty on those parts will expire coincidentally with the original product warranty.

To Obtain Warranty Service:

You must, at your expense, take your Honda Outboard Motor and proof of the original purchase date to any dealer who is authorized to service Honda Outboard Motors in the United States, Puerto Rico, or the U.S. Virgin Islands, during the dealer's normal business hours. If you are unable to obtain warranty service, or are dissatisfied with the warranty service you receive, take the following steps: First, contact the owner of the dealership involved; normally this should resolve the problem. However, if you should require further assistance, write or call the Honda Marine Customer Relations Department of American Honda Motor Co., Inc. Please see Contacting Honda on page 180.

Exclusions:

This warranty does not extend to the following:

- Conditions caused by lack of routine maintenance or improper storage (as outlined in the Owner's Manual)
- Conditions caused by the use of propeller (s) that do not allow the outboard motor to run in its recommended full throttle rpm range
- Operation inconsistent with the recommended operation/duty cycle (as outlined in the Owner's Manual)
- Parts affected or damaged by an abuse, submersion and/or collision
- Fuel contamination and water entering the engine through the fuel intake, air intake, or exhaust system
- Operation with fuels, oils, additives and lubricants which are not suitable for use in the product
- Use in an application for which the outboard motor was not designed, such as racing or competitive use or any other misuse or neglect
- Normal wear and tear
- Incorporation of unsuitable attachments or parts
- The unauthorized alteration, improper installation and/ or rigging, or any causes other than defects in material or workmanship
- Corrosion to steering system or electrical components, corrosion due to electrolysis, water born foreign chemicals, improper service or corrosion caused by damage or abuse
- Reimbursement for towing charges, in and out of water charges, or technician travel time
- Growth of marine organisms on motor surfaces, external or internal
- Any product that has ever been declared a total loss or sold for salvage by a financial institution or insurer, or that has been issued a "salvage" or similar title under any state's law.

CONSUMER INFORMATION

Disclaimer of consequential damage and limitation of implied warranties:

American Honda disclaims any responsibility for loss of time or use of the outboard, revenue, or the equipment in which the outboard is installed, transportation, commercial loss, or any other incidental or consequential damage. Any implied warranties are limited to the duration of this written limited warranty.

Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusions and limitations may not apply to you.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Accessories and Replacement Parts

This warranty is limited to Honda Marine parts, accessories and apparel when distributed by American Honda Motor Co., Inc., 4900 Marconi Drive, Alpharetta, Georgia 30005-8847.

Products Covered by Warranty:	Length of Warranty: (from date of original retail purchase)		
	NON-COMMERCIAL	COMMERCIAL/RENTAL	STATE/LOCAL/FEDERAL GOVERNMENT
Accessories other than noted below	12 months	3 months	3 months
Emission related accessories: Portable fuel tanks, fuel line assemblies, and water/fuel separators	24 months	24 months	24 months
Replacement Parts	6 months	3 months	3 months

CONSUMER INFORMATION

To Qualify for This Warranty:

1. The accessories or replacement parts must be purchased from American Honda or a dealer, distributor, or distributor's dealer authorized by American Honda to sell those products in the United States, Puerto Rico, and the U.S. Virgin Islands. Parts and Accessories must be purchased for installation on original Honda equipment or engines to be eligible for warranty coverage. Installing Parts and Accessories on non-Honda products or engines voids this warranty.
2. You must be the first retail purchaser. This warranty is not transferable to subsequent owners.

What American Honda Will Repair or Replace Under Warranty:

American Honda will repair or replace, at its option, any marine product accessories or replacement parts that are proven to be defective in material or workmanship under normal use during the applicable warranty time period.

Anything replaced under warranty becomes the property of American Honda Motor Co., Inc. All parts replaced under warranty will be considered as part of the original product and any warranty on those parts will expire coincidentally with the original product warranty.

Accessories and replacement parts, installed by a dealer who is authorized by American Honda to sell them, will be repaired or replaced under warranty without charge for parts or labor. If installed by anyone else, accessories and replacement parts will be repaired or replaced under warranty without charge for parts, but any labor charges will be the responsibility of the purchaser.

To Obtain Warranty Service:

You must, at your expense, take the Honda Outboard Motor product accessory or replacement part or the outboard motor or boat on which the accessory or replacement part is installed, and proof of purchase to any Honda Marine authorized service facility or dealer in the United States, Puerto Rico, or the U.S. Virgin Islands, during normal business hours.

Exclusions:

This warranty does not extend to accessories or parts affected or damaged by collision, normal wear, use in an application for which the product was not designed or any other misuse, neglect, incorporation or use of unsuitable attachments or parts, unauthorized alteration, improper installation, or any causes other than defects in material or workmanship of the product.

Installing parts and accessories on non-Honda products or engines voids this warranty.

Disclaimer of consequential damage and limitation of implied warranties:

American Honda disclaims any responsibility for loss of time or use of the outboard motor, or the boat on which the product is installed, transportation, commercial loss, or any other incidental or consequential damage. Any implied warranties are limited to the duration of this written warranty. Some states do not allow limitations on how long an implied warranty lasts and/or do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusions and limitations may not apply to you. This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.

CONSUMER INFORMATION

Emission Control System Warranty

Your new Honda outboard engine complies with both the U.S. EPA and State of California emission regulations.

American Honda provides the same emission warranty coverage for outboard engines sold in all 50 states. In all areas of the United States your outboard engine must be designed, built, and equipped to meet the U.S. EPA and California Air Resources Board emission standard for spark ignited marine engines.

CALIFORNIA EMISSIONS CONTROL SYSTEM WARRANTY STATEMENT YOUR WARRANTY RIGHTS AND OBLIGATIONS

The California Air Resources Board (CARB) and American Honda Motor Co., Inc. are pleased to explain the emission control system warranty on your 2025 Honda outboard engine. In California, new outboard engines must be designed, built, and equipped to meet the state's stringent anti-smog standards.

American Honda Motor Co., Inc. must warrant the emission control system on your outboard engine for the periods of time listed below provided there has been no abuse, neglect, or improper maintenance of your outboard engine.

Your emission control system may include parts such as the carburetor or fuel injection system, the ignition system, catalytic converter, canisters, clamps, filters, fuel caps, fuel lines, fuel tanks, valves, and vapor hoses. Also included may be hoses, belts, connectors, and other emission-related assemblies.

Where a warrantable condition exists, American Honda Motor Co., Inc. will repair your outboard engine at no cost to you including diagnosis, parts, and labor.

MANUFACTURER'S WARRANTY COVERAGE:

Select emission control parts from model year 2010 and later outboard engines are warranted for five years or 250 hours of use, whichever first occurs; or the length of the Honda Marine Distributor's Limited Warranty, whichever is longer. The evaporative emission control system from model year 2010 and later outboard engines are warranted for two years with no limit on hours of use, or the length of the Honda Marine Distributor's Limited Warranty, whichever is longer, from the date of delivery to the retail purchaser. However, warranty coverage based on the hourly period is only permitted for engines equipped with hour meters as defined in § 2441(a) (13)* or their equivalent. If any emission-related part on your engine is defective under warranty, the part will be repaired or replaced by American Honda Motor Co., Inc. See the Emission Control System Warranty Parts table on page 195 for parts description.

* California Code of Regulations

OWNER'S WARRANTY RESPONSIBILITIES:

As the outboard engine owner, you are responsible for the performance of the required maintenance listed in your owner's manual. American Honda Motor Co., Inc. recommends that you retain all receipts covering maintenance on your outboard engine, but American Honda Motor Co., Inc. cannot deny warranty solely for the lack of receipts or your failure to ensure the performance of all scheduled maintenance.

As the outboard engine owner, you should, however, be aware that American Honda Motor Co., Inc. may deny you warranty coverage if your outboard engine or a part has failed due to abuse, neglect, improper maintenance, or unapproved modifications.

You are responsible for presenting your outboard engine to a Honda Marine dealer as soon as a problem exists. The warranty repairs will be completed in a reasonable amount of time, not to exceed 30 days.

CONSUMER INFORMATION

If you have any questions regarding your warranty rights and responsibilities, you should contact

American Honda Motor Co., Inc.

Marine Division Customer Relations Office

4900 Marconi Drive

Alpharetta, Georgia 30005-8847

Telephone: (770) 497-6400

WARRANTY COVERAGE:

See Manufacturer's Warranty Coverage above for warranty coverage terms. This warranty is transferred to each subsequent purchaser for the duration of the warranty period.

Warranty repairs will be made without charge for diagnosis, parts, and labor. All defective parts replaced under this warranty become the property of American Honda Motor Co., Inc. A list of warranty parts is on the reverse side of this statement. Normal maintenance items, such as spark plugs and filters, that are on the warranted parts list are warranted up to their required replacement interval only.

American Honda Motor Co., Inc. is also liable for damages to other engine components caused by a failure of any warranted part during the warranty period.

Only Honda approved replacement parts will be used in the performance of any warranty repairs, and they will be provided without charge to the owner. You may use any replacement part as defined in § 1900(b)(20)* in the performance of any maintenance or repairs. Honda cannot deny coverage under the emission warranty solely for use of non-Honda replacement parts or service performed at a location other than an authorized Honda dealership; however, use of a part that is not functionally identical to the original equipment part in any respect that may in any way affect emissions (including durability) could result in denial of coverage. If a non-Honda replacement part is used in the repair or maintenance of your engine, and an authorized Honda Marine dealer determines it causes the failure of a warranted part, your warranty claim may be denied. If the part in question is not related to the reason that your engine requires repair, your claim will not be denied.

* California Code of Regulations

TO OBTAIN WARRANTY SERVICE:

You must take your Honda outboard engine, along with your sales registration card or other proof of original purchase date, at your expense, to any Honda Marine dealer that is authorized by American Honda Motor Co., Inc. to sell and service that Honda marine product during its normal business hours. Claims for repair or adjustment found to be caused solely by defects in material or workmanship will not be denied because the engine was not properly maintained and used.

If you are unable to obtain warranty service, or are dissatisfied with the warranty service you received, contact the owner of the dealership involved. Normally this should resolve your problem. However, if you require further assistance, write or call the Honda Marine Customer Relations Office of American Honda Motor Co., Inc.

CONSUMER INFORMATION

EXCLUSIONS:

Failures other than those resulting from defects in material or workmanship are not covered by this warranty. This warranty does not extend to emission control systems or parts which are affected or damaged by owner abuse, neglect, improper maintenance, misuse, misfueling, improper storage, and/or collision, the incorporation of, or use of, unsuitable attachments, or the unauthorized alteration of any part.

This warranty does not cover replacement of expendable maintenance items made in connection with required maintenance service after the items first scheduled replacement as listed in the maintenance section of the product owner's manual, such as: spark plugs and filters.

DISCLAIMER OF CONSEQUENTIAL DAMAGE AND LIMITATION OF IMPLIED WARRANTIES:

American Honda Motor Co., Inc. disclaims any responsibility for incidental or consequential damages such as loss of time or the use of outboard engine, or any commercial loss due to the failure of the equipment; and any implied warranties are limited to the duration of this written warranty. This warranty is applicable only where the California or U.S. EPA emission control system warranty regulation is in effect.

EMISSION CONTROL SYSTEM WARRANTY PARTS:

SYSTEMS COVERED BY THIS WARRANTY:	PARTS DESCRIPTION:	LENGTH OF WARRANTY:
Evaporative	Portable fuel tank, Outboard internal fuel tank, Fuel cap, Fuel hoses, Primer bulb, Fuel hose joint, Vapor separator, and Carbon canister, All other parts not listed that may affect the evaporative emissions control system	Two years, no limit on hours of use; or the length of the Honda Distributor's Limited Warranty, whichever is longer.
Fuel Metering	Carburetor assembly, Throttle body, Fuel injector, Fuel pump, Fuel pressure regulator, Throttle position sensor, Intake air temperature sensor, Engine temperature sensor, Manifold absolute pressure sensor, Idle air control valve, Barometric pressure sensor, Fuel line solenoid valve, Intake manifold, Intake valves, and Oxygen sensor or Air fuel ratio sensor	Five years or 250 hours of use, whichever first occurs; or the length of the Honda Distributor's Limited Warranty, whichever is longer.
Air Induction	Air intake duct, Intake manifold tuning valve (Intake air bypass control valve)	
Ignition	Flywheel magneto, Ignition pulse generator, Ignition coil assembly, Ignition control module, Engine control module, Crankshaft position sensor, Spark plug cap, Spark plug*, Knock sensor, and Camshaft position sensor	
Lubrication System	Oil pump and internal parts	
Crankcase Emission Control	Crankcase breather tube, Positive crankcase ventilation valve, Oil filler cap	
Exhaust	Exhaust manifold and Exhaust valves	
Valve Control System	Rocker arm oil control valve	
Miscellaneous Parts	Tubing, fittings, seals, gaskets, and clamps associated with these listed systems.	
* Covered up to the first required replacement only. See the Maintenance Schedule on page 116.		

CONSUMER INFORMATION

Canada

Distributor's Warranty

HONDA CANADA INC., for and on behalf of Honda Motor Co. Ltd., Tokyo, Japan, gives the following written warranty on each new marine product manufactured by Honda Motor Co. Ltd., Japan, distributed in Canada by Honda Canada Inc. and sold by authorized Honda Marine dealers.

Whenever used herein, the word "Honda" refers to Honda Canada Inc. and/or Honda Motor Co. Ltd., as appropriate from the context.

HONDA WARRANTS THAT each new Honda Marine product will be free, under normal use and maintenance, from any defects in material or workmanship for the relevant warranty period set forth below. If any defects should be found in a Honda Marine product within the relevant warranty period, necessary repairs and replacements with a new part or the Honda equivalent shall be made at no cost to the consumer for parts and labour, when Honda acknowledges that such defects are attributable to faulty material or workmanship at the time of manufacture.

WARRANTY PERIOD RETAILED ON OR AFTER APRIL 1, 2005:

	Non-commercial use	Commercial use
All Honda Outboard Models	36 Months	12 Months

THIS WARRANTY COVERS

- a) Any Honda Marine product purchased in Canada from an authorized Honda dealer which has been registered at the time of purchase on a form provided by Honda, which has had set-up and pre-delivery service performed by an authorized Honda dealer and which is normally operated in Canada;
- b) Any factory installed part (except normal maintenance parts referred to in "THIS WARRANTY DOES NOT COVER"); and
- c) Any marine product on which required maintenance services have been performed as prescribed in the Owner's Manual.

THIS WARRANTY DOES NOT COVER

- a) Any repairs required as a result of collision, accident, striking any object, misuse or lack of required maintenance;
- b) Any repairs required as a result of any attachments, parts or devices installed by or repairs done by a party other than an authorized Honda dealer;
- c) Any outboard that has been operated out of water, (Run Dry) damaging the water pump and or engine components due to insufficient cooling water.
- d) Any marine products modified, altered, disassembled or remodelled;
- e) Normal maintenance services, including tightening of nuts, bolts and fittings and engine tune-up and the replacement of parts made in connection with normal maintenance services including filters, spark plugs and wires, fuses, belts, lubricants and other expendables susceptible to natural wear;
- f) Outboard propeller or shear pin; and
- g) All accessories or attachments.

CONSUMER INFORMATION

THE OWNER'S OBLIGATION

In order to maintain the validity of this DISTRIBUTORS WARRANTY, the required maintenance services as set forth in the Owner's Manual must be performed at the proper intervals and detailed receipts and records retained as proof.

TO OBTAIN WARRANTY SERVICE

You must take your Honda Marine product, at your expense, during normal service hours, to any authorized Honda Marine dealership. If you are unable to obtain or are dissatisfied with the warranty service you receive, first contact the owner of the dealership involved; this should resolve the problem.

If you require further assistance, contact Honda Canada's Customer Relations Department at:
HONDA CANADA INC.

Customer Relations Office
180 Honda Boulevard
Markham, Ontario L6C 0H9

TELEPHONE: 1-888-946-6329 TOLL FREE
FAX : 1-877-939-0909 TOLL FREE

REPLACEMENT PARTS AND ACCESSORY WARRANTY

New genuine Honda replacement parts or accessories sold to a consumer or installed by an authorized Honda Marine dealer which are not covered by the DISTRIBUTORS WARRANTY are warranted for a period of one year from date of purchase, provided, however, that this Replacement Parts and Accessory Warranty does not apply to any replacement parts modified, used with, or installed on a marine product for which the replacement parts were not intended. Electrical components that are not installed by the dealer (sold over the counter) are not covered by warranty.

ENTIRE WRITTEN WARRANTY

This DISTRIBUTORS WARRANTY and the REPLACEMENT PARTS AND ACCESSORY WARRANTY are the only and the entire written warranties given by Honda for Marine engines. No dealer or his agent or employee is authorized to extend or enlarge on these warranties on behalf of Honda by any written or verbal statement or advertisement.

DISCLAIMER

To the extent the law permits, Honda disclaims any responsibility for loss of time or use of the product, transportation or towing costs or any other indirect, incidental or consequential damage, inconvenience or commercial loss.

NOTICE TO CONSUMER

The provisions contained in these written warranties are not intended to limit, modify, take away from, disclaim or exclude any warranties set forth in or the operation of The Consumer Products Warranties Act, 1977 (Saskatchewan), The Consumer Product Warranty and Liability Act (New Brunswick), The Consumer Protection Act (Quebec), or any other similar provincial or federal legislation.

INDEX

1

1 LEVER Switch45, 100

3

3 A Fuse.....160

A

ACG Fuse.....160

Active Mode.....42, 75

ACTIVE Switch42, 75

ACTIVE/FAST IDLE Switch.....42, 75

Alternator (ACG) Indicator59

ANODE65

INSPECTION.....137

ARE YOU READY TO GET UNDERWAY?67

Automatic Tilt Mode107

B

BATTERY.....169

Battery Will Not Charge155

Battery Switch OFF Notification66

BEFORE OPERATION.....67

BREAK-IN PROCEDURE.....70

C

CLEANING AND FLUSHING.....140

COMMON CONTROLS48

COMPONENT AND CONTROL LOCATIONS.....13

CONSUMER INFORMATION.....179

CONTROL AND FEATURE IDENTIFICATION CODES11

CONTROLS26

CONTROLS AND FEATURES11

Cooling System Indicator.....63

Cruise Control Mode101

CRUISE/UP Switch.....46, 99

CRUISING92

Customer Service Information.....180

D

Dealer Locator Information179

Distributor's Limited Warranty183

Distributor's Warranty.....196

E

ELECTRIC STARTER WILL NOT OPERATE.....151, 155

Emergency Engine Stopping.....82, 85

EMERGENCY GEAR SHIFTING167

Emergency Stop Switch.....29

Emergency Stop Switch Clip29

Spare Emergency Stop Switch Clip116

EMISSION CONTROL SYSTEM INFORMATION170

Emission Control System Warranty.....190

ENGINE COVER

Engine Cover Latch55

REMOVAL AND INSTALLATION	120
ENGINE OIL	
ENGINE OIL CHANGE.....	123
ENGINE OIL LEVEL CHECK.....	122
ENGINE OIL RECOMMENDATIONS	124
STORAGE	147
ENGINE OVERHEATS.....	154
ENGINE WILL NOT START	152

F

Fast Idle Button	37, 39
Fast Idle Lever	35
Fast Idle Mode	
ACTIVE/FAST IDLE Switch	42
FAST IDLE Switch	42
FAST IDLE Switch.....	42
FUEL	
Draining the Fuel System.....	146
FUEL PRIMING	71
Fuel Priming Bulb.....	65
FUEL RECOMMENDATIONS	133
REFUELING.....	132
STORAGE	143
FUEL FILTER WITH WATER SEPARATOR (LOW PRESSURE SIDE).....	134
Inspection	135
Replacement.....	136

Water Separator Buzzer	64
FUSE.....	155
Fuse Replacement.....	155

G

GEARSHIFT AND THROTTLE OPERATION.....	87
Gearshift/Throttle Control Lever	
Side-Mount type	34
Flush-Mount Type	31, 36
Top-Mount Type.....	32, 38
Gearshift/Throttle Control Lever Friction	88

H

HARD STARTING OR STALLS AFTER STARTING	153
HOISTING THE OUTBOARD MOTOR	147
Honda Publications	179
HOW TO DETERMINE WHICH DIRECTION THE PROPELLER SHAFT ROTATES.....	12

I

Ignition Switch	26
IMPORTANT SAFETY INFORMATION	7
INDICATORS	59
INFREQUENT OR OCCASIONAL USE	72
IS YOUR OUTBOARD MOTOR READY TO GO?	67

INDEX

L

Low Oil Pressure Indicator	61
LOW OIL PRESSURE INDICATOR COMES ON or OIL PRESSURE INDICATOR GOES OFF AND ENGINE SPEED IS LIMITED	161
LUBRICATION POINTS	125

M

Main Fuse	156
MAINTENANCE SAFETY	114
MAINTENANCE SCHEDULE	116
Malfunction Indicator	60
Manual Relief Valve	52, 109
MOORING, BEACHING, LAUNCHING	103
MULTIPLE OUTBOARD MOTORS	109

N

NMEA 2000® Interface Coupler	56
Normal Engine Stopping	83, 85

O

Oil Pressure Indicator	61
One-lever Mode	100
Operating Hour Notification System	56
OPERATION	70
OTHER FEATURES	64
OUTBOARD MOTOR SAFETY	7

Overheat Indicator	62
OVERHEAT INDICATOR COMES ON AND ENGINE SPEED IS LIMITED	162
OWNER'S MANUAL	115

P

Power Harness Fuse	156
Power Reduction	66
Power Switch	27
Power Tilt Switch	51, 108
Power Trim/Tilt Switch	48, 93
PROPELLER REPLACEMENT	138

R

REFUELING	132
REMOVAL FROM STORAGE	149
Rev Limiter	64

S

SAFE OPERATING PRECAUTIONS	70
SAFETY LABEL LOCATION	10
Select Switch	40
SERIAL NUMBER LOCATIONS	168
SERVICING YOUR OUTBOARD MOTOR	113
SHALLOW WATER OPERATION	102
SPARE EMERGENCY STOP SWITCH CLIP	116
SPARK PLUG SERVICE	128

SPECIFICATIONS	175
STAR LABEL	173
START/STOP Switch	28
STARTING THE ENGINE	72
STEERING	91
STOPPING THE ENGINE	82
Emergency Engine Stopping	82, 85
Normal Engine Stopping	83, 85
STORAGE	143
ENGINE OIL	147
FUEL	143
STORAGE PRECAUTIONS	148
SUBMERGED OUTBOARD MOTOR	165

T

Tachometer	55
TAKING CARE OF UNEXPECTED PROBLEMS	151
TECHNICAL INFORMATION	168
THE IMPORTANCE OF MAINTENANCE	113
Tilt Lock Lever	53, 105
TOOL KIT	115
TRANSPORTING	150
Trim	93
TRIM SPT. Switch	48
Trim Support Mode	48, 97
Trim Tab	55
TRIM TAB ADJUSTMENT	119

TROLL/DN Switch	44
Trolling Control Mode	44, 99
TRL (Trolling) Control Switch	54, 96
TURNING WHEN MULTIPLE ENGINES ARE MOUNTED ...	110

W

Warranty Statements	183
Water Separator Buzzer	64
WATER SEPARATOR BUZZER SOUNDS	164
WHEN COLLIDING WITH AN UNDERWATER OBSTACLE	165

MEMO

HONDA

31ZVT610
00X31-ZVT-6100



英 AB 0000.00AA.AA
Printed in Japan