

PARTS AND OPERATION MANUAL



Bullfloat — HAL 150 & 300

© COPYRIGHT 2001, MULTQUIP INC.

Revision #2 (03/12/01)



MULTQUIP INC.

18910 WILMINGTON AVE.
CARSON, CALIFORNIA 90746
310-537-3700
800-421-1244
FAX: 310-537-3927

PARTS DEPARTMENT:

800-427-1244
FAX: 800-672-7877

SERVICE DEPARTMENT:

800-478-1244
FAX: 310-537-4259

E-mail: mq@multiquip.com • **www:** www.multiquip.com

Atlanta • Boise • Dallas • Houston • Newark
Montreal, Canada • Manchester, UK
Rio De Janeiro, Brazil • Guadalajara, Mexico



WARNING



CALIFORNIA — Proposition 65 Warning

Engine exhaust and some of its constituents, and some dust created by power sanding, sawing, grinding, drilling and other construction activities contains chemicals known to the State of California to cause cancer, birth defects and other reproductive harm. Some examples of these chemicals are:

- Lead from lead-based paints.
- Crystalline silica from bricks.
- Cement and other masonry products.
- Arsenic and chromium from chemically treated lumber.

Your risk from these exposures varies, depending on how often you do this type of work. To reduce your exposure to these chemicals: **ALWAYS** work in a well ventilated area, and work with approved safety equipment, such as dust masks that are specially designed to filter out microscopic particles.

HERE'S HOW TO GET HELP

*PLEASE HAVE THE MODEL AND SERIAL NUMBER
ON-HAND WHEN CALLING*

PARTS DEPARTMENT

800-427-1244 or 310-537-3700

FAX: 800-672-7877 or 310-637-3284

SERVICE DEPARTMENT/TECHNICAL ASSISTANCE

800-478-1244 or 310-537-3700

FAX: 310- 537-4259

WARRANTY DEPARTMENT

888-661-4279, or 310-661-4279

FAX: 310- 537-1173

MAIN

800-421-1244 or 310-537-3700

FAX: 310-537-3927

Here's How To Get Help	3
Table Of Contents	4
Parts Ordering Procedures	5
Explanation Of Codes In Remarks Column	6

BULLFLOAT HAL 150 & 300

Safety Instructions	7-8
Specifications	9
What is a Bullfloat	10-11
Operation	12-14
Trouble Shooting	15
Maintenance and Repair	16-17

HAL 150 & 300

Frame	18-19
Electric Drive Unit & Switch	20-21
Electric Drive Unit Components	22-23
Gas Drive Unit & Gas Throttle	24-25

ROBIN ENGINE EC0250G6004

Crankcase & Cylinder	26-27
Crankshaft & Piston	28-29
Muffler & Air Cleaner	30-31
Recoil Starter & Housing	32-33
Carburetor & Fuel Tank	34-35
Coil & Spark Plug	36-37

Terms and Conditions Of Sale — Parts	38
--	----

*NOTE: Specification and part number
are subject to change without notice.*

PARTS ORDERING PROCEDURES

- Dealer account number
- Dealer name and address
- Shipping address (if different than billing address)
- Return fax number
- Applicable model number
- Quantity, part number and description of each part
- Specify preferred method of shipment:
 - UPS Ground
 - UPS Second Day or Third Day*
 - UPS Next Day*
 - Federal Express Priority One (please provide us with your Federal Express account number)*
 - Airborne Express*
 - Truck or parcel post

**Normally shipped the same day the order is received, if prior to 2PM west coast time.*

Earn Extra Discounts when you order by FAX!

All parts orders which include complete part numbers and are received by fax qualify for the following extra discounts:

<u>Number of line items ordered</u>	<u>Additional Discount</u>
1-9 items	3%
10+ items**	5%

Get special freight allowances when you order 10 or more line items via FAX!**

- UPS Ground Service at no charge for freight
- PS Third Day Service at one-half of actual freight cost

No other allowances on freight shipped by any other carrier.

**Common nuts, bolts and washers (all items under \$1.00 list price) do not count towards the 10+ line items.

DISCOUNTS ARE SUBJECT TO CHANGE

Fax order discount and UPS special programs revised June 1, 1995

**Extra Fax Discount
for Domestic USA
Dealers Only**

**Up to 5%
extra savings!**

**UPS
Special**
For faxed orders only

**Now! Direct TOLL-FREE access
to our Parts Department!**

Toll-free nationwide:

800-421-1244

Toll-free FAX:

800/6-PARTS-7 • 800-672-7877

EXPLANATION OF CODE IN REMARK COLUMN

How to read the marks and remarks used in this parts book.

Section 1: Items Found In the “Remarks” Column

Serial Numbers-Where indicated, this indicates a serial number range (inclusive) where a particular part is used.

Model Number-Where indicated, this shows that the corresponding part is utilized only with this specific model number or model number variant.

Section 2: Items Found In the “Items Number” Column

All parts with same symbol in the number column:

*, #, +, %, or ■, belong to the same assembly or kit.

Note: If more than one of the same reference number is listed, the last one listed indicates newest (or latest) part available.

NOTE: The contents of this parts catalog are subject to change without notice.


SAFETY INSTRUCTIONS

The Bullfloat models HAL 150/300 have been developed and tested in accordance with strict International Safety Standards. This section contains general advice.

Regular maintenance of the Bullfloat **promotes** safe operation.

- When in doubt and/or when you are operating the Bullfloat for the first time, always read the necessary instructions in this manual.
- Wear safety shoes with extra protection (steel caps and anti-slip soles).
- Place the wires between the electrical source and the work area in such a way that they can not be damaged or your co-workers cannot trip over them.
- Do not leave any tools or parts laying around on the work floor, as this can cause accidents.
- Watch where you are going; the ground can be slippery.
- Take care that you do not injure yourself on objects, such as scaffolding and reinforcement materials, which can be found directly or indirectly in the working area.
- Pay attention to your own safety and that of your fellow workers.
- Be careful when lifting and carrying the Bullfloat. Do not bend forwards when picking up the apparatus, but bend your knees. Ensure that the working area is within your reach, so that you do not have to bend forward.
- Ensure that you are qualified (familiar with the contents of this manual) to operate and carry out light maintenance work to the Bullfloat.
- Check that the electrical source complies with the local regulations.
- Use grounded extension cords, when it is necessary to use extension cords.
- Use an electrical source which is provided with a ground leakage switch between the electrical mains and the Bullfloat.
- Ensure that the wall socket and possible connections between the extension cords are protected against dampness.
- Do not pull the plug out of the wall socket or extension cords by it's cord, use the plug.

The following safety-aspects specifically apply to those Whiteman products which are equipped with a gas-engine.



■ Do not use the Bullfloat with a gas-engine indoors or in poorly ventilated places, such as pits etc.

■ Make sure that there is sufficient ventilation in spaces which are surrounded by walls. Never inhale exhaust gases, they can damage your health and that of your fellow workers.

- Wear working-gloves, safety glasses and protective clothing during refueling.
- Make sure that there is sufficient ventilation during refueling.
- Refuel only after the engine has cooled off sufficiently.



Refueling of fuel, while the engine is hot, might lead to a very dangerous situation including an explosion and fire.

■ **It is strictly forbidden to refuel:**

- in the direct vicinity of a open fire or other flammable materials,
- in explosion endangered places.



■ To avoid getting an electric shock, do not touch the high-tension cable or spark plug cap while the engine is running.

General Safety Instructions

- When operating the Bullfloat wear ear protection, safety glasses, a safety helmet, gloves which do not conduct electricity and protective clothing.
- Ensure that all symbols on the Bullfloat — can always be clearly read.
- Regularly check the Bullfloat's connections.
- When cleaning the Bullfloat, ensure that no water or cleaning detergents, under high pressure, get into the motor housing or plug connections.
- When the Bullfloat is not being used for long periods of time, then it must be store in a dry and clean area.

SAFETY INSTRUCTIONS

Important Safety Checks for the electrical Bullfloat

- Check the feeder cable and extension cords outer casing before you connect the Bullfloat to the electrical mains.



- Check the feeder cable's attachment on the bullfloat, before you connect the Bullfloat to the electrical mains. The cable must be correctly attached to the Bullfloat.

- Ensure that the feeder cable does not graze past any sharp objects.

- The use of extension cords are permitted, if they are completely watertight.




- Switch the Bullfloat "off" when the electrical power cuts off. This prevents the Bullfloat from starting suddenly when the electrical power comes on again.

- Check the feeder cable and extension cord's attachments regularly. When the Bullfloat is in operation, the plugs can loosen due to the vibrations.

- Disconnect the electrical supply to the Bullfloat, before you start to clean or service the Bullfloat.

- Connect the Bullfloat to an alternating voltage source of 115VAC, which is provided with a ground switch, with a frequency of 60 Hz.
- Check that the ventilation openings in the motor housing are free from dirt and moisture.
- Regularly check the connections of the feeder cable to the switch.

Explanation of the utilized safety symbols.




1. Safety glasses, safety helmet and ear protection compulsory.
2. Gloves compulsory.
3. Safety shoes with extra protection compulsory.
4. Dangerous electrical voltage.
5. Before opening the motor housing remove the plug.
6. Inflammable material.
7. Pls. read the operation-instructions
8. Careful, danger!





Tip: Ask the manufacturer for clarification, if you have any questions about any of these safety instructions.

SPECIFICATIONS

	HAL (115VAC)	HAL (2 stroke gas-engine)
Voltage	115VAC 1 Phase/60Hz	—
Capacity	350 W	520 W
Revolutions	12000 r/min	12000 r/min
Centrifugal force Mass	1800 N (405 lbs.)	1800 N (405 lbs.)
	1 m (11Kg) (24.3 lbs.)	1 m (11Kg) (24.3 lbs.)
	1, 5 m (13Kg) (28.6 lbs.)	1, 5 m (13Kg) (28.6 lbs.)
	2 m (15Kg) (33.1 lbs.)	2 m (15Kg) (33.1 lbs.)
	2, 5 m (17Kg) (37.5 lbs.)	2, 5 m (17Kg) (37.5 lbs.)
	3 m (19Kg) (41.9 lbs.)	3 m (19Kg) (41.9 lbs.)
Fuel	—	2-stroke (mixture)
Mixture	—	1 : 25
Sealing	IP 54, splash proof	IP 54, splash proof
Insulation	Class II Double Insulated	—
Motor protection	Impact and shock proof	—
Design	Portable	Portable
Dimensions drive-unit		
Length	180 mm (7.1 in.)	150 mm (5.9 in.)
Width	150 mm (5.9 in.)	200 mm (7.9 in.)
Height	140 mm (5.5 in.)	220 mm (8.7 in.)



HAL 150 AND 300 — WHAT IS A BULLFLOAT



- | | |
|-----------------------|------------------|
| 1. Aluminium profile | 7. Grip |
| 2. Operating handle | 8. ON/OFF-switch |
| 3. Pitch control | 9. Gas throttle |
| 4. Drive-unit 115 VAC | 10. Plug |
| 5. Vibratory Unit | 11. Cable |
| 6. Gas engine | |

What is a Bullfloat?

A Bullfloat is an apparatus with a vibrating alloy blade that smooths and compacts the top layer of freshly poured concrete, without the need for guiding rails.

Before the Bullfloat is brought into action, the concrete should be distributed and compacted by means of a vibrator.

The vibrator is used in combination with a laser, in order to adjust and control the height of the concrete floor.

The Bullfloat consists of an operating handle, an electrical or gas-engine vibrating-unit and an aluminium blade, available in 5 lengths: 1m, 1.5m, 2m, 2.5m, and 3m.

The switch is located on the operating handle with which the electrical vibrating-unit is switched 'ON' and 'OFF'. The gas-engine vibrating-unit is operated by means of a gas throttle also located on the operating handle.

Operation

The drive-unit of the Bullfloat is started by turning the knob of the electric-speed-regulator to the 'ON' position (electrical), or by pulling the recoil-starter of the gas-engine.

An excentric part is set in motion by the drive-shaft of the motor. This rotating motion sets the aluminium blade in vibration. The vibrating motion of the blade smooths and compacts the surface of the concrete.

HAL 150 AND 300 — OPERATION


This section describes the operation of the HAL 150 & 300 Bullfloats.

Tip: For the location and description of the Bullfloat's parts, which are mentioned in the text, refer to the illustration figure (page. 9): What is a Bullfloat.


How to assemble the HAL 150 & 300 Bullfloats.

When delivered the Bullfloat is not ready for use. You only have to carry out the following procedures to assemble them:

1. Connect the switch (an electronic speed regulator, or a gas throttle), to the operating handle by means of the bracket and the butterfly nut. Now lock the bracket by tightening the butterfly nut. (Fig. No. 2.0)
2. Stick the operating handle into the shaft of the motor unit frame. Make sure that the operating handle is locked properly.



How to adjust the trowel blade angle.



Use position (I), when smoothing freshly poured concrete. (Fig. No. 2.1)

Use position (II), in the event you want to smooth the same lane once again. (Fig. No. 2.1)

Operation and use of the Bullfloat


This section describes how to operate and use the Bullfloat. In the text are numbers in brackets. These numbers are position numbers and they correspond to the numbers in the parts list of the corresponding figures.

Careful: Read the safety instructions before you switch on the apparatus.

Careful: Prevent the Bullfloat, from sinking into the concrete. After the motor has been switched on, immediately move the Bullfloat backwards.

Tip: Before the Bullfloat is brought into action, first compact the freshly poured concrete floor with a poker-vibrator while at the same time adjust the height of the floor by means of a laser device.


Tip: Pour concrete lanes of approx. 3 ft. wide and approx. 15 ft. long. You can finish this surface in one pass without any problem.



Tip: When using a low slump concrete, move the Bullfloat slowly across the surface of the concrete. When using a high slump concrete, move the Bullfloat faster across the surface of the concrete.

Operation of the Electric Bullfloat


1. Check that the Bullfloat is properly assembled and that the switch is in the 'OFF' position.
2. Put the plug of the drive-unit's feeder cable in the wall socket.
3. Place the Bullfloat in the direct vicinity of where you are going to smooth the surface of the concrete-floor.
4. Place the Bullfloat on the surface of the freshly poured concrete, and turn the speed regulator slowly to the required revolutions.
5. Adjust the trowel blade angle. (read paragraph 2, on page 11)
6. Now start to smooth the surface of the concrete floor by moving the Bullfloat backwards in a slow but steady motion.
7. After having finished one lane of concrete, switch off the Bullfloat immediately, by turning the speed regulator's knob to the position 'Minimal'. You will hear a "CLICK". (Fig. 2.2, on page 11)



Tip: If the processed concrete-surface is not smooth or level enough, repeat the procedures 5,6,7 and 8.

8. Pull the plug of the feeder cable out of the wall socket.
9. After use, place the Bullfloat on a dry and stable surface.

Operation of the Gas Bullfloat



- a. Throttle cable
- b. Spark plug
- c. Overflow pipe
- d. Starter rope
- e. Fuel cap and fuel filter
- f. Fuel tank
- g. Air filter
- h. Carburetor

Starting Procedure

1. Check that the Bullfloat is properly assembled, and the fuel tank is filled.
2. Place the Bullfloat in the direct vicinity of where you are going to smooth the surface of the concrete.
3. Adjust the throttle-lever (1) to the idle-position.(Fig 2.5)




Figure 2.5
Idle position of the throttle-handle and components of the carburetor

4. Put the choke-lever (2) in the upper position.(Fig 2.5)
5. Push simultaneously the black priming pump (3) and the tickler lever (4) (Fig 2.5) until fuel comes out of the overflow pipe (c). (Fig 2.4)

Careful! : When pushing the tickler lever (4) half way down, the fuel will flow directly into the engine and will create starting problems. **Be sure to push the tickler lever fully down.**

Careful! : Never change the adjustment of the main jet screw on the carburetor (5).(Fig 2.5)

6. Open the throttle-handle half way.
7. Give the starter rope (6) (Fig 2.6) a rapid vigorous pull until the engine fires.

WARNING: Do not pull the starter rope all the way. The rope might break. Use 3/4 of the starter rope's length.

8. If you have executed the starting procedure in the correct way, the engine will run after approx. 2 pulls of the starter rope.
9. Allow the engine to run for approx. 10 seconds. Push the choke lever (2) (Fig 2.5) slowly down. The period of time depends on the ambient temperature.

10. After allowing a three-minute warming-up period set the throttle handle to the desired engine speed. The Bullfloat is now ready for use.

Smoothing concrete

11. Adjust the right trowel blade angle. (read paragraph 2, page 11)
12. Smooth the freshly poured concrete.

Tip: Repeat procedure 12 in the event the treated surface is not smooth or level enough.

13. Switch "off" the Bullfloat after you have finished the concrete lane:

— Put the throttle lever (1) in the idle position. (Fig 2.5)




Figure 2.6
Location of the starter rope and the stop button

— Press the black stop-button (7) for a couple of seconds until the engine stops. (Fig 2.6)

14. If you do not expect to use the engine for a long period of time, drain the fuel tank of fuel and let the engine run at idle speed until the fuel in the carburetor is used and the engine stops.
15. After use, place the Bullfloat on a dry and clean surface.

WARNING! Make sure to refill the fuel tank before you run out of fuel during operation. Do not let the engine run until all the fuel is used. This might cause starting problems. The average operation time is approx. 45 min. (per tank).

HAL 150 AND 300 — TROUBLE SHOOTING

Problem: The Bullfloat does not vibrate in the ON position.

Cause: Fault in the electrical connections of the feeder cable.

Solution: Check the electrical connections to the Bullfloat, switch, plug and feeder cable for breakage.

Replace the faulty part(s).

Problem: The Bullfloat does not get into the required number of revolutions.

Cause: Voltage drop, due to the feeder cable being too long.

Solution: Move the electrical source closer to the working area. Be certain you have the correct wire gauge size for the distance and amp draw.

Problem: The electrical motor rotates irregularly and makes a lot of noise.

Cause:

1. The bearings are worn out, and/or
2. an electrical defect in the stator, and/or
3. a break in the feeder cable.

Solution:

1. Replace the bearings, and/or
2. replace the stator, and/or
3. repair or replace the feeder cable.

Problem: The connected and running Bullfloat rotates irregularly and does not get into the required revolutions.

Cause: Insufficient current supply.

Solution:

Electrical supply via electrical mains; check the plug connections for defects.

Problem: The electrical motor runs irregularly.

Cause: The carbon brushes are worn out.

Solution: Replace the carbon brushes. (Replace every 6-12 months).

Problem: Gas engine does not start.

Cause: There is no, or too little, fuel in the fuel tank. The starting procedure was not carried out in the correct way.

Solution: Fill the fuel tank or repeat the starting procedure.

Problem: The engine starts but runs irregularly.

Cause: The spark plug, the fuel filter or the air filter are dirty.

Solution: Clean or replace the spark plug, the fuel filter or the air filter. See paragraph 4-4 on the next page.

Problem: The engine runs in idle position but stops when increasing the revolutions.

Cause: The choke lever has not been pushed down completely, after the starting procedure.

Solution: Repeat the starting procedure. (Do not prime again). See Section 3, 4 & 5 on page 13.

Problem: Engine smokes excessively.

Cause:

1. Choke lever has not been pushed down all the way.
2. The carburetor is worn out.
3. The engine is worn out.
4. Wrong mixture. (Possibly too much oil)

Solution:

1. Check the position of the choke lever.
2. Replace the worn out parts of the carburetor, (please consult your dealer or the manufacturer).
3. Replace the gas engine.
4. Replace the mixture for the right mixture with the correct proportion: 1 part 2-stroke oil to 25 parts of normal gasoline (1: 25).

Maintenance

Although the Bullfloat has few moving parts, regular maintenance promotes a long and trouble-free life.

Warning: Never use a high pressure cleaner to clean a Bullfloat with an electrical or gas drive unit.

Lubricating the blade pitch control

Lubricate the blade pitch control, after long periods of storage, or at least twice a year, by using a hand grease gun. (Fig. 4.0)




Figure 4.0
Lubricating the blade pitch control

4.3 Cleaning and servicing of the electrical drive unit.

Warning: Cut off the electrical supply to the Bullfloat before carrying out any maintenance activities to the Bullfloat.

In order to achieve a maximum cooling effect the ventilation slots of the electrical drive unit must stay free from dirt and grease. Check them at the end of each working day.

If necessary, clean the motor with a brush or a damp cloth.

4.4 Cleaning and servicing of the gas engine. (refer also to engine manual)

Daily maintenance

— In order to achieve a maximum cooling effect the ventilation openings must stay free from dirt or grease. Check them at the end of each working day. If necessary, clean them with a brush or a damp cloth.

— For a proper functioning of the carburetor's control mechanism, it is necessary to check the carburetor for concrete or dirt, each time after use. If necessary clean the control mechanism with a brush or a damp cloth.

Maintenance after 20 hours of operation

— How to clean the fuel filter.

(Removal Procedure)

1. Remove the fuel tank cap.
2. Pull out the black rubber tube from the fuel tank. At the end of the tube is the felt-weight assembly. Remove the felt and the felt-weight from the tube and wash out both parts in clean fuel.
3. Insert the felt and the felt-weight into the fuel tank again.

How to clean the air filter.

1. Unscrew the black filter cap from the carburator.
2. Take out the filter element.
3. Wash out the filter element in clean fuel and wring out the filter element.
4. Re-install the filter and the black filter cap.




Figure 4.1
Location of the fuel and air filters


WARNING!: When the engine operates in dusty conditions, clean the air filter each day or after each 10 hours of operation.

Maintenance after 50 hours of operation

- Cleaning of the piston.
Remove the carbon from the upper side of the piston, from the exhaust-ports in the cylinder, from the combustion chamber and from the exhaust.
- Cleaning of the spark plug.
Clean off carbon deposits on the spark plug electrode using a plug cleaner or wire brush.
Check electrode gap. If necessary adjust it to between: 0.6 to 0.7 mm.

Longtime storage

1. Remove the spark plug and pour 3 to 5 cc of new engine oil into the plug-hole.
Pull the recoil starter several times and reinstall the spark plug.
2. Slowly pull the recoil starter until resistance is felt. The piston is in its compression stroke.
3. Clean the engine thoroughly with an oiled cloth.
4. Store the engine in a clean and dry place.




HAL 150 AND 300 FRAME

HAL 150 & 300 type E, ER and B frame

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	BF230010	BLADE, ALUM. 1.0 m — 3 ft.	1	
	BF230015	BLADE, ALUM. 1.5 m — 5 ft.	1	
	BF230020	BLADE, ALUM. 2.0 m — 6½ ft.	1	
	BF230025	BLADE, ALUM. 2.5 m — 8 ft.	1	
	BF230030	BLADE, ALUM. 3.0 m — 10 ft.	1	
3	BF23003	MOTOR ASSEMBLY BRACKET	1	
4	BF0060	RUBBER BUFFER	3	
5	BF0124	BOLT M8 X 10	5	
6	BF0173	UNDULATED RING	2	
7	BF0093	NUT M10	3	
8	BF0115	BOLT M8 X 150	2	
9	BF0107	NUT M8	2	
10	BF0172	RETAINING RING	2	
11	BF0156	WASHER M 10	4	
31	BF230031	ASSEMBLY BRACKET	1	
34	BF0140	BOLT	1	
35	BF0212	RETAINING RING	1	
36	BF23036	GRIP	1	
37	BF23037	SPACER	1	
49	BF2348	OPERATING HANDLE 150 CM	3	
50	BF2350	PITCH CONTROL	1	
51	BF23051	RUBBER SLEEVE	1	
53	BF23053	ADJUSTABLE STRIP	1	
54	BF0131	BOLT M10 X 25	2	
56	BF23056	SPACER 4,2 mm	2	
58	BF0203	LOCK-RING	2	
59	BF23059	LUBRICATING NIPPLE & CAP	1	
60	BF0133	BOLT M10 X 50	1	
61	BF23061	SPACER 32 mm	1	
63	BF23063	BRASS NUT M8	1	
64	BF0125	BOLT M8	1	
66	BF23066	PLASTIC CLAMP	1	
68	BF23068	LOCKING CLIP	1	

HAL 150 AND 300 ELECTRIC DRIVE-UNIT AND SWITCH




HAL 150 AND 300 ELECTRIC DRIVE-UNIT AND SWITCH

HAL 150 & 300 type-E,ER drive-unit and switch

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
1	BF2301 N	EXCENTER-HOUSING	1	
2	BF2302N	EXCENTER-SHAFT	1	
6	BF2306B	RUBBERSEAL	1	
7	BF2307	ADAPTOR - BOLT (SHORT)	2	
8	BF2308	ADAPTOR - BOLT (LARGE)	1	
10	BF0155	WASHER	3	
11	BF2311N	COVER&BEARING, EXCENTER	1	
12	BF231213	EXCENTER 1.0 - 1.5 m.	1	
	BF231217	EXCENTER 2.0 - 2.5 m.	1	
13	BF0201	LOCKRING	1	
14	BF2314	EXCENTER-BEARING	1	
16	BF2316	O-RING	1	
20	BF2320	DRIVE-UNIT	1	
21	BF0051	RUBBERBUFFER	3	
22	BF2325	COUPLING- SET	1	INCLS. ALL ITEMS W/*
22A*	BF2323	CATCH, DRIVESHAFT	1	
22B*	BF0273	SCREW	1	
22C*	BF0154	WASHER	1	
22D*	BF2322	SPRING	1	
23	BF0172	RETAINING RING M8	3	
24	BF0088	CAPNUT	2	
29	BF0017	CABLE 2 X1,5 mm2 + PLUG 220V	10	
33	BF0086	CAPNUT (HIGH)	1	
35	BF2335	CABLE-CLAMP	1	
44	BF0004	CABLE	1	
69	BF2369ER	SWITCH ASSEMBLY BRACKET (ER)	1	
73	BF0325	WING-SCREW	1	
74	BF23074	SWITCH COMPLETE	1	
78	BF0122	SCREW	1	
90	BF0420	PACKING BOX	2	
91	BF0421	NUT	2	
92	BF2392	SPEED-REGULATOR (ONLY)	1	
93	BF2393	SWFTCH-BOX (SPEED-REGULATOR)	1	
94	BF2394	POTENTIOMETER & SWITCH	1	
95A	BF2395A	KNOB (POTENTIOMETER)	1	
95B	BF2395B	KNOB-CAP	1	
95C	BF2395C	FIGURE DIAL	1	
95D	BF2395D	STATOR	1	
97	BF2397	TERMINAL-BLOC	1	
98	BF2398	SPEED-REGULATOR COMPL. (INCL. BRACKET)	1	
99	BF2399	SPEED-REGULATOR COMPL. (EXCL. BRACKET)	1	

HAL 150 AND 300 ELETRIC DRIVE-UNIT COMPONENTS




HAL 150 AND 300 ELETRIC DRIVE-UNIT COMPONENTS

HAL 150 & 300 type- E, ER drive-unit

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
3A	BF2303A	VENTILATION RING (SMALL)	1	
3B	BF2303B	VENTILATION RING (LARGE)	1	
3C	BF2303C	VENTILATION HOUSING	1	
40	BF0428	RUBBERING	1	
41	BF0421	PLASTIC NUT	1	
42	BF0430	PACKING BOX	1	
43	BF1101220240	REAR-BEARING	1	
45S	BF2345S	STATOR	1	
45R	BF2345R	ROTOR	1	
46	BF2346	FRONT SHIELD	1	
47	BF0249	SELF TAPPING SCREW	5	
52	BF1101220170	VENTILATOR-COVER	1	
53	BF1101220200	SCREW	2	
54	BF1101220250	SPRING SOURCER	2	
55	BF1101220220	BRUSH-COVER	2	
56	BF1101220180	MOTOR-HOUSING	1	
57	BF2357	CAPACITOR	1	
58	BF2358	CAPACITOR-CLAMP	1	
59	BF0248	SELF TAPPING SCREW	3	
60	BF2360	TERMINAL-BLOC	1	
61	BF1101220230'	SET OF BRUSHES	1	
62	BF0230	SELF TAPPING SCREW	3	
63	BF0231	SELF TAPPING SCREW	3	
64	BF0154	WASHER	3	
65	BF0417	PRESSING RING	2	
66	BF0415	CABLE-SLEEVE	1	
67	BF0416	CABLE-PACKING-BOX	1	

HAL 150 AND 300 GAS DRIVE-UNIT AND GAS THROTTLE



HAL 150 AND 300 GAS DRIVE-UNIT AND GAS THROTTLE


HAL 150 & 300 type- B drive-unit and gasthrottle

NO.	PART NO.	PART NAME	QTY.	REMARKS
1	BF2301 N	EXCENTER-HOUSING	1	
2	BF2302N	EXCENTER-SHAFT	1	
6	BF2306 B	SEAL, RUBBER	1	
7	BF2307	ADAPTOR-BOLT (SHORT)	2	
8	BF2308	ADAPTOR-BOLT (LARGE)	1	
10	BF0155	WASHER	3	
11	BF2311N	COVER&BEARING (EXCENTER HS.)	1	
12	BF231213	EXCENTER 1.0 - 1.5 m.	1	
	BF231217	EXCENTER 2.0 - 2.5 m.	1	
13	BF0201	LOCK RING	1	
14	BF2314	EXCENTER-BEARING	1	
16	BF2316	O-RING	1	
18	BF2318N	ENGINE BRACKET	1	
20	BF2302666020	GAS ENGINE, KAWASKI	1	
20A	BF2320A	ENGINE ADAPTOR	1	
21	BF0055	RUBBER BUFFER	3	
22	BF2325	COUPLING - SET	1	INCLS. ALL ITEMS W/*
22A*	BF2323	CATCH, DRIVESHAFT	1	
22B*	BF0273	SCREW	1	
22C*	BF0154	WASHER	1	
22D*	BF2322	SPRING	1	
23	BF0172	RETAINING RING M8	3	
24	BF0088	CAPNUT	2	
28	BF2328	SPACER	3	
33	BF0086	CAPNUT (HIGH)	1	
69	BF2369B	LEVER, GAS & BRACKET	1	
70	BF2302666700	LEVER, GAS (ONLY)	1	
71	BF2371	THROTTLE-CABLE (OUTER)	1	
72	BF2372	THROTTLE-CABLE (INNER)	1	
73	BF0325	WING-SCREW	1	
75	BF2375	ASSEMBLY-BRACKET	1	
76	BF2376	THROTTLE-CABLE STOPPER	1	
78	BF0122	SCREW	1	
79	BF0123	NUT	4	
83	BF2383	SPRING	1	
84	BF2384	DRIVE-SHAFT ASSY	1	
	BF23510	UNIT ASSY (ENGINE & COMPONENTS), KAWASAKI	1	
	KWAAIR	ELEMENT, AIR FILTER KAWASAKI ENGINE	1	
	0650140460	SPARK PLUG, KAWASAKI ENGINE	1	

NOTE:

For the balance of the Kawaski Engine Parts, call your local Kawaski Engine distributor referring to engine model TGO 18D-CA 51
For the Robin Engine spare parts, refer to the engine section of this book.


ROBIN EC0250G6004 — CRANKCASE & CYLINDER



ROBIN EC0250G6004 — CRANKCASE & CYLINDER

CRANKCASE & CYLINER

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
10	525100300	CRANKCASE ASSY	1	INCLS. ITEMS W/*
15	5231502202	GASKET	1	
30*	0440129970	OIL SEAL	2	
40*	0600129920	BALL BEARING	2	
95	0140059520	SCREW	3	
170	5231502304	GASKET	1	
510	5251500200	CYLINDER	1	
630	0119059730	SOCKET HEAD BOLT	2	




ROBIN EC0250G6004 — CRANKSHAFT & PISTON

CRANKCASE & PISTON

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
10	5252001001	CRANKSHAFT	1	
55	0011306160	BOLT & WASHER ASSY	1	
65	0031206000	WASHER	1	
350	5232502600	PISTON PIN	1	
360	5232501902	PISTON	1	
370	5242500701	PISTON RING	1	
380	0565089970	CLIP	2	
390	0610089990	NEEDLE BEARINGS	1	

ROBIN EC0250G6004 — MUFFLER, AIR CLEANER




ROBIN EC0250G6004 — MUFFLER, AIR CLEANER

MUFFLER, AIR CLEANER

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
310	5253015000	MUFFLER	1	
320	5253500000	MUFFLER COVER	1	
340	5233504302	GASKET	1	
345	5253500101	GASKET	1	
360	0119059660	SOCKET HEAD BOLT	2	
370	0043705160	SCREW ASSY	1	
510	5203004030	AIR CLEANER ASSY	1	INCLS. ITEMS W/*
515*	5253004010	CLEANER BODY ASSY	1	
520*	5203004010	ELEMENT, AIR CLEANER	1	
540	5233014000	INSULATOR CAP	1	
550	5253500200	GASKET	1	
560	5103502800	GASKET	1	
562	5256501200	GASKET	1	
563	5256501100	O'RING	1	
580	0043305650	SCREW ASSY	2	
581	0140059500	SCREW ASSY	2	

ROBIN EC0250G6004 — RECOIL STARTER & HOUSING





ROBIN EC0250G6004 — RECOIL STARTER & HOUSING

RECOIL STARTER & HOUSING

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
10	5255500001	BLOWER HOUSING	1	
13	5215500300	BUFFLE PLATE	1	
20	5259500000	DECAL	1	
40	0043505160	SCREW AND WASHER ASSY	3	
50	5255500401	CYLINDER COVER	1	
51	0140059490	SCREW	1	
52	0200070010	WASHER	1	
55	5503503001	SPACER	1	
210	5255001000	RECOIL STARTER ASSY	1	INCLS. ITEMS W/*
213*	5225004020	STARTER KNOB	1	
214*	5025001020	SPIRAL SPRING	1	
215*	5235024022	STARTER ROPE	1	
216*	5025001010	REEL	1	
217*	5255001020	SET SCREW	1	
218*	5215002040	FRICTION PLATE	1	
219*	5105015050	FRICTION SPRING	1	
220*	5105015020	RATCHET	1	
221*	5105015060	RETURN SPRING	1	
222*	5255001040	DAMPER	1	
230	0140059480	SCREW	1	

ROBIN EC0250G6004 — CARBURETOR & FUEL TANK




ROBIN EC0250G6004 — CARBURETOR & FUEL TANK

FUEL TANK, CARBURETOR

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
10	5256500502	FUEL TANK	1	
20	5259503500	LABEL, MODEL	1	
30	5216004003	CAP	1	
35	0043705160	SCREW ASSY	4	
40	5236503900	FILTER	1	
65	5256012001	TUBE ASSY	1	
140	5256002000	PLATE	1	
145	0230059970	SPACER	2	
147	0230059950	SPACER	1	
210	5256007000	CARBURETOR ASSY	1	INCLS. ITEMS W/*
227*	5236046050	SPACER	1	
232*	5246001030	COVER	1	
233*	5246001040	DIAPHRAGM	1	
234*	5316005250	DIAPHRAGM ASSY	1	
235*	5236046040	GASKET	1	
236*	5246001150	PUMP	1	
237*	5236046010	SCREW	4	
246*	5256007010	BODY ASSY	1	
247*	5016004010	SCREEN	1	
253*	5236046060	BODY ASSY	1	
254*	5316005120	RING	1	
255*	5236018040	SWIVEL	1	
256*	5206008030	SCREW	2	
350*	5256500100	CABLE BRACKET	1	
355*	5216008010	ADJUSTER SCREW	1	
357*	5316005150	NUT	1	
360*	5219500000	HOLDER	1	

ROBIN EC0250G6004 — COIL & SPARK PLUG



ROBIN EC0250G6004 — COIL & SPARK PLUG

COIL & SPARK PLUG

<u>NO.</u>	<u>PART NO.</u>	<u>PART NAME</u>	<u>QTY.</u>	<u>REMARKS</u>
10	5257001010	FLYWHEEL	1	
11	5257001020	IGNITION COIL	1	
35	0140049920	SCREW	2	
60	0660000371	SWITCH ASSY	1	
70	0043304100	SCREW & WASHER ASSY	2	
81	5257500300	GROMMET	1	
95	0654009931	SPRING, PLUG CAP	1	
100	0650149721	SPARK PLUG	1	
110	5237503301	SPARK PLUG CAP	1	

PAYMENT TERMS

Terms of payment for parts are net 10 days.

FREIGHT POLICY

All parts orders will be shipped collect or prepaid with the charges added to the invoice. All shipments are F.O.B. point of origin. Multiquip's responsibility ceases when a signed manifest has been obtained from the carrier, and any claim for shortage or damage must be settled between the consignee and the carrier.

MINIMUM ORDER

The minimum charge for orders from Multiquip is \$15.00 net. Customers will be asked for instructions regarding handling of orders not meeting this requirement.

RETURNED GOODS POLICY

Return shipments will be accepted and credit will be allowed, subject to the following provisions:

1. A Returned Material Authorization must be approved by Multiquip prior to shipment.
2. To obtain a Return Material Authorization, a list must be provided to Multiquip Parts Sales that defines item numbers, quantities, and descriptions of the items to be returned.
 - a. The parts numbers and descriptions must match the current parts price list.
 - b. The list must be typed or computer generated.
 - c. The list must state the reason(s) for the return.
 - d. The list must reference the sales order(s) or invoice(s) under which the items were originally purchased.
 - e. The list must include the name and phone number of the person requesting the RMA.
3. A copy of the Return Material Authorization must accompany the return shipment.
4. Freight is at the sender's expense. All parts must be returned freight prepaid to Multiquip's designated receiving point.
5. Parts must be in new and resalable condition, in the original Multiquip package (if any), and with Multiquip part numbers clearly marked.
6. The following items are not returnable:
 - a. Obsolete parts. (If an item is listed in the parts price book as being replaced by another item, it is obsolete.)
 - b. Any parts with a limited shelf life (such as gaskets, seals, "O" rings, and other rubber parts) that were purchased more than six months prior to the return date.
 - c. Any line item with an extended dealer net price of less than \$5.00.
 - d. Special order items.
 - e. Electrical components.
 - f. Paint, chemicals, and lubricants.
 - g. Decals and paper products.
 - h. Items purchased in kits.
7. The sender will be notified of any material received that is not acceptable.
8. Such material will be held for 5 working days from notification, pending instructions. If a reply is not received within 5 days, the material will be returned to the sender at his expense.
9. Credit on returned parts will be issued at dealer net price at time of the original purchase, less a 15% restocking charge.
10. In cases where an item is accepted for which the original purchase document can not be determined, the price will be based on the list price that was effective twelve months prior to the RMA date.
11. Credit issued will be applied to future purchases only.

PRICING AND REBATES

Prices are subject to change without prior notice. Price changes are effective on a specific date and all orders received on or after that date will be billed at the revised price. Rebates for price declines and added charges for price increases will not be made for stock on hand at the time of any price change.

Multiquip reserves the right to quote and sell direct to Government agencies, and to Original Equipment Manufacturer accounts who use our products as integral parts of their own products.

SPECIAL EXPEDITING SERVICE

A \$20.00 to \$50.00 surcharge will be added to the invoice for special handling including bus shipments, insured parcel post or in cases where Multiquip must personally deliver the parts to the carrier.

LIMITATIONS OF SELLER'S LIABILITY

Multiquip shall not be liable here under for damages in excess of the purchase price of the item with respect to which damages are claimed, and in no event shall Multiquip be liable for loss of profit or good will or for any other special, consequential or incidental damages.

LIMITATION OF WARRANTIES

No warranties, express or implied, are made in connection with the sale of parts or trade accessories nor as to any engine not manufactured by Multiquip. Such warranties made in connection with the sale of new, complete units are made exclusively by a statement of warranty packaged with such units, and Multiquip neither assumes nor authorizes any person to assume for it any other obligation or liability whatever in connection with the sale of its products. A part from such written statement of warranty, there are no warranties, express, implied or statutory, which extend beyond the description of the products on the face hereof.

[illegible]

PARTS AND OPERATION MANUAL

HERE'S HOW TO GET HELP

*PLEASE HAVE THE MODEL AND SERIAL NUMBER
ON-HAND WHEN CALLING*

PARTS DEPARTMENT

800-427-1244 or 310-537-3700

FAX: 800-672-7877 or 310-637-3284

SERVICE DEPARTMENT/TECHNICAL ASSISTANCE

800-478-1244 or 310-537-3700

FAX: 310- 537-4259

WARRANTY DEPARTMENT

888-661-4279, or 310-661-4279

FAX: 310- 537-1173

MAIN

800-421-1244 or 310-537-3700

FAX: 310-537-3927



MULTIQUIP INC.

POST OFFICE BOX 6254
CARSON, CA 90749
310-537-3700 • 800-421-1244
FAX: 310-537-3927
E-MAIL: mq@multiquip.com
WWW: multiquip.com

Atlanta • Boise • Dallas • Houston • Newark
Quebec, Canada • Manchester, UK • Rio De Janeiro, BR • Guadalajara, MX