



Atlas Copco

**ZBP 15-60 / ZBP 45-60 / ZBP 45-75
50 HZ**



Core Parts

Description	Order Nr
BATTERY	1636 0430 50
CABLE RJ45 UTP (1,8M)	1640 0552 60
CONTROLLER	1636 0334 08
ECO CONTROLLER	1636 0382 57



Inverter & Parts

Description	Order Nr
INVERTER	1636 0241 97
CONNECTION PCBA	1636 3300 85
CONTROL PCBA	1636 3300 92
POWER PACK	1636 3300 86
FAN	1636 3300 87



Cooling System

Description	Order Nr
FAN	1636 0450 14



Smartbox

Description	Order Nr
MODULE	1636 0404 73
ANTENNA	1638 9115 00



Electrical Parts STD

Description	Order Nr
RELAY 20A 1NA	1636 0417 16
RELAY 10A 1CO 24V	1636 0418 10
RELAY 5A 24V 2CO	1636 0418 15
RELAY 10A 1CO 230V	1636 0418 09
C. BREAKER 2P 16A	0975 8356 06
C. BREAKER 1P 2A	1633 0134 00
STOP PUSH BUTTON	1636 0001 15
TERMINAL BOARD	1640 0484 31
DC/DC CONVERTER	1636 0382 58
TIMER	1633 0168 22



Keys

Description	Order Nr
DOOR KEYS	1615 7271 00