


ILLUSTRATED PARTS LIST

MODEL NUMBER HD600L

PRODUCT NUMBER 961 43 00-84

MFG. ID. NUMBER 96143008400


HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD600L (96143008400) PRODUCT NO. 961 43 00-84



HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD600L (96143008400) PRODUCT NO. 961 43 00-84

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 42 76-58	Upper Handle Assembly (Includes Foam Grip)	41	532 15 04-06	Screw, Dogpoint 3/8-16 x 1-1/8
2	532 42 09-51	Cable, Engine Zone Control	44	532 44 72-52	Kit, Lawn Mower Housing
3	532 43 00-34	Bracket, Upstop	46	532 42 17-82	Blade Adapter / Pulley
6	532 18 23-98	Handle Knob, Star	47	532 42 18-25	Blade, 22"
7	532 17 88-48	Screw #10-16 x 5/8	48	532 85 10-74	Washer, Hardened
8	532 43 34-30	Control Bar	49	532 85 02-63	Washer, Helical
9	532 43 13-90	Rear Door Assembly	50	532 85 10-84	Screw, Machine, Hex Head
11	532 42 55-75	Hairpin, Door/Handle Pivot	51	532 43 71-31	3/8-24 x 1-3/8 Grade 8
12	532 19 19-38	Handle Knob, Standard	53	532 43 73-45	Front Baffle
13	532 43 75-16	Plug, Lower Handle Bar	56	817 41 13-12	Screw
14	532 43 71-32	Clipping Deflector			Screw, Hex Washer Head
15	532 43 72-73	Handle, Clipping Deflector	57	532 15 53-77	#13 x 3/4
17	532 43 12-38	Rear Baffle	58	532 44 11-97	Nut, Hex
18	532 13 20-04	Keps Locknut 1/4-20	59	532 19 15-74	Lower Handle
19	532 19 47-88	Rope Guide	62	532 42 57-11	Handle Bolt
20	532 44 45-01	Rear Skirt	64	- - -	Belt Retainer
21	532 41 99-49	Spring, Rear Door, LH, Black			Engine, Kohler, Model Number XT149-3311-ED
22	532 14 18-41	Screw, Panhead, Torx #20			(For engine service and replacement parts, call Kohler at 1-800-544-2444)
24	532 41 99-48	Spring, Rear Door, RH, Grey	70	532 18 27-48	Grip, Foam
26	532 41 99-45	Screw, Rear Door/Handle Pivot	83	532 75 00-97	Screw, Hex Washer Head
28	872 25 05-05	Bolt, Carriage 5/16-18 x 5/8	84	532 42 81-24	Fastener, Push
30	532 43 85-84	Grassbag	85	532 43 45-30	Mounting Bracket,
31	532 41 99-51	Frame, Grass Catcher			Rear Skirt
34	532 43 81-34	Bracket, Grassbag	96	532 19 79-91	Clip, Cable
37	817 00 05-10	Screw	97	532 43 48-93	Belt Keeper
39	532 44 25-31	Handle Bracket, LH	99	532 43 73-89	Front Shroud Assembly
40	532 44 05-26	Handle Bracket, RH	- -	532 44 71-59	Operator's Manual, English / French

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.



HUSQVARNA ROTARY LAWN MOWER - MODEL NO. **HD600L** (96143008400) PRODUCT NO. 961 43 00-84

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	532 43 09-72	Drive Control Assembly (Includes Cable)	31	532 40 48-45	Pawl, Drive
9	532 43 16-50	Cable, Drive	32	532 44 28-23	Wheel & Tire Assembly, Rear
10	532 43 27-90	Mounting Bracket, Drive Control	33	532 40 91-48	Nut, Flangelock 3/8-16
11	817 41 13-12	Screw, Hex Washer Head #13 x 3/4	34	532 19 74-80	O-Ring
			35	532 43 05-98	Axle, Rear
12	873 94 08-00	Nut, Hex	36	532 44 22-07	Axle Assembly, Front
13	532 43 45-64	Gearcase Assembly, Complete	37	532 16 34-09	Screw, Hi-Lo Thread, #12 x 5/8
14	532 19 41-28	Pulley, Drive	38	532 19 17-30	Nut, Hex
15	532 08 83-48	Washer, Flat	39	532 40 70-59	Bolt
16	532 43 00-30	Rod, Connecting	40	532 44 28-22	Wheel & Tire Assembly, Front
17	532 75 11-53	Nut, Hex	41	532 40 48-35	Pinion
18	532 43 85-36	Kit, Selector Assembly (Includes Key Numbers 19, 21 and 58)	44	532 42 15-27	Belt, Drive
			47	532 06 77-25	Washer, Flat
19	532 43 39-96	Knob, Wheel Adjuster	48	532 43 84-89	Kit, Water Washout Assembly
20	532 42 70-23	Debris Shield	49	532 43 49-94	Fitting, Water Washout
21	532 43 52-42	Anchor	50	532 41 55-85	Washer, Lock, Internal Tooth
23	532 43 78-70	Wheel Axle Assembly, LH	51	532 41 55-86	Locknut, Hex, with O-Ring
24	532 43 35-11	Bracket, Height Adjustment	55	532 40 65-58	Spring, Tension
25	532 42 60-65	Mounting Bracket, Debris Shield	58	532 43 52-41	Bolt, Shoulder
26	532 42 60-66	Belt Keeper	59	532 44 21-13	Support Bracket
28	812 00 00-58	E-Ring 7/16	61	532 18 16-98	Screw
29	532 18 94-03	Cover, Dust, Wheel	62	532 19 79-91	Clip, Cable
30	817 00 05-10	Screw, Hex Head	63	532 42 81-24	Fastener, Push
			84	532 41 64-05	Adapter, Quick-Connect Coupling
			85	532 43 90-77	Support Bracket, Front Axle

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.