


ILLUSTRATED PARTS LIST

MODEL NUMBER HD800BBC

PRODUCT NUMBER 961 43 00-89


MFG. ID. NUMBER 96143008904



HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800BBC (96143008904) PRODUCT NO. 961 43 00-89

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	585 85 48-06	Upper Handle	48	532 44 17-68	Washer, Hardened
2	583 86 42-01	Cable, Blade Brake/Clutch	50	532 18 04-60	Bolt, Hex Head, Grade 8
6	532 18 23-98	Handle Knob, Star	51	532 43 05-99	Front Baffle
8	585 64 53-12	Control Bar Assembly (Includes Blade Control Lever, Roll Pin and Spring)	53	817 00 05-10	Screw, Hex Head 1/4-20
9	532 43 13-90	Rear Door Assembly	56	817 41 13-12	Screw, Hex Washer Head #13 x 3/4
11	532 42 55-75	Hairpin, Door/Handle Pivot	57	532 15 53-77	Nut, Hex
12	532 19 19-38	Handle Knob, Standard	58	585 90 82-03	Lower Handle
13	532 43 75-16	Plug, Lower Handle Bar	59	532 19 15-74	Handle Bolt
14	532 43 71-32	Clipping Deflector	62	532 42 57-11	Belt Retainer
15	532 43 72-73	Handle, Clipping Deflector	64	---	Engine, Honda,
17	581 78 21-01	Rear Baffle			Model Number GCV160-LAOBHH
18	581 91 26-01	T-Knob			* (For service and replacement parts, call Honda Engines at 1-800-426-7701)
19	581 90 21-01	Rope Guide			
20	532 44 45-01	Rear Skirt			
21	532 41 99-49	Spring, Rear Door, LH, Black	83	532 75 00-97	Screw, Hex Washer Head
22	532 14 18-41	Screw, Panhead, Torx #20	84	532 42 81-24	Fastener, Push
24	532 41 99-48	Spring, Rear Door, RH, Grey	85	532 43 45-30	Mounting Bracket,
26	532 41 99-45	Screw, Rear Door/Handle Pivot	96	532 19 79-91	Rear Skirt
28	586 21 25-01	Bolt, Carriage 5/16-18 x 5/8			Clip, Cable
30	580 94 34-05	Grassbag	97	580 68 03-02	Mounting Bracket,
31	585 05 47-02	Frame, Grass Catcher	99	585 66 87-02	Blade Brake/Clutch
34	532 43 81-34	Bracket, Grassbag			Front Shroud Assembly
39	585 90 07-03	Handle Bracket, LH	100	532 43 94-68	Control, Throttle
40	585 90 08-03	Handle Bracket, RH	101	532 18 83-65	Screw
41	532 15 04-06	Screw, Dogpoint 3/8-16 x 1-1/8	103	532 18 03-93	Spring, Blade Brake/Clutch
44	581 70 83-41	Kit, Lawn Mower Housing	105	532 13 20-04	Nut, Hex
46	---	Blade Brake/Clutch Assembly *	114	532 19 96-87	Screw, Blade Brake/Clutch Control
47	532 43 83-88	Blade, 22"	115	584 29 94-01	Screw, Hi-Lo Thread 5/16
			--	115 63 46-32	Operator's Manual, English / French
			--	115 63 46-46	Operator's Manual, Spanish

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.



HUSQVARNA ROTARY LAWN MOWER - MODEL NO. HD800BBC (96143008904) PRODUCT NO. 961 43 00-89

KEY NO.	PART NO.	DESCRIPTION	KEY NO.	PART NO.	DESCRIPTION
1	581 95 05-05	Drive Control Assembly (Includes Cable)	32	581 68 51-01	Wheel & Tire Assembly, Rear, 8"
9	581 95 21-01	Cable, Drive	33	532 40 91-48	Nut, Flangelock 3/8-16
10	532 43 27-90	Mounting Bracket, Drive Control	34	532 19 74-80	O-Ring
11	817 41 13-12	Screw	35	532 43 05-98	Axle, Rear
12	873 94 08-00	Nut, Hex	36	532 44 22-07	Axle, Front
13	581 68 08-01	Gearcase Assembly, Complete	37	532 16 34-09	Screw, Hi-Lo Thread, 12 x 5/8
14	532 19 34-43	Pulley, Drive	38	532 19 17-30	Nut, Hex
15	532 08 83-48	Washer, Flat	39	532 40 70-59	Bolt
16	532 43 00-30	Rod, Connecting	40	532 41 08-31	Wheel & Tire Assembly, Front, 8"
17	532 75 11-53	Nut, Hex	41	532 40 48-35	Pinion
18	532 43 78-69	Kit, Selector Assembly	44	532 43 77-99	Belt, Drive
19	532 43 39-96	Knob, Wheel Adjuster	47	532 06 77-25	Washer, Flat
20	580 80 69-01	Debris Shield	48	532 43 84-89	Water Washout Assembly
21	532 43 52-42	Anchor	49	532 43 49-94	Fitting, Hose, Water Washout
23	532 43 78-70	Wheel Axle Assembly, LH	50	532 41 55-85	Washer, Lock, Internal Tooth
24	532 43 35-11	Bracket, Height Adjustment	51	532 41 55-86	Locknut, Hex, with O-Ring
25	532 42 60-65	Mounting Bracket, Debris Shield	55	532 40 65-58	Spring, Tension
26	532 44 21-53	Belt Keeper	58	532 43 52-41	Bolt, Shoulder
28	812 00 00-58	E-Ring 7/16	59	532 44 21-13	Support Bracket
29	581 84 04-01	Cover, Dust, Wheel	61	532 18 16-98	Screw
30	817 00 05-10	Screw, Hex Head 1/4-20	62	532 19 79-91	Clip, Cable
31	532 40 48-45	Pawl, Drive	63	532 42 81-24	Fastener, Push
			84	532 41 64-05	Adapter, Quick-Connect Coupler
			85	532 43 90-77	Support Bracket, Front Axle

NOTE: All component dimensions given in U.S. inches. 1 inch = 25.4 mm. **IMPORTANT:** Use only Original Equipment Manufacturer (O.E.M.) replacement parts. Failure to do so could be hazardous, damage your lawn mower and void your warranty.