

WSM

WORKSHOP MANUAL COMPACT TRACK LOADER

SVL75-2

Kubota

CONTENTS

TO THE READER TO THE READER

I INFORMATION

CONTENTS

INFORMATION

1. SAFETY FIRST I-1
2. SAFETY PRECAUTIONS FOR WORK..... I-2
3. SAFETY DECALS I-7
4. MAIN SPECIFICATIONS..... I-12
5. DIMENSIONS I-13

G GENERAL

CONTENTS

GENERAL

1. MACHINE IDENTIFICATION..... G-1
2. ENGINE IDENTIFICATION G-2
3. MUFFLER FULL ASSEMBLY
IDENTIFICATION G-4
4. GENERAL PRECAUTIONS..... G-6
5. HANDLING PRECAUTIONS FOR
ELECTRICAL PARTS AND WIRING..... G-10
6. LUBRICANT, FUEL AND COOLANT G-17
7. TIGHTENING TORQUES..... G-18
8. MAINTENANCE..... G-22
9. SPECIAL TOOL..... G-65

1 ENGINE

CONTENTS

MECHANISM

1. SPECIFICATIONS..... 1-M1
2. DIMENSIONS 1-M2
3. PERFORMANCE CURVES..... 1-M3
4. ENGINE BODY 1-M4
5. LUBRICATING SYSTEM..... 1-M6
6. COOLING SYSTEM 1-M7
7. COMMON RAIL SYSTEM (CRS) 1-M9
8. EGR SYSTEM 1-M22
9. EXHAUST SYSTEM..... 1-M24

SERVICING

1. TROUBLESHOOTING..... 1-S1
2. SERVICING SPECIFICATIONS..... 1-S5
3. TIGHTENING TORQUES OF
SCREWS, BOLTS AND NUTS FOR
SPECIAL USE 1-S10
4. CHECKING, REMOVING AND
SERVICING 1-S12

2 MACHINE BODY

CONTENTS

SERVICING

1. FRONT ATTACHMENT 2-S1
2. UPPER STRUCTURE 2-S9
3. TRACK FRAME 2-S36

3 HYDRAULIC SYSTEM

CONTENTS

MECHANISM

1. HYDRAULIC CIRCUIT 3-M1
2. HYDRAULIC DEVICE LAYOUT 3-M3
3. HYDRAULIC SYSTEM 3-M4

4. HST PUMP 3-M50
5. GEAR PUMP 3-M53
6. TRAVEL CONTROL PILOT VALVE 3-M55
7. FRONT CONTROL PILOT VALVE 3-M62
8. CONTROL VALVE..... 3-M69
9. TRAVEL MOTOR..... 3-M73
10. LIFT ARM CYLINDER 3-M75
11. BUCKET CYLINDER 3-M76
12. HYDRAULIC QUICK HITCH
CYLINDER..... 3-M77
13. UNLOAD VALVE 3-M78
14. AUX SOLENOID VALVE 3-M81
15. HYDRAULIC QUICK HITCH
SOLENOID VALVE (OPTION)..... 3-M82
16. HIGH-FLOW SOLENOID VALVE
(OPTION)..... 3-M84

SERVICING

1. TROUBLESHOOTING..... 3-S1
2. SERVICE DATA..... 3-S9
3. PERFORMANCE CHECKS AND
ADJUSTMENT METHODS..... 3-S12
4. REMOVING/INSTALLING 3-S25
5. HYDRAULIC HOSE 3-S170

4 ELECTRICAL SYSTEM

CONTENTS

SERVICING

1. DIAGNOSING MALFUNCTION 4-S1
2. WIRING CIRCUIT 4-S4
3. ELECTRONIC EQUIPMENT LAYOUT 4-S5
4. UNPLUGGING ELECTRICAL
CONNECTORS AND WIRING
LAYOUT..... 4-S6
5. CONNECTOR TERMINAL..... 4-S20
6. TROUBLESHOOTING FOR
START-UP PROBLEM 4-S22
7. INSPECTION 4-S23
8. INSTRUMENT PANEL..... 4-S32
9. TROUBLESHOOTING..... 4-S55
10. FLOW CHART OF THE USER MODE
AND SERVICE MODE SETTINGS..... 4-S158

5 CABIN

CONTENTS

MECHANISM

1. AIR CONDITIONER SYSTEM 5-M1
2. WIPER 5-M19

SERVICING

1. TROUBLESHOOTING..... 5-S1
2. MAINTENANCE AND SERVICE
RELATED SPECIFICATIONS 5-S4
3. PRECAUTIONS WHEN REPAIRING
THE REFRIGERANT SYSTEM 5-S5
4. INSPECTING AND CHARGING THE
REFRIGERANT SYSTEM 5-S10
5. INSPECTION AND DISASSEMBLY 5-S19
6. REMOVING AND INSTALLING
WINDOW 5-S55
7. WINDOW WASHER 5-S64

8. HYDRAULIC HOSE ROUTING5-S66

TO THE READER

This Workshop Manual tells the servicing personnel about the mechanism, servicing and maintenance of the machine. It contains 4 parts: "**Information**", "**General**", "**Mechanism**" and "**Servicing**".

■ Information

This section contains information below.

- Safety First
- Safety Label
- Specification
- Dimension

■ General

This section contains information below.

- Engine Identification
- Model Identification
- General Precautions
- Maintenance Check List
- Check and Maintenance
- Special Tools

■ Mechanism

This section contains information on the structure and the function of the unit. Before you continue with the subsequent sections, make sure that you read this section.

Refer to the latest version of Workshop Manual (Code No. 9Y121-06741) for the diesel engine that this workshop manual does not include.

■ Servicing

This section contains information below.

- Troubleshooting
- Servicing Specifications
- Tightening Torques
- Checking, Disassembling and Servicing

All illustrations, photographs and specifications contained in this manual are of the newest information available at the time of publication.

KUBOTA reserves the right to change all information at any time without notice.

Since this manual includes several models, information or illustrations and photographs can show more than one model.

Record of Revisions

Last digit of the Code No.	Date	Page	Main Revised Point and Corrective Measures	Remarks
1	2016.12.28	I-12	AUX flow rate for high-flow has been added.	T. S
		3-M1, 2	Hydraulic diagram for high-flow has been added.	
		3-M3	High-flow solenoid valve has been added.	
		3-M7	Hydraulic diagram for high-flow has been added.	
		3-M53	Specification of gear pump for high-flow model has been added.	
		3-M55 to 3-M66	Specification of multi-function control lever for high-flow model has been added.	
		3-M84, 85	Specification of high-flow solenoid valve has been added.	
		3-S21	Measuring the high-flow pressure has been added.	
		3-S163	Removal and installation procedure of high-flow solenoid valve has been added.	
		3-S174	Hydraulic hose piping of high-flow solenoid valve has been added.	
		3-S175 to 3-S177	Hydraulic hose list has been updated.	
		4-S5 to 4-S8	High-flow solenoid valve has been added.	
		4-S32 to 4-S36	Error code list has been updated.	
		4-S51 to 4-S152	Troubleshooting has been updated.	
		Appendices	Wire harness, connector chart and electrical circuit diagram have been added.	
2	2018.2.28	G-22	Maintenance interval has been changed.	T. S
		G-45	Replacing the water separator filter element has been added in the "Every 500 Service Hours".	
		2-S15	Fuel tube list (serial number 035178 or later) has been added.	
		3-M1, 2	Hydraulic circuit diagrams have been corrected.	
3	2019.03.15	G-23, G-24	Maintenance interval for biodiesel has been added.	T. S
		G-56	Maintenance procedure for CCV heater has been added.	
		G-64	Fuse layout for CCV heater has been added.	
		2-S37 to 2-S40	Service specifications and allowable limits for the front idler, rear idler, track roller, and sprocket have been added.	
		4-S5, 4-S16	Accelerator dial sensor has been added in electronic equipment layout.	
		4-S20	New ECU terminal for accelerator dial sensor has been added.	
		4-S26	Fuse layout for CCV heater has been added.	

It's a preview. You can download the full file by clicking the link below.

<https://shop servicemanual.com/>

Service Manuals from 2\$