




IMPORTANT! – To assure product SAFETY and RELIABILITY, repairs should be performed by MAKITA Service Centers or other qualified service organizations. Always use MAKITA replacement parts.

2 Model 6922NB

08-96

SERVICE CHANGE

1. Change on Gear and Gear Housing.




FIG.	DESCRIPTION	TYPE 1	TYPE 2
41	Gear Case Complete	PART# 159677-9 (Discontinued)	PART# 159930-3
43	Ball Bearing	PART# 211033-2 (608LB)	PART# 210013-5 (698VV)
44	Spur Gear 34	PART# 226267-4 (Discontinued)	PART# 226475-7 (Helical Gear 30)
45	Washer 617	PART# 216209-6	PART# 212048-2 (Thrust Needle Bearing)
46, 62	Rubber Pin 4	PART# 263002-9	-----
49	Armature 115V	PART# 517071-5 (with Spur Gear) (Discontinued)	PART# 517191-5 (with Helical Gear)
59	Gear Housing Complete	PART# 159725-4 (Discontinued)	PART# 134788-1 (Incl. Fig. 47. Bearing Retainer, 344470-6 & 3ea. Screw M4x10, 911111-5 are added)
63	Ball Bearing 608LB	PART# 211033-2	PART# 134790-4 Gear Assembly (Helical Gear)
64	Spur Gear 18	PART# 226268-2	
65	Ball Bearing 6000LLB	PART# 211061-7	
67	Spiral Bevel Gear	PART# 226711-1	

The above parts are interchangeable as a set.