




MAINTENANCE & PARTS MANUAL



SJ-800 Series

Engine Powered

**Model SJ-8831 Serial #36952 & Above
Model SJ-8841 Serial #42029 & Above**

For Service please call 800 275-9522

Skyjack Inc. Service Center 3451, Swenson Ave., St. Charles, IL. 60174 FAX 630 262-0006

For Parts in North America and Asia please call 800 965-4626

Skyjack Inc. Parts Center, 3451 Swenson Ave., St. Charles, IL. 60174 FAX 888 782-4825

For Parts & Service in Europe please call 44-1691-676 236

Skyjack Europe Glovers Meadow, Maesbury Road, Oswestry, Shropshire, UK FAX 44-169- 676 238

CALIFORNIA
Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects, and other reproductive harm.

SERIAL NUMBER BREAKDOWN			
		MANUAL PART # 112114	MANUAL PART # 118938
MODELS	8831	36951 & BELOW	36952 & ABOVE
	8841	42028 & BELOW	42029 & ABOVE

TABLE OF CONTENTS

<u>Section - Paragraph</u>	<u>Page No.</u>	
Section 1 - About Your Aerial Platform		S
1.1 Major Assemblies	1	
1.2 Platform	1	
1.3 Operator's Control Box	1	E
1.4 Manual Storage Box	1	
1.5 Lifting Mechanism	1	
1.6 Maintenance Support	1	
1.7 Base - (Models 71xx & 8xx)	1	C
1.8 Base - (Model 9250)	2	
1.9 Tilt Sensing System	2	
1.10 Serial Number Nameplate	2	T
1.11 Major Components	3	
1.12 Standard and Optional Features	4	
1.13 Operator Safety Reminders	5	I
1.14 Electrocution Hazard	5	
1.15 Safety Precautions	6, 7, 8	
Section 2 - List of Tables		O
Table Of Contents	1	
Section 3 - System component identification and schematics - Operation		N
Table Of Contents	1	
Section 4 - Troubleshooting information - Operation		
Table Of Contents	1	
Section 5 - Maintenance and service - Operation		I
Table Of Contents	1	
Section 6 - Parts lists - Operation		N
List Of Illustrations	2	
		D
		E
		X

The Safety Alert Symbol identifies important safety messages on machines, safety signs in manuals or elsewhere. When you see this symbol, be alert to the possibility of personal injury or death. Follow the instructions in the safety message.



This Safety Alert Symbol Means Attention!

Become Alert! Your Safety Is Involved.



DANGER

DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION

CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.

IMPORTANT

IMPORTANT indicates a procedure(s) essential for safe operation and which, if not followed, may result in a malfunction or damage to the machine.